

SAP Worksheet #1—Title and Approval Page

Final

**Sampling and Analysis Plan
Phase I Site Investigation for
Per- and Polyfluoroalkyl Substances in Soil and Groundwater
Ault Field**

**Naval Air Station Whidbey Island
Oak Harbor, Washington**

Contract Task Order 4041

February 2018

Prepared for:

**Department of the Navy
Naval Facilities Engineering Command
Northwest**

Under the:

**NAVFAC CLEAN 9000 Program
Contract N62470-16-D-9000**

Prepared by:



**1100 112th Ave NE Ste 500
Bellevue, WA 98004**

This page intentionally left blank.

SAP Worksheet #1—Title and Approval Page (continued)

Approval Signatures:

Ken Bowers
Naval Facilities Engineering Command Atlantic
Quality Assurance Officer

Other Approval Signatures:

Kendra Leibman
Naval Facilities Engineering Command Northwest
Remedial Project Manager

David Einan
United States Environmental Protection Agency Region 10
Remedial Project Manager

This page intentionally left blank.

Executive Summary

The Department of the Navy (Navy), Naval Facilities Engineering Command (NAVFAC) Northwest has contracted CH2M HILL, Inc. (CH2M) to conduct sampling activities in groundwater and soil at Ault Field, Naval Air Station Whidbey Island (NASWI), in Oak Harbor, Washington (**Figure 1**). This Sampling and Analysis Plan (SAP) outlines the sampling activities included in the Phase 1 Site Investigation (SI) for per- and polyfluoroalkyl substances (PFAS) in groundwater and soil at Ault Field. CH2M prepared this document under the NAVFAC Comprehensive Long-term Environmental Action—Navy (CLEAN) 9000 Contract N62470-16-D-9000, Contract Task Order 4041, in accordance with the Navy's Uniform Federal Policy (UFP) SAP policy guidance to help ensure that environmental data collected are scientifically sound, of known and documented quality, and suitable for intended uses.

Ault Field is located on Whidbey Island near Oak Harbor, WA, and is one of three NASWI installations. Ault Field was commissioned September 21, 1942. Currently, Ault Field supports Navy tactical electronic attack squadrons flying the EA-18G Growler, the P-3 Orion Maritime Patrol squadrons, and two Fleet Reconnaissance squadrons flying the EP-3E Aries ("Installation Information," 2017).

Based on a desktop review of available data and previous investigations, there are eight potential source areas at Ault Field where aqueous film-forming foam (AFFF) has been utilized: Area 16 (Ault Field Runway Ditches), Area 31 (former Runway Fire Training School), all hangars (collection and storage of AFFF), Area 29 (Clover Valley Fire School), Area 30 (Fire School Can Disposal Area), Area 27 (temporary fire school), Area 28 (Chapel Fire School), and the current firefighting school (**Figure 2**). As part of the Phase 1 SI, the investigation will be focused around the Current Firefighting School, Area 29, and Area 30. The investigation will also be conducted in areas between the Current Firefighting School and the southwestern fence line.

The purpose of the Phase 1 SI is to collect information to support the evaluation of the long-term solutions for the two residential parcels near Ault Field where PFAS have been detected in drinking water above the Lifetime Health Advisory (LHA). Field work under this SI will occur from January 2018 to February 2018 and will include installation of new groundwater wells in the east and south areas of the base and on each of the residential parcels where PFAS exceedances occurred. Select existing on-Base groundwater monitoring wells will also be sampled for PFAS. The Phase 2 SI will investigate other on-Base source areas that may be contributing to the PFAS contamination on Ault Field. This effort will be conducted based on the findings of the Ault Field Preliminary Assessment. The Phase 1 SI objectives are as follows:

- Determine if there is a water-bearing zone below the contaminated zone that may be a suitable drinking water source (i.e., below the EPA's LHA for PFOS and PFOA). If there is a clean water-bearing zone, confirm if the recharge rate is sufficient to provide drinking water to the home.
- Collect groundwater samples from existing on-Base groundwater wells upgradient of the parcels with wells that contain PFAS at levels above the EPA LHA.
- Drill nine new on-Base groundwater wells upgradient of the off-Base parcels above the EPA LHA.
- Assess aquifer conditions at both Residence 1 and 2 by installed series' of wells upgradient of the impacted properties.
- Up to four soil samples will be collected from each boring at each new well installation.

Wells to be installed in the east area include two series of three monitoring wells on-Base near the runways (**Figures 3 and 4**) and one off-Base well at Residence 1 (**Figure 5**). Wells to be installed in the south area include a series of three monitoring wells on-Base north of Residence 2 and one monitoring well off-Base on Residence 2 (**Figure 6**). Existing monitoring wells to be sampled are located in the vicinity of the current fire fighting school and

are shown on **Figure 7**. Groundwater water samples will be collected from each of these selected monitoring wells and from all new monitoring wells installed as part of this effort.

This SAP consists of 37 worksheets specific to the scope of this investigation. All tables are embedded within the worksheets. All figures are included at the end of the document. Field standard operation procedures are included in **Appendix A**. Laboratory Department of Defense Environmental Laboratory Accreditation Program Accreditation letters are included in **Appendix B**. Laboratory standard operation procedures are included in **Appendix C**.

The laboratory information cited in this SAP is specific to Vista Analytical in El Dorado Hills, California. If additional laboratory services are requested requiring modification to the existing SAP, revised SAP worksheets will be submitted to the Navy for approval.

SAP Worksheets

| | |
|--|----------|
| Executive Summary | 5 |
| Acronyms and Abbreviations | 9 |
| SAP Worksheet #1—Title and Approval Page | 1 |
| SAP Worksheet #2—SAP Identifying Information | 11 |
| SAP Worksheet #3—Distribution List | 13 |
| SAP Worksheet #4—Project Personnel Sign-Off Sheet | 15 |
| SAP Worksheet #5—Project Organizational Chart | 17 |
| SAP Worksheet #6—Communication Pathways..... | 19 |
| SAP Worksheet #7—Personnel Responsibilities Table | 23 |
| SAP Worksheet #8—Special Personnel Training Requirements Table | 25 |
| SAP Worksheet #9-1—Project Scoping Session Participants Sheet | 27 |
| SAP Worksheet #9-2—Project Scoping Session Participants Sheet | 29 |
| SAP Worksheet #9-3—Project Scoping Session Participants Sheet | 30 |
| SAP Worksheet #9-4—Project Scoping Session Participants Sheet | 31 |
| SAP Worksheet #10—Conceptual Site Model | 33 |
| SAP Worksheet #11—Project Quality Objectives/Systematic Planning Process Statements | 35 |
| SAP Worksheet #12—Measurement Performance Criteria Table – Field QC Samples..... | 41 |
| SAP Worksheet #13—Secondary Data Criteria and Limitations Table | 43 |
| SAP Worksheet #14—Summary of Project Tasks | 45 |
| SAP Worksheet #15—Reference Limits and Evaluation Table | 49 |
| SAP Worksheet #16—Project Schedule/Timeline Table..... | 51 |
| SAP Worksheet #17—Sampling Design and Rationale | 53 |
| SAP Worksheet #18—Sampling Locations and Methods/SOP Requirements Table..... | 55 |
| SAP Worksheet #19—Analytical SOP Requirements Table | 57 |
| SAP Worksheet #20—Field Quality Control Sample Summary Table..... | 59 |
| SAP Worksheet #21—Project Sampling SOP References Table | 61 |
| SAP Worksheet #22—Field Equipment Calibration, Maintenance, Testing, and Inspection Table | 63 |
| SAP Worksheet #23—Analytical SOP References Table | 65 |
| SAP Worksheet #24—Analytical Instrument Calibration Table..... | 67 |
| SAP Worksheet #25—Analytical Instrument and Equipment Maintenance, Testing, and Inspection Table | 69 |
| SAP Worksheet #26—Sample Handling System | 71 |
| SAP Worksheet #27—Sample Custody Requirements Table | 73 |
| SAP Worksheet #28—Laboratory QC Samples Table | 75 |
| SAP Worksheet #29—Project Documents and Records Table | 77 |
| SAP Worksheet #30—Analytical Services Table | 79 |
| SAP Worksheet #31—Planned Project Assessments Table..... | 81 |
| SAP Worksheet #32—Assessment Findings and Corrective Action Responses | 83 |

SAP Worksheet #32-1—Laboratory Corrective Action Form..... 85
SAP Worksheet #32-2—Field Performance Audit Checklist..... 87
SAP Worksheet #32-3—Safe Behavior Observation Form 89
SAP Worksheet #33—QA Management Reports Table 91
SAP Worksheet #34-36—Data Verification and Validation (Steps I and IIa/IIb) Process Table..... 93
SAP Worksheet #37—Usability Assessment..... 95
References 97

Appendixes

- A Field Standard Operating Procedures – CH2M
- B Laboratory DoD ELAP Accreditation Letters
- C Laboratory Standard Operating Procedures

Tables

- 10-1 Site Description and Background
- 11-1 Problem Definitions, Environmental Questions, and Project Quality Objectives
- 17-1 Sampling Design and Rationale

Figures

- 1 Base Location Map
- 2 Site Layout Map
- 3 Proposed SE Wells 1, 2, and 3
- 4 Proposed SE Wells 4, 5, and 6
- 5 Proposed New Well at Residence 1
- 6 Proposed New Wells 7, 8, 9, and at Residence 2
- 7 Existing Wells to be Sampled

Acronyms and Abbreviations

| | |
|-------|---|
| °C | degree(s) Celsius |
| µg/L | microgram(s) per liter |
| AFFF | aqueous film-forming foam |
| bgs | below ground surface |
| CA | corrective action |
| CAS | Chemical Abstract Services |
| CCV | continuing calibration verification |
| CH2M | Ch2M HILL, Inc. |
| CLEAN | Comprehensive Long-term Environmental Action—Navy |
| DL | detection limit |
| DO | dissolved oxygen |
| DoD | Department of Defense |
| DQI | data quality indicator |
| DV | data validation |
| EDD | electronic data deliverable |
| EDS | Environmental Data Services, Inc. |
| ELAP | Environmental Laboratory Accreditation Program |
| FCLP | Field Carrier Landing Practice |
| FD | field duplicate |
| FTL | Field Team Leader |
| H&S | health and safety |
| HDPE | high density polyethylene |
| HQ | hazard quotient |
| HSM | Health and Safety Manager |
| HSP | Health and Safety Plan |
| ICAL | initial calibration |
| ID | identification |
| IDW | investigation-derived waste |
| IS | internal standard |
| LC | liquid chromatograph |
| LCL | lower criteria limit |
| LCS | laboratory control sample |
| LHA | Lifetime Health Advisory |
| LOD | limit of detection |
| LOQ | limit of quantitation |
| MDL | method detection limit |
| mL | milliliter(s) |
| MPC | measurement performance criteria |
| MS | matrix spike |
| MS | mass spectrometer |
| MSD | matrix spike duplicate |

| | |
|--------|---|
| N/A | not applicable |
| NASWI | Naval Air Station Whidbey Island |
| NAVFAC | Naval Facilities Engineering Command |
| Navy | Department of the Navy |
| OLF | Outlying Landing Field |
| ORP | oxidation-reduction potential |
| PAL | project action limit |
| PC | Project Chemist |
| PFBS | perfluorobutane sulfonate |
| PFAS | per- and polyfluoroalkyl substance |
| PFOA | perfluorooctanoic acid |
| PFOS | perfluorooctane sulfonate |
| PHA | Provisional Health Advisory |
| PID | photoionization detector |
| PM | Project Manager |
| POC | point of contact |
| PQL | project quantitation limit |
| PVC | polyvinyl chloride |
| QA | quality assurance |
| QAO | Quality Assurance Officer |
| QAPP | Quality Assurance Project Plan |
| QC | quality control |
| QL | quantitation limit |
| QM | Quality Manager |
| QSM | Quality Systems Manual |
| RL | reporting limit |
| RPD | relative percent difference |
| RPM | Remedial Project Manager |
| RSD | relative standard deviation |
| RSL | Regional Screening Level |
| SAP | Sampling and Analysis Plan |
| SBO | safe behavior observation |
| SI | Site Investigation |
| SOP | standard operating procedure |
| SSC | Site Safety Coordinator |
| STC | Senior Technical Consultant |
| TAL | target analyte list |
| TBD | to be determined |
| TCL | target compound list |
| TM | Task Manager |
| UCL | upper confidence limit |
| UFP | Uniform Federal Policy |
| USEPA | United States Environmental Protection Agency |
| WQP | water quality parameter |

SAP Worksheet #2—SAP Identifying Information

Site Name: Ault Field, Oak Harbor, Naval Air Station Whidbey Island (NASWI)
Operable Unit/Solid Waste Management Unit: Not applicable (N/A)
Contractor Name: CH2M HILL, Inc. (CH2M)
Contract Number: N62470-16-D-9000
Contract Title: Comprehensive Long-term Environmental Action—Navy (CLEAN) 9000 Program
Work Assignment Number (optional): Contract Task Order 4041

1. This Sampling and Analysis Plan (SAP) was prepared in accordance with the requirements of the following:
 - *Guidance for Quality Assurance Project Plans (QAPPs)* (USEPA, 1998)
 - *Uniform Federal Policy (UFP) – QAPP* (USEPA, 2005)
 - *Guidance on Systematic Planning Using the Data Quality Objectives Process* (USEPA, 2006).
2. Identify regulatory program: Comprehensive Environmental Response, Compensation, and Liability Act of 1980.
3. This document is a project-specific SAP. The approval entities are Naval Facilities Engineering Command (NAVFAC) Northwest Remedial Project Manager (RPM) and NAVFAC Atlantic Quality Assurance Officer (QAO).
4. List dates of scoping sessions that were held:

| Scoping Session | Date |
|--|--------------------|
| Project Scoping Session with NAS Whidbey Island Remedial Project Manager (RPM) | August 9, 2017 |
| Project Scoping Session with NAS Whidbey Island Remedial Project Manager (RPM) | September 6, 2017 |
| Project Scoping Session with NAS Whidbey Island Remedial Project Manager (RPM) | September 8, 2017 |
| Project Scoping Session with NAS Whidbey Island Remedial Project Manager (RPM) | September 20, 2017 |
| Project Scoping Session with NAS Whidbey Island Remedial Project Manager (RPM) | September 21, 2017 |

5. List dates and titles of any SAP documents written for previous site work that are relevant to the current investigation.

| | |
|--|--------------|
| <i>Investigation of Perflourinated Compounds in Drinking Water, Naval Air Station Whidbey Island, Oak Harbor and Coupeville, Washington (Navy 2017a)</i> | January 2017 |
| <i>Sampling and Analysis Plan Site Inspection for Perfluorinated Compounds in Groundwater, Outlying Landing Field, Coupeville, Washington (Navy 2017b)</i> | January 2017 |

SAP Worksheet #2—SAP Identifying Information (continued)

6. List organizational partners (stakeholders) and connection with lead organization:
 - NAVFAC LANT – Project Chemist, Ken Bowers
 - NAVFAC Northwest – Remedial Project Manager, Kendra Leibman
 - USEPA – Project Manager, Dave Einan
 - City of Oak Harbor, Washington – City Engineer, Arnie Peterschmidt
 - Island County Public Health, Washington – Hydrogeologist, Doug Kelly
7. Lead organization:
 - Department of the Navy (Navy) – NAVFAC Northwest
8. If any required SAP elements or required information are not applicable (N/A) to the project or are provided elsewhere, then note the omitted SAP elements and provide an explanation for their exclusion as follows:
 - A crosswalk table is excluded because all required information is provided in this SAP.

SAP Worksheet #3—Distribution List

| Name of SAP Recipients | Title/Role | Organization | Telephone Number | Email Address or Mailing Address |
|------------------------|---|-----------------------------------|------------------|----------------------------------|
| Kendra Leibman | RPM/Task Order Contracting Officer's Representative | NAVFAC Northwest | | |
| Steve Skeehan | Technical Representative | NAVFAC Northwest | | |
| Charie Escola | Technical Representative | NAVFAC Northwest | | |
| Judy Solomon | NAVFAC QAO | NAVFAC Atlantic | | |
| Rebecca Maco | Project Manager (PM) | CH2M | | |
| Peter Lawson | Senior Technical Consultant (STC) | CH2M | | |
| Janice Horton | Task Manager | CH2M | | |
| Anita Dodson | Program Chemist/SAP Reviewer | CH2M | | |
| Janna Staszak | Program SAP Quality Reviewer | CH2M | | |
| Laura Cook | Program PFAS Subject Matter Expert (SME) | CH2M | | |
| Tiffany Hill | Project Chemist (PC) | CH2M | | |
| Doug Weaver | Data Validator | Environmental Data Services (EDS) | | |
| Susan Moore | Activity Quality Manager (AQM) | CH2M | | |
| To be determined (TBD) | Field Team Leader (FTL) | CH2M | | |
| Loren Kaehn | Health and Safety Manager | CH2M | | |
| TBD | Site Safety Coordinator (SSC) | CH2M | | |
| Martha Maier | Laboratory PM | Vista Analytical | | |


This page intentionally left blank.

SAP Worksheet #4—Project Personnel Sign-Off Sheet

| Name | Organization/Title/Role | Telephone Number | Signature/Email receipt | SAP Section Reviewed | Date SAP Read |
|---------------|--------------------------------------|------------------|-------------------------|----------------------|---------------|
| Rebecca Maco | CH2M/PM | | | | |
| Janice Horton | CH2M/Task Manager | | | | |
| Peter Lawson | CH2M/STC | | | | |
| Janna Staszak | CH2M/SAP Reviewer | | | | |
| Laura Cook | CH2M/PFAS SME | | | | |
| Loren Kaehn | CH2M/Health and Safety Manager (HSM) | | | | |
| Anita Dodson | CH2M/Navy Program Chemist | | | | |
| Tiffany Hill | CH2M/PC | | | | |
| TBD | Data Validator | TBD | | | |
| TBD | FTL | CH2M | | | |
| TBD | SSC | CH2M | | | |
| Martha Maier | Laboratory PM | Vista Analytical | | | |

This page intentionally left blank.

SAP Worksheet #5—Project Organizational Chart



----- Lines of Communication
 _____ Lines of Authority

This page intentionally left blank.

SAP Worksheet #6—Communication Pathways

| Communication Drivers | Responsible Entity | Name | Phone Number and/or Email | Procedure |
|---|-------------------------------------|---------------------------------|---------------------------|---|
| Communication with Base representatives, RPM, and CH2M FTL/SSC | Navy Technical Representative (NTR) | Steve Skeehan Charlie Escola | | Primary point of contact (POC) for the Navy for the contractor during field work; can delegate communication to other internal POCs. |
| Communication with Base | RPM | Kendra Leibman | | Primary POC for facility; can delegate communication to other internal or external POCs. CH2M PM will notify RPM by email or telephone call within 24 hours for field changes affecting the scope or implementation of the SAP. |
| Communication regarding overall project status and implementation and primary POC with RPM and project team | CH2M PM | Rebecca Maco | | Oversees project and will be informed of project status by the TM. If field changes occur, PM will work with the RPM to communicate in-field changes to the team by email within 24 hours. All data results will be communicated to the project team following data receipt and review. |
| Quality issues, and technical communications for project implementation, and data interpretation | CH2M STC | Peter Lawson | | Contact the STC regarding quality issues during project implementation. The STC will report to the PM, the Technical Representative, and the RPM. Contact STC regarding questions/issues encountered in the field, input on data interpretation, as needed. STC will have 24 hours to respond to technical field questions as necessary. Additionally, STC will review the data as necessary prior to Navy discussions and reporting review. |
| Quality issues during and technical communications for project implementation and data interpretation | CH2M AQM | Susan Moore | | Contact the AQM regarding quality issues during project implementation. The AQM will report to the PM and the RPM. |
| Health and safety (H&S) | CH2M HSM | Loren Kaehn | | Responsible for generation of the Health and Safety Plan (HSP) and approval of the activity hazard analyses prior to the start of fieldwork. The PM will contact the HSM as needed regarding questions/issues encountered in the field. |

SAP Worksheet #6—Communication Pathways (continued)

| Communication Drivers | Responsible Entity | Name | Phone Number and/or E-mail | Procedure |
|--|---|----------------------------|----------------------------|---|
| H&S | CH2M SSC | TBD | TBD | Responsible for the adherence of team members to the site safety requirements described in the HSP. Will report H&S incidents and near losses to the PM as soon as possible. |
| Stop Work Order | CH2M PM CH2M FTL Field Team Members | Rebecca Maco TBD TBD | | Any field member can immediately stop work if an unsafe condition that is immediately threatening to human health is observed. The field staff, FTL, or SSC should notify the Technical Representative, the RPM, and the CH2M PM immediately. Ultimately, the FTL and PM can stop work for a period of time. NAVFAC Northwest can stop work at any time. |
| Work plan changes in field | FTL | TBD | TBD | Documentation of deviations from the work plan will be made in the field logbook, and the PM will be notified immediately. Deviations will be made only with approval from the PM. |
| Field changes/field progress reports | FTL | TBD | TBD | Documentation of field activities and work plan deviations (made with the approval of STC and/or QAO) in field logbooks; provide daily progress reports to PM. |
| Reporting laboratory data quality issues | Analytical Laboratory Project Managers | Martha Maier | | All QA/quality control (QC) issues with project field samples will be reported within 2 days to the PC by the laboratory. |
| Field and analytical corrective actions (CAs) | Program Chemist | Tiffany Hill | | Any CAs for field and analytical issues will be determined by the FTL and/or the PC and reported to the PM within 4 hours. |
| Data tracking from field collection to database upload Release of analytical data | PC | Tiffany Hill | | Tracks data from sample collection through database upload daily. No analytical data can be released until validation of the data is completed and has been approved by the PC. The PC will review analytical results within 24 hours of receipt for release to the project team. The PC will inform the Navy CLEAN Program chemist who will notify the Navy QAO of any laboratory issues that would prevent the project from meeting project quality objectives or would cause significant delay in project schedule. |

SAP Worksheet #6—Communication Pathways (continued)

| Communication Drivers | Responsible Entity | Name | Phone Number and/or E-mail | Procedure |
|-------------------------------|------------------------|--|----------------------------|--|
| Reporting data quality issues | Data Validation (DV) | TBD | TBD | The data validator reviews and qualifies analytical data as necessary. The data along with a validation narrative are returned to the PC within 7 calendar days. |
| Field CAs | FTL, PM, and Deputy PM | TBD Rebecca Maco Janice Horton | TBD | Field and analytical issues requiring CA will be determined by the FTL and/or PM on an as-needed basis. The PM will ensure SAP requirements are met by field staff for the duration of the project. The FTL will notify the PM via phone of any need for CA within 4 hours. The PM may notify the Technical Representative and RPM of any field issues that would negatively affect schedule or the ability to meet project data quality objectives. |

This page intentionally left blank.

SAP Worksheet #7—Personnel Responsibilities Table

| Name | Title/Role | Organizational Affiliation | Responsibilities |
|----------------------------------|------------------------------|----------------------------|---|
| Kendra Leibman | RPM | NAVFAC Northwest | Oversees project for Navy and provides base-specific information, and coordinates with NASWI. |
| Steven Skeehan Charlie Escola | Technical Representative | NAVFAC Northwest | Oversees field work, provides base-specific information, and coordination with NASWI. |
| Rebecca Maco | PM | CH2M | Oversees and manages project activities. |
| Peter Lawson | STC/QM | CH2M | Provides senior technical support for project approach and execution. Provides QA oversight. |
| Susan Moore | QM | CH2M | Provides senior technical support for project approach and execution. Provides QA oversight. |
| Laura Cook | SME | CH2M | Provides senior technical support for project approach and execution. |
| Loren Kaehn | HSM | CH2M | Prepares HSP and manages H&S for all field activities. |
| Anita Dodson | Navy Program Chemist | CH2M | Provides SAP project delivery support, reviews and approves SAPs, and performs final data evaluation and QA oversight. |
| Janna Staszak | Program SAP Quality Reviewer | CH2M | Reviews and approves changes or revisions to the SAP. |
| Tiffany Hill | Project Chemist | CH2M | Data management: Performs data evaluation and QA oversight, is the POC with laboratory and validator for analytical issues. |
| Doug Weaver | Data Validator | EDS | Validates laboratory data from an analytical standpoint prior to data use. |
| TBD | FTL | CH2M | Coordinates all field activities and sampling. |
| TBD | Field Staff | CH2M | Conducts field activities. |
| Martha Maier | Laboratory PM | Vista Analytical | Manages samples tracking and maintains good communication with PC. |
| Anne Helak | Laboratory QAO | Vista Analytical | Responsible for audits, CA, and checks of QA performance within the laboratory. |

This page intentionally left blank.

SAP Worksheet #8—Special Personnel Training Requirements Table

No specialized training beyond standard H&S training is required for this project.

This page intentionally left blank.

SAP Worksheet #9-1—Project Scoping Session Participants Sheet

| Project Name: Site Investigation of Per- and Polyfluoroalkyl Substances (PFAS) in Groundwater Projected Date(s) of Drilling and Sampling: November 2017 - February 2018 PM: Rebecca Maco | | Site Name: Ault Field, NAS Whidbey Island Site Location: Oak Harbor, Washington | | |
|---|--|--|---------|----------------|
| Date of Session: August 9, 2017 Scoping Session Purpose: To obtain consensus on the path forward for the SI for PFAS in groundwater at Ault Field. | | | | |
| Name | Title/Project Role | Affiliation | Phone # | E-mail Address |
| Laura Himes | Environmental Engineer/Technical Support | NAVFAC Northwest | | |
| Charles Escola | NTR | NAVFAC Northwest | | |
| Kendra Leibman | RPM | NAVFAC Northwest | | |
| Lloyd Potter | Lead Engineering Technician | NAVFAC Northwest | | |
| Rebecca Maco | PM | CH2M | | |
| Rachel Clennon | TM | CH2M | | |
| Janice Horton | TM | CH2M | | |

Comments

The initial rationale for the SI at Ault Field was that at similar Navy sites, aqueous film-forming foam (AFFF)-containing PFAS was used, and PFAS were detected in groundwater. Recent sampling of drinking water within a one mile radius of on-Base source areas yielded an exceedance of PFOA in one single-use residential well (Residence 1) east of the base boundary and an exceedance of PFOS in one single-use residential well (Residence 2) south of the base boundary. During the scoping session potential on-Base locations for drilling two series of three wells were identified in an area suspected to be upgradient of Residence 1. To the south, existing wells suspected to be upgradient of Residence 2 were evaluated for accessibility based on their locations within a heavily wooded area. During the scoping session, the Navy and CH2M representatives went to both residences and spoke with tenants regarding well locations.

Field work is expected to begin in late November 2017.

Action Items

- Confirmed several existing wells in the SW area near the current fire training school and marked the locations using ArcGIS mapping. Action Item: Perform records review of areas evaluated during the scoping session. The records review should consider depth and screened intervals relative to source area and downgradient detection at Residence 2, and propose a set of wells to include for sampling in this SI. Develop a figure showing all wells, including abandoned wells and a list of wells for RPM review.
- Marked one potential location for drilling a well on Residence 2 which would initially be a monitoring well, but could eventually be a drinking water well if found to be clean and if permitted as such. Determined the potential location to be over 1,000' from the Area 2 Landfill boundary and as close to the residence as possible without being intrusive on landscaped areas (**Figure 6**). Action Item: Include the monitoring well location on a figure and determine this well depth. Verify with GIS the potential location is at least 1,000' from the Area 2 Landfill boundary.

SAP Worksheet #9-1—Project Scoping Session Participants Sheet (continued)

- Discussed the possibility of Residence 2 as candidates to tie into the Oak Harbor water line utilized by the Navy, which is located across the street from Residence 2.
- Identified candidate well locations in the east area near the airfield and marked locations in the field using ArcGIS mapping program to develop a map for RPM review.
- Discussed the possibility of connecting Residence 1 to the nearby community well system, or to the Oak Harbor water line, assumed to be located within one mile of Residence 1. Action item to reach out to the community well owner and help them assess what actions could be taken to increase capacity of their system in order to tie in Residence 1.

Consensus Decisions

The Project Field Team agrees to the approach for the Phase 1 SI for PFAS in groundwater at Ault Field.

SAP Worksheet #9-2—Project Scoping Session Participants Sheet

| Project Name: Site Investigation of Per- and Polyfluoroalkyl Substances (PFAS) in Groundwater Projected Date(s) of Drilling and Sampling: November 2017 - February 2018 PM: Rebecca Maco | | Site Name: Ault Field, NAS Whidbey Island Site Location: Oak Harbor, Washington | | |
|---|--------------------|--|---------|----------------|
| Date of Session: September 6, 2017 Scoping Session Purpose: To determine alternate well series locations for on-Base wells in the east area, near the airfield. | | | | |
| Name | Title/Project Role | Affiliation | Phone # | E-mail Address |
| Kendra Leibman | RPM | NAVFAC Northwest | | |
| Charles Escola | NTR | NAVFAC Northwest | | |
| Janice Horton | TM | CH2M | | |

Comments

Initial candidate well locations identified during the scoping session performed August 9, 2017 were found to be in proximity to flight lines, therefore well installation in those areas would have required flight line waivers and special training, scheduling conflicts with flights utilizing the nearby runway during drilling and monitoring, and constructed well height limitations. During the scoping session two areas further east of the initial candidate locations were identified for drilling the two well series. One candidate series is located in the area adjacent to the Weapons Storage Area. The second candidate series is located in the area adjacent to the Weapons Handling Area (Building 423). Both well series locations were evaluated to be outside of mapped wetlands and archeological sites. During the scoping session, an additional location for well installation was identified within the Former Mobile Turret Tower Range (MRP site). The MRP site is located in the south area of Ault Field, in an area situated between Area 2 (Western Highlands Landfill) and Residence 2. The MRP site is suspected to be upgradient of Residence 2 well. Additionally, during the scoping session, wells located in Rothboeck Canyon, a former construction landfill south of Building 423, were ground truthed to verify locations. The Rothboeck Canyon wells were found to be mapped incorrectly in the ArcGIS software.

Field work is expected to begin in late November 2017.

Action Items

- Identified alternate well locations for drilling two well series in the east area. Action Item: Update the figures to reflect alternate well locations in both areas, including wetlands boundaries on the figures and provide to RPM for review. Determine well depths for these areas. Review previous PFAS groundwater sampling report for all hangars, Area 16 and Area 31, which will be provided by RPM.
- Identified potential locations for drilling two wells within the MRP site which would be located between Area 2 and Residence 2 well. Action Item: Update figure to reflect these well locations, include wetland boundaries on the figure and provide to RPM for review. Determine well depths for this area.
- Confirmed existing wells in the Rothboeck Canyon area south of Building 423. Action Item: Confirm surveyed location of Rothboeck Canyon wells using Rothboeck soil and groundwater report, which will be provided by RPM.

Consensus Decisions

The Project Field Team agrees to the approach for the Phase 1 SI for PFAS in groundwater at Ault Field.

SAP Worksheet #9-3—Project Scoping Session Participants Sheet

| Project Name: Site Investigation of Per- and Polyfluoroalkyl Substances (PFAS) in Groundwater Projected Date(s) of Drilling and Sampling: November 2017 - February 2018 PM: Rebecca Maco | | Site Name: Ault Field, NAS Whidbey Island Site Location: Oak Harbor, Washington | | |
|---|--------------------|--|---------|----------------|
| Date of Session: September 8, 2017 Scoping Session Purpose: To determine three potential locations for drilling one monitoring well on Residence 1. | | | | |
| Name | Title/Project Role | Affiliation | Phone # | E-mail Address |
| Kendra Leibman | RPM | NAVFAC Northwest | | |
| Rebecca Maco | PM | CH2M | | |

Comments

The monitoring well would be drilled to drinking water construction standards in the event that it could be used as a drinking water well in the future. In the near term, this well will be used as a monitoring well.

Field work is expected to begin in late November 2017.

Action Items

- Determine three possible locations for a monitoring well to be drilled on Residence 1, taking into consideration limitations for fitting a drill rig and support vehicle on the property. Action Item: Create a figure showing the three possible locations and provide to Leslie Yuenger.

Consensus Decisions

The Project Field Team agrees to the approach for the Phase 1 SI for PFAS in groundwater at Ault Field.

SAP Worksheet #9-4—Project Scoping Session Participants Sheet

| Project Name: Site Investigation of Per- and Polyfluoroalkyl Substances (PFAS) in Groundwater Projected Date(s) of Drilling and Sampling: November 2017 - February 2018 PM: Rebecca Maco | | Site Name: Ault Field, NAS Whidbey Island Site Location: Oak Harbor, Washington | | |
|---|--------------------|--|---------|----------------|
| Date of Session: September 20, 2017 to September 21, 2017 Scoping Session Purpose: To obtain consensus on investigation approach and locations | | | | |
| Name | Title/Project Role | Affiliation | Phone # | E-mail Address |
| Steve Skeehan | NTR | NAVFAC Northwest | | |
| Charles Escola | NTR | NAVFAC Northwest | | |
| Janice Horton | TM | CH2M | | |
| Joe Hauser | TM | CH2M | | |
| David Butler | Field Staff | CH2M | | |

Comments

The purpose of the scoping session was to ground-truth existing on-Base wells at Areas 2, 3, 4, 29, and the Current Fire Fighting School. These areas are located in the south of Ault Field and are suspected to be upgradient of Residence 2 well. Ground-truthing activities included opening wells identified as non-abandoned and recording current water level measurements and depth to bottom of the wells. Details such as any locks replaced, updated coordinates for well locations, wells that could not be found, well obstructions, etc., were also recorded. Additionally, the wells located in Rothboeck Canyon were ground-truthed to verify coordinate locations, and lock and key numbers for those wells were recorded.

Field work is expected to begin in late November 2017.

Action Items

- Update UFP-SAP figures and tables to include wells which are available for groundwater sampling.
- Provide to RPM keys to locks which were replaced, and serial numbers for the Rothboeck Canyon well locks.

Consensus Decisions

The Project Field Team agrees to the approach for the Phase 1 SI for PFAS in groundwater at Ault Field.

This page intentionally left blank

SAP Worksheet #10—Conceptual Site Model

Ault Field is located on Whidbey Island near Oak Harbor, Washington (**Figure 1**). **Figure 2** presents the layout of Ault field and the surrounding area. **Table 10-1** presents a summary of the site description and background.

Table 10-1. Site Description and Background

NAS Whidbey Island, Oak Harbor, Washington

| | |
|---|---|
| Site Name | Ault Field, NASWI, Oak Harbor, Washington (Figures 1 and 2) |
| Study Area Description | Ault Field is located on Whidbey Island near Oak Harbor, WA, and is one of three NASWI installations. Ault Field was commissioned September 21, 1942, as part of NASWI. The areas to be investigated are located in the east and south portions of Ault Field, downgradient of potential source areas, but upgradient from residences that showed exceedances for PFOA/PFOS. The two private residences with exceedances for PFOA/PFOS will also be part of this investigation (see Figures 5 and 6). |
| Potential Sources | Based on historical use of AFFF, there are eight potential source areas at Ault Field: Area 16 (Ault Field Runway Ditches), Area 31 (former Runway Fire Training School), all hangars (collection and storage of AFFF), Area 29 (Clover Valley Fire School), Area 30 (Fire School Can Disposal Area), Area 27 (temporary fire school), Area 28 (Chapel Fire School), and the Current Firefighting School (Figure 2). |
| Study Area Investigation History | <p>A three-phase voluntary off-Base drinking water sampling program was conducted November 2016 to June 2017. Off-Base drinking water wells were sampled for PFOS, PFOA, and PFBS. The results from Phase 1 indicated PFOS above the LHA was only present in a well located on Residence 2 and results from Phase 2 indicated PFOA above the LHA was only present in a well located on Residence 1l (Figure 2). Details of the three-phase program are summarized in Final Sampling and Analysis Plan Investigation of Perfluorinated Compounds in Drinking Water (CH2M, 2017a), they are also publicly available at: https://www.navfac.navy.mil/navfac_worldwide/atlantic/fecs/northwest/about_us/northwest_documents/environmental-restoration/pfas-groundwater-and-drinking-water-investigation.html. The vertical extent of PFAS contamination at Residence 1 and Residence 2 is unknown.</p> <p>Drinking water wells were identified within 1 mile downgradient of these Ault Field source areas where AFFF containing PFAS was likely used, and these wells were sampled for PFOS, PFOA and PFBS only, as part of Phase 1 sampling under a phased voluntary sampling program beginning in November 2016. The Phase 1 sampling area included more than 176 properties, from which 82 drinking water well samples were collected. The Phase 1 results indicate that PFOS and/or PFOA are above the PAL in one off-Base drinking water well located south of the current Fire Fighting School. Based on these results and other information made available to the Navy, the drinking water investigation area was extended an additional half-mile downgradient from the current Fire Fighting School to include additional parcels east of the runway, and runway ditches on the east side of Ault Field. This area, referred to as the Phase 2 sampling area, included 60 properties, from which 17 drinking water well samples were collected. Results from Phase 2 investigation indicated that PFOS and/or PFOA are above the PAL in one additional off-Base drinking water well located east of the Ault Field runway, and the investigation area was extended a 0.5-mile downgradient of this area for Phase 3 sampling. The Phase 3 sampling area included 14 properties. PFAS were not detected in any of the samples collected as part of the Phase 3 sampling effort at Ault Field. The sampling areas and locations with PAL exceedances are shown on Figure 2.</p> <p><u>Per Navy’s PFAS Guidance (September 2017), data will be collected for all 14 analytes listed in USEPA Method 537 rev. 1.1.</u></p> <p>On-Base groundwater investigation for PFAS is limited at Ault Field. In 2015, three areas where AFFF may have been stored, handled, or released at Ault Field were investigated, including Hangar 5, and Areas 16 and 31 (Navy, 2016). The two groundwater wells sampled in Area 16 south of where the runways intersect did not contain PFOS or PFOA. The two groundwater wells sampled near Hangar 5 contained detectable traces of PFOS and PFOA. The two groundwater wells sampled at Area 31 contained PFOS and PFOA above the EPA lifetime health advisory.</p> <p>No on-Base PFAS sampling has been conducted in areas that are part of this study’s investigation area. The presence of PFAS in soil is unknown.</p> |
| Current Use | The area surrounding Ault Field is a low-density residential area. Potable water is primarily supplied by private or community drinking water wells, or the City of Oak Harbor. Currently, Ault Field supports Navy tactical electronic attack squadrons flying the EA-18G Growler, the P-3 Orion Maritime Patrol squadrons, and two Fleet Reconnaissance squadrons flying the EP-3E Aries (“Installation Information,” 2017). |

SAP Worksheet #10—Conceptual Site Model (continued)

Table 10-1. Site Description and Background (continued)

NAS Whidbey Island, Oak Harbor, Washington

| | | |
|--|---------------------------------|---|
| Site Conditions | Physical Characteristics | Whidbey Island, including the entire proposed sampling area, lies within the Puget Lowland, a topographic and structural depression between the Olympic Mountains and the Cascade Range. |
| | Geology and Hydrogeology | <p>The surface soil in the vicinity of Ault Field primarily consists of artificial fill, post-glacial deposits, glaciomarine drift, and glacial deposits. Artificial fill, consisting of coarse- or fine-grained material, underlies the runway areas. Post-glacial deposits, consisting of peaty sand and silt, are generally found in the low-lying marshy areas (Navy, 1994).</p> <p>The 1994 Remedial Investigation (RI) Report (Navy, 1994) identified a confined aquifer beneath Area 16 at a depth of approximately 20 to greater than 150 feet bgs and consisting of fine to medium sand with some silt. Clay and silt of the Everson glaciomarine drift forms the overlying confining layer. A single, unconfined aquifer was identified beneath Area 31, interpreted to be the same as that encountered in Area 16, but without the glaciomarine drift that confines the aquifer in Area 16 (presumed to pinch out).</p> <p>Ault Field is located in a valley, with elevated areas to the south, northeast, and east of the field. Because Area 31 lies at the base of the south side of Monkey Hill, groundwater flow mimics topography in that area, flowing to the south, away from the hill and toward the Strait of Juan de Fuca. This was confirmed by the RI Report (Navy, 1994). Across the remainder of the Base, east of the runway, groundwater generally flows to the northeast, and east toward Clover Valley Stream, Clover Valley Lagoon, and Dugualla Bay. West of the runway, there is likely a component of flow to the west toward the Strait of Juan de Fuca.</p> |
| Contaminants of Potential Concern (COPCs) | | 14 PFAS compounds, see Worksheet #15 for complete list of compounds. |
| Nature and Extent | | <p>PFAS are known to be present in two locations in off-Base drinking water. The concentration of PFOS exceeded the LHA in a groundwater sample collected from a water supply well located off-Base in the south (Residence 2) and the concentration of PFOA exceeded the LHA in a groundwater sample collected from a water supply well located off-Base in the east (Residence 1) during the 2016-2017 voluntary sampling program. The source of PFAS contamination to the off-Base drinking water wells and the vertical extent of impact is not currently known.</p> <p>Figure 8 shows a summary of the sample results from Phases 1, 2, and 3 of the voluntary off-Base drinking water sampling.</p> <p>In 2015, three areas where AFFF may have been stored, handled, or released at Ault Field were investigated, including Hangar 5, and Areas 16, and 31 (Navy, 2016). The two groundwater wells sampled in Area 16 south of where the runways intersect did not contain PFOS or PFOA. The two groundwater wells sampled near Hangar 5 contained detectable traces of PFOS and PFOA. The two groundwater wells sampled at Area 31 contained PFOS and PFOA above the EPA LHA. The existing on-Base wells which will be sampled under this SI have not been previously sampled for PFAS.</p> |
| Migration Pathways | | <ul style="list-style-type: none"> • Leaching of PFAS currently and/or historically present to groundwater • Transport via advection with groundwater flow • Potential releases to subsurface soil. |
| Potential Receptors/ Exposure Routes | | <ul style="list-style-type: none"> • Groundwater: current users of drinking water (ingestion) • Soil: If an exceedance is detected in soil, it will be investigated under a separate SAP |

SAP Worksheet #11—Project Quality Objectives/Systematic Planning Process Statements

Data Gaps

The following data gaps were identified based on the previous investigations summarized in **Table 10-1**.

- The vertical extent of PFAS contamination at Residence 1 and Residence 2.
- Additional on-Base wells are required to collect data which would provide an understanding of groundwater flow conditions between potential source areas and the impacted properties (Residence 1 and Residence 2).
- Presence of PFAS contamination in existing on-Base wells located within potential source areas west and north of Residence 2. The presence of PFAS in soil is unknown.
- Whether PFAS contamination detected in off-Base drinking water wells (such as Residence 1 and 2) is associated with on-Base sources or other potential sources located off-Base. Information collected from the proposed on-Base monitoring wells will help define whether a connection exists between on-Base sources and off-site detections

Problem Definition/Objective, Environmental Questions, and Project Quality Objectives

The problem definition/objectives, environmental questions, general investigation approaches, and Project Quality Objectives (PQOs) contained in this UFP-SAP are described in **Table 11-1** and are based on the USEPA *Guidance on Systematic Planning Using the Data Quality Objectives Process* (USEPA, 2006) and its seven-step process. The detailed sampling approach, including numbers of samples and a full list of analytes, is provided in **Worksheet #17**. Proposed drilling locations are shown on **Figures 3 through 6**.

Table 11-1

What are the Project Action Limits (PALs)?

Project Action Limits (PALs) are media-specific standards and criteria chosen for evaluation to help provide a conservative assessment of site conditions and determine if further evaluation or action is needed to address concentrations of chemicals present onsite. The following list summarizes the PALs applicable to groundwater.

- USEPA lifetime Health Advisory (LHA) for PFOA and PFOS: 0.07 µg/L, unless both chemicals are detected, then 0.07 µg/L is the LHA for the cumulative concentration of the two chemicals.
- USEPA RSL for perfluorobutane sulfonates (PFBS): 400 µg/L (based on a HQ = 1.0)
- PALs currently do not exist for the remaining 11 PFAS compounds. At the time of drafting the SAP there are no USEPA RSLs or any state regulatory screening levels available. Per Navy policy, data needs to be collected for all 14 analytes listed in USEPA Method 537 rev. 1.1.

PALs currently do not exist for soil. Soil samples are being collected in order to determine the approximate distribution of PFAs in the soil profile at each well location. See **Worksheet 15-2** for the soil reference limits.

For what purpose will the data be used?

The data will be used by the Navy, its contractors, and the stakeholder agencies to define objectives shown in **Table 11-1**.

What types of data are needed (matrix, target analytes, analytical groups, field screening, onsite analytical or offsite laboratory techniques, sampling techniques)?

The data to be collected during this investigation will include the following:

Lithological interpretation of borings from well installations.

SAP Worksheet #11—Project Quality Objectives/ Systematic Planning Process Statements (continued)

Groundwater levels in newly constructed on-base monitoring wells to improve understanding of groundwater flow directions in areas upgradient from Residence 1 and Residence 2.

Groundwater samples will be submitted to an offsite laboratory (Vista Analytical) for PFAS analysis to include analysis of all 14 PFAS compounds that are listed in Method 537, Rev 1.1 as method analytes.

Field measurements of groundwater quality (pH, dissolved oxygen [DO], temperature, conductivity, oxidation-reduction potential [ORP], and turbidity) will be completed during groundwater sampling.

Soil samples will be submitted to an offsite laboratory (Vista Analytical) for PFAS analysis to include analysis of all 14 PFAS compounds that are listed in Method 537, Rev 1.1 as method analytes. Samples to be collected and analyzed to meet each of the project objectives are described in **Worksheet #18**. Sampling and well installation methodology is included in **Worksheet #14**. Justification for individual sample locations is provided in **Worksheet #17 and #18**. The specific target analytes and PALs were included in **Worksheet #15**.

The data will be collected following the SOPs presented in **Worksheet #21**.

Are there any special data quality needs, field or laboratory, in order to support environmental decisions?

No special data quality needs are necessary to support environmental decisions.

Where, when, and how should the data be collected/generated?

Detailed information on data collection is provided on **Worksheets #14, #16, and #17**.

Table 11-1. Problem Definitions, Environmental Questions, and Project Quality Objectives

| Problem Definition/ Objective | Environmental Question | General Investigation Approach | Project Quality Objectives |
|---|---|--|--|
| <p>Determine if deeper wells on Residence 1 and Residence 2 can be installed that show PFOS and PFOA levels below the LHA and with stratigraphy that will support a long-term source of drinking water.</p> | <p>Do deeper wells constructed on the impacted properties represent an option for long-term solution?</p> | <p>On Residence 2, one monitoring well will be installed south of the existing well and will be drilled into the Sea Level Aquifer (up to 150' bgs). A well driller's log is not available for the existing well on the property; however, the pump is thought to be 80' bgs.</p> <p>Based on a desktop evaluation of approximately fifteen well logs in the vicinity of Residence 2, the lithology is highly variable consisting of mostly sandy material with discontinuous interbeds of clay varying from 2ft to 60ft in thickness.</p> <p>On Residence 1, the total depth of the existing well is 35' bgs and according to the well log is screened primarily in sand deposits. Information from a nearby domestic well suggests that the maximum depths of the sand aquifer in this area is approximately 55' bgs, and is underlain by a gray clay unit to a depth of approximately 110' bgs. Based on well drilling logs from adjacent properties, the lithology beneath the clay layer is expected to be a sand unit, suitable for producing groundwater. One new replacement well will be drilled on Residence 1 property, targeting this lower aquifer zone</p> <p>Groundwater will be collected for in-field water quality parameters and laboratory analysis of PFAS from a sample port at the wellheads of the monitoring wells.</p> <p>Routine sampling will be conducted under a separate work plan.</p> | <p>If the new wells show PFAS contamination above the LHA, then these wells will continue to be utilized as groundwater monitoring wells.</p> <p>If the new wells do not show PFAS contamination above the LHA, then additional data collection will occur under a separate SAP for evaluation of feasibility of converting the new wells to domestic drinking water wells in support of the long-term solutions planning.</p> |

SAP Worksheet #11—Project Quality Objectives/Systematic Planning Process Statements (continued)

Table 11-1. Problem Definitions, Environmental Questions, and Project Quality Objectives

| Problem Definition/ Objective | Environmental Question | General Investigation Approach | Project Quality Objectives |
|--|---|---|--|
| <p>Estimate on-Base groundwater flow directions and assess whether potential upgradient source areas may be the source of the contamination detected in impacted drinking water wells located at Residences 1 and 2.</p> | <p>Is there PFAS contamination between on-Base source areas and off-Base impacted residences, and is the groundwater flow in these areas toward the off-Base impacted residences?</p> | <p>Two three-well series will be installed on-Base, west and northwest of Residence 1. The wells to the northwest of Residence 1 will be installed to an approximate depth of 75' to 125' bgs (Figure 3). The wells to the west of Residence 1 will be screened at depths between 35' and 70' bgs (Figure 4).</p> <p>One three-well series north of Residence 2 will be drilled on-Base to approximate depths of 100' bgs (Figure 6). The precise screened interval will be determined based on subsurface lithology encountered during drilling. Groundwater levels will be measured in new and existing wells in the area to determine groundwater flow directions in the Sea Level Aquifer in the area north of Residence 2 (Figures 6 and 7).</p> <p>Groundwater samples will be collected for in-field water quality parameters and laboratory analysis of PFAS from a sample port at the wellheads of the monitoring wells. All new monitoring wells and up to seventeen existing on-Base monitoring wells north of Residence 2 will be sampled for PFAS (Figure 7).</p> | <p>If groundwater flow directions and PFAS results from the new on-Base monitoring wells and existing on-Base monitoring wells indicate the residences are downgradient from suspected source areas, then additional investigation is necessary to determine if the new wells installed on the residences could be utilized as drinking water wells.</p> |

SAP Worksheet #11—Project Quality Objectives/Systematic Planning Process Statements (continued)

Table 11-1. Problem Definitions, Environmental Questions, and Project Quality Objectives

| | | | |
|---|---|--|--|
| <p>Assess the aquifer conditions upgradient of both Residences 1 and 2.</p> | <p>What is the horizontal and vertical extent of the aquifers in these areas?</p> | <p>Two three-well series will be installed on-Base, west and northwest of Residence 1 to better define the horizontal and vertical extent of the aquifer in this area.</p> <p>One three-well series will be installed on-Base, north of Residence 2 to better define lateral and vertical extent of the Sea Level Aquifer and determine if this aquifer thins out to the north and west in Clover Valley as indicated by the 1993 Remedial Investigation (Navy, 1993) (Figure 6).</p> | <p>For Residence 1 and 2, the CSM will be updated based on lithology data collected during drilling.</p> <p>If the Sea Level aquifer pinches out to the west indicated by the presence of shallow bedrock, then potential source areas 29 and 30 will be considered unlikely sources of contamination at Residence 2.</p> <p>If the Sea Level aquifer extends to the west, then these source areas will be investigated under Phase 2 as potential sources of contamination observed at Residence 2 as well as sources further to the north.</p> |
|---|---|--|--|

This page intentionally left blank.

SAP Worksheet #12—Measurement Performance Criteria Table – Field QC Samples

Matrix: Groundwater/Soil

Analytical Group: PFAS

Concentration Level: Low

| QC Sample | Analytical Group | Frequency | Data Quality Indicators (DQIs) | Measurement Performance Criteria |
|---|------------------|----------------------------------|--------------------------------|---|
| Matrix Spike(MS)/Matrix Spike Duplicate (MSD) | PFAS | One per 20 samples | Accuracy/Precision | See Worksheet #28 . |
| Field Duplicate (FD) | | One per 10 samples | Precision | Relative percent difference (RPD) < 30% |
| Field Reagent Blank | | One per site per day of sampling | Bias/Contamination | No analytes detected more than (>) ½ limit of quantitation (LOQ) or > 1/10 sample concentration, whichever is greater |
| Cooler Temperature Indicator | | One per cooler | Accuracy/Representativeness | Temperature ≤ 6 degrees Celsius (°C), not frozen |

This page intentionally left blank.

SAP Worksheet #13—Secondary Data Criteria and Limitations Table

| Secondary Data | Data Source (originating organization, report title and date) | Data Generator(s) (originating organization, data types, data generation/collection dates) | How Data Will Be Used | Limitations on Data Use |
|------------------------|--|---|---------------------------------|----------------------------|
| Drinking water sources | CH2M. Drinking Water Source Verification Technical Memorandum. 2016 | Desktop data search performed by CH2M in September 2016 using available historical documents and public records to identify off-Base, potentially impacted, drinking water sources. | Identify drinking water sources | None |
| Groundwater sources | MMEC Group. Summary Report Groundwater Sampling for Perfluorinated Compounds in Hanger 5 and Areas 16 and 31. 2016 | Analytical results for PFAS in onsite groundwater monitoring wells | Identify groundwater sources | None |

This page intentionally left blank.

SAP Worksheet #14—Summary of Project Tasks

Applicable standard operating procedures (SOPs) for project tasks outlined in this section are listed in **Worksheet #21** and provided in **Attachment A**.

Pre-mobilization Tasks

- Subcontractor procurement
 - Analytical laboratories
 - Utility locator
 - Driller
 - Surveyor
 - IDW transportation and disposal contractor
- Fieldwork scheduling
- Coordination with NAS Whidbey Island and property owners for site access, security, and staging areas.

Mobilization

Mobilization for the field effort includes procurement of necessary field equipment and initial transport to the site. Equipment and supplies will be brought to the site when the CH2M field team mobilizes for field activities. Prior to beginning any phase of work, CH2M and its subcontractors will have field meetings to discuss the work items and worker responsibilities, and to familiarize workers with the HSP.

All monitoring wells will be installed in accordance with Washington well construction standards by a Washington-licensed driller.

Utility Clearance

Utilities will be cleared before beginning intrusive activities. CH2M will coordinate utility clearance. In addition, a third-party utility clearance subcontractor will be procured by CH2M to clearly mark the proposed monitoring well locations. Any proposed monitoring well locations within 5 feet of utility locations will be relocated to avoid impact to utilities. If a monitoring well location needs to be relocated, the field team will use its best judgment in relocating the well and will notify the CH2M PM of its new location.

Monitoring Well Installation

Monitoring wells will be installed in accordance with the SOPs listed in **Worksheet #21** and provided in **Appendix A**.

Well Development

Following installation, each monitoring well will be developed by the drilling subcontractor using a combination of surging and pumping throughout the well screen. During monitoring well development, the CH2M field crew will measure water quality parameters (WQPs), including pH, temperature, conductivity, and turbidity with a water quality meter. Development will continue until the water is relatively clear and free of sediment or until 1 hour of development has passed, whichever occurs first.

Development information, including turbidity, pH, specific conductivity, temperature, and gallons of water removed will be recorded in the field logbook. In addition, the water quality meter will be calibrated daily (at a minimum) and the calibration documented in the field notebook.

SAP Worksheet #14—Summary of Project Tasks (continued)

Surveying

The newly installed monitoring wells will be horizontally and vertically located by a Washington-licensed surveyor. The surveyor will provide coordinates of all horizontal points X, Y, to the nearest 0.5 foot and vertical point Z to the nearest 0.01 foot (0.1 foot for unpaved ground surface elevations).

Sampling Tasks

Applicable field logbook and forms should be filled out completely each day.

- Groundwater Level Measurements
 - Before sitewide groundwater sampling, and at least 24 hours after well installation and development has been completed, the depth to groundwater, to the nearest 0.01 foot, will be measured from all monitoring wells. Measurements will be made from the top of the PVC riser, which will be marked with an indelible marker. If during removal of the locking well cap, the well demonstrates signs of being under pressure (escaping air sounds or cap being pushed off by pressure), then the depth to water in that monitoring well will be measured repeatedly over a period of several minutes to determine whether the water level is still changing. If over several minutes the water level continues to change, the water level in that well will not be measured for a period of 1 hour to allow the water level to equilibrate. Depth to water and time measured will be recorded in the field logbook.
- Other Groundwater Field Measurements
 - Field measurements of groundwater quality (pH, DO, temperature, conductivity, ORP, and turbidity) will be completed during groundwater sampling in accordance with the SOPs listed in **Worksheet #21** and provided in Appendix A.
- Collection of groundwater samples
 - Groundwater samples will be collected in accordance with **Worksheet #18** and with the SOPs listed in **Worksheet #21** and provided in **Appendix A**
 - Depth to water, WQPs, and total well depth measurements will be recorded on Groundwater Sampling Data Sheets.
- Collection of soil samples

Decontamination

- All drilling equipment used during monitoring well installation, and re-usable sampling equipment (i.e., Grundfos centrifuge pump) will be decontaminated immediately after each use in accordance with applicable SOPs referenced in **Worksheet #21**. Sensitive instrumentation such as equipment used to collect WQPs will be decontaminated in accordance with the equipment manufacturers' guidelines. Decontamination procedures will follow guidance for PFAS free materials as stated in the SOPs for groundwater and soil in **Worksheet #21**.

IDW Handling

- IDW will be managed in accordance with the *Interim Per- and Polyfluoroalkyl Substances (PFAS) Site Guidance for NAVFAC Remedial Project Managers (RPMs)/September 2017 Update*. September. (Navy, 2017d) and in accordance with SOPs listed in **Worksheet #21** and provided in **Appendix A**.

SAP Worksheet #14—Summary of Project Tasks (continued)

Analyses and Testing Tasks

- The subcontracted analytical laboratory will process and prepare samples for analyses, and will analyze all samples for branched and linear PFAS in accordance with **Worksheets #18 and #19**.

QC Tasks

- Implement SOPs for field and laboratory activities being performed.
- QC samples are described on **Worksheet #20**.

Secondary Data

- See **Worksheet #13**.

DV, Review, and Management Tasks

- See **Worksheets #34 through #36** for discussion of data management procedures.

Documentation and Reporting

- A summary of field activities as well as a data evaluation will be documented in a report and submitted to the Navy RPM for review and approval.

Assessment/Audit Tasks

- **Worksheets #31 and #32**.

Demobilization

Full demobilization will occur when the project is completed and appropriate QA/QC checks have been performed. Personnel no longer needed during the course of field operations may be demobilized prior to the final project completion date. The following will occur prior to demobilization:

- Chain-of-custody records will be reviewed to verify that all samples were collected as planned and submitted for appropriate analyses.
- Restoration of the site to an appropriate level (e.g., repair of deep ruts) will be verified by the CH2M FTL.
- All equipment will be inspected, packaged, and shipped to the appropriate location.

This page intentionally left blank.

SAP Worksheet #15-1—Reference Limits and Evaluation Table

Matrix: Groundwater

Analytical Group: PFAS

| Analyte | Chemical Abstract Service (CAS) Number | USEPA Lifetime Health Advisory (µg/L) | RSLs Tap water HQ = 1.0 (June 2017) (µg/L) | PQL Goal ¹ (µg/L) | Laboratory Limits (µg/L) | | | LCS and MS/MSD Recovery Limits and RPD ² (%) | | |
|--|--|---------------------------------------|--|------------------------------|--------------------------|-------------|------------|---|-----|-----|
| | | | | | LOQs (µg/L) | LODs (µg/L) | DLs (µg/L) | LCL | UCL | RPD |
| Perfluorooctanoic acid (PFOA) ³ | 335-67-1 | 0.07 | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorooctane Sulfonate (PFOS) ³ | 1763-23-1 | 0.07 | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorobutanesulfonic acid (PFBS) ³ | 375-73-5 | -- | 400 | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorohexanoic acid (PFHxA) | 307-24-4 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluoroheptanoic acid (PFHpA) | 375-85-9 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorohexane sulfonate (PFHxS) | 355-46-4 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorononanoic acid (PFNA) | 375-95-1 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorodecanoic acid (PFDA) | 335-76-2 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluoroundecanoic acid (PFUnA) | 2058-94-8 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorododecanoic acid (PFDoA) | 307-55-1 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorotridecanoic acid (PFTrDA) | 72629-94-8 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| Perfluorotetradecanoic acid (PFTeDA) | 376-06-7 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| N-Ethylperfluoro-1-octanesulfonamidoacetic acid (EtFOSAA) | 2991-50-6 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| N-Methylperfluoro-1-octanesulfonamidoacetic acid (MeFOSAA) | 2355-31-9 | -- | -- | 0.008 | 0.008 | 0.005 | 0.00218 | 70 | 130 | 30 |
| PFOA + PFOS (calculated) ⁴ | -- | 0.07 | -- | -- | -- | -- | -- | -- | -- | -- |

Notes:

¹ The project quantitation limit (PQL) goal is equal to the laboratory LOQ.

² Accuracy and precision limits follow laboratory in-house limits per QSM v5.1 Table B-15.

³ PALs are available for PFOS, PFOA, and PFBS. No other criteria are available or applicable to the remaining analytes. The analytes have been included to follow Navy policy.

⁴ If both PFOS and PFOA are detected, the combined concentration must be less than 0.07 µg/L. Otherwise, the chemicals will be compared to the USEPA Lifetime Health Advisory of 0.07 µg/L individually.

DL = detection limit

LCL = lower confidence limit

LCS = laboratory control sample

LOD = limit of detection

RPD = relative percent difference

UCL = upper confidence limit

SAP Worksheet #15-2—Reference Limits and Evaluation Table

Matrix: Soil

Analytical Group: PFAS

| Analyte | CAS No. | Project Screening Limit (µg/kg) | Project Screening Limit Reference ^b | Project QL Goal (µg/kg) | Laboratory-Specific Limits ^b | | | LCS and MS/MSD Recovery Limits and RPD ^a (%) | | |
|--|------------|---------------------------------|--|-------------------------|---|-------------|------------|---|-----|-----|
| | | | | | LOQ (µg/kg) | LOD (µg/kg) | DL (µg/kg) | LCL | UCL | RPD |
| Perfluorooctanoic acid (PFOA) | 335-67-1 | 1,300 | NAVFAC Guidance 2017 | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorooctane Sulfonate (PFOS) | 1763-23-1 | 1,300 | NAVFAC Guidance 2017 | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorobutanesulfonic acid (PFBS) | 375-73-5 | 1,600,000 | NAVFAC Guidance 2017 | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorohexanoic acid (PFHxA) | 307-24-4 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluoroheptanoic acid (PFHpA) | 375-85-9 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorohexane sulfonate (PFHxS) | 355-46-4 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorononanoic acid (PFNA) | 375-95-1 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorodecanoic acid (PFDA) | 335-76-2 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluoroundecanoic acid (PFUnA) | 2058-94-8 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorododecanoic acid (PFDoA) | 307-55-1 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorotridecanoic acid (PFTrDA) | 72629-94-8 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| Perfluorotetradecanoic acid (PFTeDA) | 376-06-7 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| N-Ethylperfluoro-1-octanesulfonamidoacetic acid (EtFOSAA) | 2991-50-6 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |
| N-Methylperfluoro-1-octanesulfonamidoacetic acid (MeFOSAA) | 2355-31-9 | NC | NC | 2.0 | 2.0 | 1.0 | 0.242 | 70 | 130 | 30 |

Notes:

Navy Policy has instructed the inclusion of all 14 PFAS analytes prescribed in USEPA Method 537 rev. 1.1 Modified. Not all of these analytes have available screening levels. These analytes have “NC” listed indicating, “No criteria.”

^a Accuracy and precision limits follow laboratory in-house limits per QSM v5.1 Table B-15.

^b Results for nonaqueous samples are reported on a dry-weight basis.

SAP Worksheet #16—Project Schedule/Timeline Table

| Activities | Organization | Dates (MM/DD/YY) | | Deliverable |
|------------------------------|---------------------|-----------------------------------|--------------------------------|--------------------------------------|
| | | Anticipated Date(s) of Initiation | Anticipated Date of Completion | |
| Draft SAP preparation | CH2M | August 2017 | September 2017 | Draft SAP |
| Navy SAP review | Navy | October 2017 | October 2017 | Comments |
| Final SAP | CH2M | November 2017 | November 2017 | Final SAP |
| Pre-sampling, subcontracting | CH2M | TBD | TBD | |
| Monitoring Well Installation | CH2M, Subcontractor | TBD | TBD | |
| Groundwater Sampling | CH2M | TBD | TBD | |
| Analytical Data | Subcontractor | 7-day turnaround time | | Analytical data |
| Data management | CH2M | TBD | TBD | |
| Reporting | CH2M | TBD | TBD | Draft and Final Technical Memorandum |

This page intentionally left blank.

SAP Worksheet #17—Sampling Design and Rationale

Groundwater will be sampled and analyzed during this SI. Table 17-1 presents the sampling strategy and rationale.

Table 17-1. Sampling Strategy Table

| Location | Matrix | Total Depth (ft btoc) | Screen Interval ('bgs) | Analysis | Laboratory Method | Number of Samples | Sampling Strategy | Rationale |
|---------------|--------|-----------------------|------------------------|----------|---|-------------------|--|---|
| WI-AF-N2-3 | GW | 123 | 112 – 122 | PFAS | USEPA Method 537 Modified / SOP 49 | 1 | Groundwater will be collected for in-field water quality parameters and laboratory analysis of PFAS from a sample port at the wellheads of the monitoring wells. | Groundwater from existing wells at Areas 2, 3, 4, 29, and the Current Fire Fighting School will be sampled for PFAS. These wells are located between potential upgradient sources and Residence 2 (Figure 7) and will be sampled to determine if potential source areas are contributing to groundwater plumes that are migrating outside the base boundary. |
| WI-AF-N2-6C | | 74 | 64 – 74 | | | 1 | | |
| WI-AF-N2-7S | | 20 | 8 – 18 | | | 1 | | |
| WI-AF-N2-8 | | 119 | 102 – 112 | | | 1 | | |
| WI-AF-N2-9 | | 99 | 88 – 98 | | | 1 | | |
| WI-AF-3-MW-2 | | 96 | 84 – 94 | | | 1 | | |
| WI-AF-N3-12 | | 60 | 48 – 58 | | | 1 | | |
| WI-AF-4-MW-3 | | 80 | 69 – 79 | | | 1 | | |
| WI-AF-29-MW-4 | | 66 | 52 – 62 | | | 1 | | |
| WI-AF-N29-22D | | 104 | N/A | | | 1 | | |
| WI-AF-MW3 | | 14 | 4 – 14 | | | 1 | | |
| WI-AF-MW-114 | | 20 | 8 – 18 | | | 1 | | |
| WI-AF-MW-200 | | N/A | N/A | | | 1 | | |
| WI-AF-MW-201 | | N/A | N/A | | | 1 | | |
| WI-AF-MW-202 | | N/A | N/A | | | 1 | | |
| WI-AF-N2-5 | | 35 | 7 – 17 | | | 1 | | |
| WI-AF-MW-204 | N/A | N/A | 1 | | | | | |
| WI-AF-MW-605 | GW | | | PFAS | USEPA Method 537 Modified / SOP 49 | 1 | Groundwater will be collected for in-field water quality parameters and laboratory analysis of PFAS from a sample port at the wellheads of the monitoring wells. | Proposed Wells 1 through 6 will assess PFAS concentrations downgradient from potential source areas and upgradient from Residence 1 (Figure 3 and 4). |
| WI-AF-MW-606 | | | | | | 1 | | |
| WI-AF-MW-607 | | | | | | 1 | | |
| WI-AF-MW-608 | | | | | | 1 | | |
| WI-AF-MW-609 | | | | | | 1 | | |
| WI-AF-MW-610 | | | | | | 1 | | |
| WI-AF-MW-611 | | | | | | 1 | | |
| WI-AF-MW-612 | | | | | | 1 | | |
| WI-AF-MW-613 | | | | | | 1 | | |
| WI-AF-MW-614 | | | | | | 1 | | |
| WI-AF-MW-615 | | | 1 | | | | | |
| WI-AF-MW-605 | Soil | TBD | N/A | PFAS | USEPA Method 537 rev. 1.1 Modified / SOP 49 | Up to 4 | Soil Samples will be collected for laboratory analysis of PFAS from the soil borings for each newly installed monitoring well. | Proposed Well locations 7, 8 and 9 will be sampled and gauged to determine if groundwater from potential source areas north and northwest of Residence 2 is contributing to the PFAS exceedances at Residence 2 domestic well (Figure 6). |
| WI-AF-MW-606 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-607 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-608 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-609 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-610 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-611 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-612 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-613 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-614 | | TBD | N/A | | | Up to 4 | | |
| WI-AF-MW-615 | TBD | N/A | Up to 4 | | | | | |

Notes:
 The final number and placement of samples may be modified in the field based on the field team's professional opinion in consultation with CH2M PM and the NAVFAC Northwest RPM.

GW = groundwater
 Ft bgs = ft below ground surface.
 PFAS= per- and polyfluoroalkyl substances
 N/A = Information is not available

This page intentionally left blank.

SAP Worksheet #18—Sampling Locations and Methods/SOP Requirements Table

| Sampling Location | Sample ID | Matrix | Depth (feet bgs) | Analytical Group | Number of Samples (identify field duplicates) | Sampling SOP Reference |
|-------------------|-------------------------|-------------|-----------------------|-------------------------|---|------------------------|
| WI-AF-N2-3 | WI-AF-N2-3-MMY | Groundwater | Middle of well screen | PFAS | 1 | Worksheet #21 |
| WI-AF-N2-6C | WI-AF-N2-6C-MMY | | | | 1 | |
| WI-AF-N2-7S | WI-AF-N2-7S-MMY | | | | 1 | |
| WI-AF-N2-8 | WI-AF-N2-8-MMY | | | | 2 (FD) | |
| | WI-AF-N2-8P-MMY | | | | | |
| WI-AF-N2-9 | WI-AF-N2-9-MMY | | | | 1 | |
| WI-AF-3-MW-2 | WI-AF-3-MW-2-MMY | | | | 1 | |
| | WI-AF-3-MW-2-MMY-MS | | | | | |
| | WI-AF-3-MW-2-MMY-MSD | | | | | |
| WI-AF-N3-12 | WI-AF-N3-12-MMY | | | | 1 | |
| WI-AF-4-MW-3 | WI-AF-4-MW-3-MMY | 1 | | | | |
| | WI-AF-29-MW-4-MMY | | | | | |
| WI-AF-29-MW-4 | WI-AF-29-MW-4-MMY | 1 | Worksheet #21 | | | |
| WI-AF-N29-22D | WI-AF-N29-22D-MMY | 1 | | | | |
| WI-AF-MW3 | WI-AF-MW3-MMY | 1 | | | | |
| WI-AF-MW-114 | WI-AF-MW-114-MMY | 1 | | | | |
| WI-AF-MW-200 | WI-AF-MW-200-MMY | 1 | | | | |
| WI-AF-MW-201 | WI-AF-MW-201-MMY | 2 (FD) | | | | |
| | WI-AF-MW-201P-MMY | | | | | |
| WI-AF-MW-202 | WI-AF-MW-202-MMY | 1 | | | | |
| WI-AF-N2-5 | WI-AF-N2-5-MMY | 1 | | | | |
| WI-AF-MW-204 | WI-AF-MW-204-MMY | 1 | | | | |
| WI-AF-MW-605 | WI-AF-MW-605-MMY | 1 | | | | |
| WI-AF-MW-606 | WI-AF-MW-606-MMY | 1 | | | | |
| WI-AF-MW-607 | WI-AF-MW-607-MMY | 1 | | | | |
| WI-AF-MW-608 | WI-AF-MW-608-MMY | 1 | | | | |
| WI-AF-MW-609 | WI-AF-MW-609-MMY | 1 | | | | |
| WI-AF-MW-610 | WI-AF-MW-610-MMY | 3 (MS/MSD) | | | | |
| | WI-AF-MW-610-MMY-MS | | | | | |
| | WI-AF-MW-610-MMY-MSD | | | | | |
| WI-AF-MW-611 | WI-AF-MW-611-MMY | 2 (FD) | | | | |
| WI-AF-MW-611 | WI-AF-MW-611P-MMY | | | | | |
| WI-AF-MW-612 | WI-AF-MW-612-MMY | 1 | Worksheet #21 | | | |
| WI-AF-MW-613 | WI-AF-MW-613-MMY | 1 | | | | |
| WI-AF-MW-614 | WI-AF-MW-614-MMY | 1 | | | | |
| WI-AF-MW-615 | WI-AF-MW-615-MMY | 1 | | | | |
| WI-AF-MW-605 | WI-AF-SB605-XXY-MMY | 4 | | | | |
| | WI-AF-SB605P-XXY-MMY | | | 1 (FD at one depth) | | |
| WI-AF-MW-606 | WI-AF-SB606-XXY-MMY | 4 | | | | |
| WI-AF-MW-607 | WI-AF-SB607-XXY-MMY | 4 | | | | |
| | WI-AF-SB607-XXY-MMY-MS | | | | | |
| | WI-AF-SB607-XXY-MMY-MSD | | | 2 (MS/MSD at one depth) | | |

SAP Worksheet #18—Sampling Locations and Methods/SOP Requirements Table (continued)

| Sampling Location | Sample ID | Matrix | Depth (feet bgs) | Analytical Group | Number of Samples (identify field duplicates) | Sampling SOP Reference | | | | |
|-------------------|---------------------------|--------|------------------|------------------|---|------------------------|----|------|---|---------------|
| WI-AF-MW-608 | WI-AF-SB608-XXYY-MMYY | | | | 4 | | | | | |
| | WI-AF-SB608P-XXYY-MMYY | | | | 1 (FD at one depth) | | | | | |
| WI-AF-MW-609 | WI-AF-SB609-XXYY-MMYY | | | | 4 | | | | | |
| | WI-AF-SB609P-XXYY-MMYY | | | | 1 (FD at one depth) | | | | | |
| WI-AF-MW-610 | WI-AF-SB610-XXYY-MMYY | Soil | TBD | PFAS | 4 | Worksheet #21 | | | | |
| | WI-AF-SB610-XXYY-MMYY-MS | | | | 2 (MS/MSD at one depth) | | | | | |
| | WI-AF-SB610-XXYY-MMYY-MSD | | | | | | | | | |
| WI-AF-MW-611 | WI-AF-SB611-XXYY-MMYY | | | | 4 | | | | | |
| WI-AF-MW-612 | WI-AF-SB612-XXYY-MMYY | | | | 4 | | | | | |
| | WI-AF-SB612P-XXYY-MMYY | | | | 1 (FD at one depth) | | | | | |
| WI-AF-MW-613 | WI-AF-SB613-XXYY-MMYY | | | | 4 | | | | | |
| WI-AF-MW-614 | WI-AF-SB614-XXYY-MMYY | | | | 4 | | | | | |
| | WI-AF-SB614P-XXYY-MMYY | | | | 1 (FD at one depth) | | | | | |
| WI-AF-MW-615 | WI-AF-SB615-XXYY-MMYY | | | | 4 | | | | | |
| | WI-AF-SB615-XXYY-MMYY-MS | | | | 2 (MS/MSD at one depth) | | | | | |
| | WI-AF-SB615-XXYY-MMYY-MSD | | | | | | | | | |
| Field QC | | | | | | | | | | |
| WI-AF-QC | WI-AF-FB01-MMDDYY | | | | QC | | NA | PFAS | 1 | Worksheet #21 |
| | WI-AF-EB01-MMDDYY | | | | | | | | 1 | |
| | WI-AF-FBXX-MMDDYY | TBD | | | | | | | | |
| | WI-AF-EBXX-MMDDYY | TBD | | | | | | | | |

Notes:
 FD = field duplicate

SAP Worksheet #19—Analytical SOP Requirements Table

| Matrix | Analytical Group | Analytical and Preparation Method/SOP Reference | Containers | Sample Volume | Preservation Requirements | Maximum Holding Time ^a (preparation/analysis) |
|-------------|------------------|---|--|---------------|---------------------------|--|
| Groundwater | PFAS | USEPA Method 537 rev. 1.1 Modified / SOP 49 | 2 x 125 milliliters (mL) polypropylene | 125 mL | Cool to ≤6 °C | 14 days/ 28 days |
| Soil | PFAS | USEPA 537 rev. 1.1 Modified / SOP 49 | 1 X 6 oz HDPE jar | 10 g | Cool to ≤6 °C | 28 days to extraction/ 30 days to analysis |

Notes:

^a Maximum holding time is calculated from the time the sample is collected to the time the sample is prepared/extracted.

mL = milliliter

This page intentionally left blank.

SAP Worksheet #20—Field Quality Control Sample Summary Table

| Matrix | Analytical Group | No. of Sampling Locations | No. of Field Duplicates | No. of MS/MSDs | No. of Equip. Blanks | No. of Field Reagent Blanks | No. of Trip Blanks | Total No. of Samples to Lab |
|-------------------|------------------|---------------------------|-------------------------|----------------|----------------------|-----------------------------|--------------------|-----------------------------|
| Ault Field | | | | | | | | |
| Groundwater | PFAS | Up to 28 | Up to 3 | 2/2 | Up to 5 | Up to 28 | - | Up to 68 |
| Soil | PFAS | Up to 44 | Up to 5 | Up to 3/3 | Up to 8 | Up to 8 | - | Up to 71 |

Samples will be collected as detailed in **Worksheets #14, #17, and #18** of this SAP. Field QA/QC samples will be collected as detailed in **Worksheet #12**.

This page intentionally left blank.

SAP Worksheet #21—Project Sampling SOP References Table

| Reference Number | Title, Revision Date and/or Number | Originating Organization of Sampling SOP | Equipment Type | Modified for Project Work? (Y/N) | Comments |
|------------------|---|--|--|----------------------------------|----------|
| SOP-001 | Chain-of-Custody, rev. 04/2015 | CH2M | Chain-of-custody form | No | |
| SOP-002 | Field Measurement of pH, Specific Conductance, Turbidity, DO, ORP, and Temperature Using a WQP Meter with Flow-through Cell, rev. 04/2015 | CH2M | Water Quality Meter with Flow-through Cell | No | |
| SOP-003 | Preparing Field Log Books, rev. 04/2015 | CH2M | Logbook and Indelible Pen | No | |
| SOP-004 | Utility Location, General, rev. 04/2015 | CH2M | | No | |
| SOP-005 | Equipment Blank and Field Blank Preparation, rev. 04/2015 | CH2M | Laboratory provided Blank Liquid and Sample Bottles | No | |
| SOP-006 | Decontamination of Personnel and Equipment, rev. 06/2015 | CH2M | For Cleansing Reusable Samplers | No | |
| SOP-007 | Disposal of Waste Fluids and Solids, rev. 03/2016 | CH2M | United States Department of Transportation 55-gallon Drums or Tank | No | |
| SOP-008 | Low-Flow Groundwater Sampling from Monitoring Wells, rev. 4/2015 | CH2M | Pump, Poly Tubing | No | |
| SOP-009 | Installation of Deep Monitoring Wells, rev. 04/2015 | CH2M | Drill Rig | No | |
| SOP-010 | Installation of Monitoring Wells, rev. 04/2015 | CH2M | Drill Rig | No | |
| SOP-011 | Installation of Shallow Monitoring Wells, rev. 04/2015 | CH2M | Drill Rig | No | |
| SOP-012 | Field Sampling Protocols to Avoid Cross-Contamination during Water Sampling for PFCs | Navy | | No | |
| SOP-013 | Water-Level Measurements | CH2M | Water Level Meter | No | |
| SOP-014 | Packaging and Shipping Procedures for Low-Concentration Samples, rev. 04/2015 | CH2M | Laboratory-supplied Coolers | No | |
| SOP-015 | Field Operation of the Geopump Peristaltic Pump by Geotech, rev. 03/2015 | Geotech | Geotech Peristaltic Pump | No | |
| SOP-016 | MultiRae Photoionization Detector (PID), rev. 04/2015 | CH2M | PID | No | |
| SOP-017 | Decontamination of Drilling Rigs and Equipment | CH2M | Drill Rig | No | |
| SOP-018 | Installation of Monitoring Wells by Sonic Drilling, rev. 04/2015 | CH2M | Sonic Drill Rig | No | |
| SOP-019 | Soil Sampling for Per- and Poly-fluoroalkyl Substances | CH2M | Sample Materials | No | |

This page intentionally left blank.

SAP Worksheet #22—Field Equipment Calibration, Maintenance, Testing, and Inspection Table

| Field Equipment | Activity ¹ | Frequency | Acceptance Criteria | CA | Resp. Person | SOP Reference ² | Comments |
|--|---|--|---|---|--------------|----------------------------|-------------------|
| Horiba U-22 pH probe | Calibration | Daily, before use | pH reads 4.0 +/- 3% | Clean probe with deionized water and calibrate again. Do not use instrument if not able to calibrate properly | FTL | SOP III-J | Appendix C |
| Horiba U-22 Specific conductance probe | Calibration | Daily, before use | Conductivity reads 4.49 +/- 3% | Clean probe with deionized water and calibrate again. Do not use instrument if not able to calibrate properly. | FTL | SOP III-J | Appendix C |
| Horiba U-22 Turbidity probe | Calibration | Daily, before use | Turbidity reads 0 +/- 3% | Clean probe with deionized water and calibrate again. Do not use instrument if not able to calibrate properly. | FTL | SOP III-J | Appendix C |
| Horiba U-22 DO and Temperature Probes | Testing | Daily, before use | Consistent with the current atmospheric pressure and ambient temperature | Clean probe with deionized water and calibrate again. Do not use instrument if not able to calibrate properly. | FTL | SOP III-J | Appendix C |
| Horiba U-22 | Maintenance- Check mechanical and electronic parts, verify system continuity, check battery, and clean probes. Calibration check | Daily before use, at the end of the day, and when unstable readings occur. | Stable readings after 3 minutes. pH reads 4.0 +/- 3% conductivity reads 4.49 +/- 3% turbidity reads 0 +/- 3% | Clean probe with deionized water and calibrate again. Do not use instrument if not able to calibrate properly. | FTL | SOP III-J | Appendix C |
| Transducers and data loggers | Calibrate | Daily, As Needed | Parameter specific per model/ instruction manual | Manufacturer technical support for calibration errors | FTL | SOP CH2M-2, SOP-III-J | Appendix C |
| Multi RAE PID | Calibrate using ambient air and isobutylene 100 parts per million calibration gas | Daily and as Needed | Parameter specific per model/ instruction manual | Manufacturer technical support for calibration errors | FTL | SOP CH2M-3, SOP-III-J | Appendix C |
| Groundwater sampling pumps and tubing | Inspect pumps, tubing and air/sample line quick-connects | Regularly | Maintained in good working order according to manufacturer's recommendations | Replace items | FTL | SOP-III-J | Appendix C |

Notes:

¹ Activities may include: calibration, verification, testing, and maintenance.

² Specify the appropriate reference letter or number from the Project Sampling SOP References table (**Worksheet #21**).

This page intentionally left blank.

SAP Worksheet #23—Analytical SOP References Table

| Lab SOP Number | Title, Revision Date, and/or Number | Date Reviewed if not Revised | Definitive or Screening Data | Matrix and Analytical Group | Instrument | Organization Performing Analysis | Variance to QSM | Modified for Project Work (Y/N) |
|----------------|--|------------------------------|------------------------------|-----------------------------|------------|----------------------------------|-----------------|---------------------------------|
| 12 | <i>Sample Receiving and Sample Control Procedures; rev. 12; 11/08/16</i> | | N/A | Groundwater/Soil/PFAS | N/A | Vista Analytical | N | N |
| 14 | <i>Bottle Order Preparation; rev. 4; 9/03/14</i> | | N/A | Groundwater/Soil/PFAS | N/A | Vista Analytical | N | N |
| 49 | Preparation and Analysis for the Determination of Per and Poly-Fluorinated Compounds; Rev. 10; 6/14/17 | | Definitive | Groundwater/Soil/PFAS | UPLC/MS/MS | Vista Analytical | N | N |

Notes:

- ^a Non-analytical SOPs do not require an annual review cycle.
- ^b Vista Analytical’s Department of Defense (DoD) Environmental Laboratory Accreditation Program (ELAP) accreditation through A2LA is granted through September 30, 2019.

UPLC/MS/MS = ultra performance liquid chromatography – tandem mass spectrometer

This page intentionally left blank.

SAP Worksheet #24—Analytical Instrument Calibration Table

| Instrument | Calibration Procedure | Frequency of Calibration | Acceptance Criteria | CA | Person Responsible for CA | SOP Reference |
|--|--------------------------------|---|---|---|---------------------------|--------------------------------------|
| UPLC/MS/MS (PFASs, modified EPA 537) | ICAL for all analytes | At instrument set-up and after ICV or CCV failure, prior to sample analysis. | <p>The available isotopically labeled analog of an analyte (Extracted Internal Standard Analyte) are used for quantitation (except labelled 6:2 FTS)</p> <p>If a labeled analog is not commercially available, the Extracted Internal Standard Analyte with the closest retention time to the analyte must be used for quantitation. (Internal Standard Quantitation)</p> <p>S/N Ratio: $\geq 10:1$ for all ions used for quantitation.</p> <p>For analytes having a promulgated standard, (e.g., HA levels for PFOA and PFOS), the qualitative (confirmation) transition ion must have a S/N Ratio of $\geq 3:1$.</p> <p>The %RSD of the RFs for all analytes must be $<20\%$. Linear or non-linear calibrations must have $r^2 \geq 0.99$ for each analyte. Analytes must be within 70-130% of their true value for each calibration standard.</p> | Correct problem, then repeat ICAL. | Analyst / Supervisor | SOP 49 DoD QSM v5.1 Table B-15 |
| | ICV | Once after each ICAL, analysis of a second source standard prior to sample analysis. | All reported analytes within $\pm 30\%$ of true value. | Correct problem and verify second source standard. Rerun ICV. If that fails, correct problem and repeat ICAL. | | |
| | CCV | Analysis of mid-level standard after every 10 field samples. All samples must be bracketed by the analysis of a standard. | <p>Concentration of analytes must range from the LOQ to the mid-level calibration concentration.</p> <p>Analyte concentrations must be within $\pm 30\%$ of their true value.</p> | <p>Immediately analyze two additional consecutive CCVs. If both pass, samples may be reported without reanalysis. If either fails, or if two consecutive CCVs cannot be run, perform corrective action(s) and repeat CCV and all associated samples since last successful CCV.</p> <p>Alternatively, recalibrate if necessary; then reanalyze all associated samples since the last acceptable CCV.</p> | | |
| | Tune Check | When the masses fall outside of the ± 0.5 amu of the true value (as determined by the product ion formulas). | Mass assignments of tuning standard within 0.5 amu of true value. | Retune instrument and verify. If the tuning will not meet acceptance criteria, an instrument mass calibration must be performed and the tune check repeated. | | |
| | Mass Calibration | Initially prior to use and after performing major maintenance, as required to maintain documented instrument sensitivity and stability performance. | Calibrate the mass scale of the MS with calibration compounds and procedures described by the manufacturer. Entire range needs to be mass calibrated. | NA | | |
| | Mass Spectral Acquisition Rate | Each analyte and extracted internal standard analyte. | A minimum of 10 spectra scans are acquired across each chromatographic peak. | NA | | |

SAP Worksheet #24—Analytical Instrument Calibration Table (continued)

| Instrument | Calibration Procedure | Frequency of Calibration | Acceptance Criteria | CA | Person Responsible for CA | SOP Reference |
|--|---|---|--|---|---------------------------|--------------------------------------|
| UPLC/MS/MS (PFASs, modified EPA 537) | Calibration, Calibration Verification, and Spiking Standards | All analytes. | Standards containing both branched and linear isomers must be used when commercially available. If not available, the total response of the analyte must be integrated (i.e., accounting for peaks that are identified as linear and branched isomers) and quantitated using a calibration curve which includes the linear isomer only for that analyte (e.g., PFOA). | NA | Analyst / Supervisor | SOP 49 DoD QSM v5.1 Table B-15 |
| | Ion Transitions (Parent-> Product) | Prior to method implementation. | The chemical derivation of the ion transitions, both those used for quantitation and those used for confirmation, must be documented. Two transitions and the ion transition ratio per analyte shall be monitored and documented with the exception of PFBA and PFPeA. In order to avoid biasing results high due to known interferences for some transitions, the following transitions must be used for the quantification of the following analytes: PFOA: 413 → 369 PFOS: 499 → 80 PFHxS: 399 → 80 PFBS: 299 → 80 4:2 FTS: 327 → 307 6:2 FTS: 427 → 407 8:2 FTS: 527 → 507 NEtFOSAA: 584 → 419 NMeFOSAA: 570 → 419 If these transitions are not used, the reason must be technically justified and documented (e.g., alternate transition was used due to observed interferences). | NA | | |
| | Instrument Sensitivity Check (ISC) | Prior to analysis and at least once every 12 hours. | Analyte concentrations must be at LOQ; concentrations must be within ±30% of their true values. | Correct problem, rerun. ISC. If problem persists, repeat ICAL. No samples shall be analyzed until ISC has met acceptance criteria. ISC can serve as the initial daily CCV. | | |

Notes:

UPLC = ultra performance liquid chromatograph

MS/MS is the combination of two mass analyzers in one mass spectrometer instrument.

DoD QSM v.5.1 is the basis for specifications on this table.

SAP Worksheet #25—Analytical Instrument and Equipment Maintenance, Testing, and Inspection Table

| Instrument/ Equipment | Maintenance Activity | Testing Activity | Inspection Activity | Frequency | Acceptance Criteria | CA | Responsible Person | SOP Reference |
|--------------------------|--|---------------------|---------------------------------|---|--|---|------------------------------|------------------|
| UPLC/MS/MS | Clean sample and gas cones. Change the column. Clean the T-Wave. | USEPA 537 Mod | Check the sample and gas cones. | T-Wave cleaning is performed when the instrument response deteriorates. Other instrument maintenance is done as needed to keep the instrument performing at peak performance. | ICAL within acceptance criteria on WS#24 and IS recovery within acceptance criteria on WS#28 | Recalibrate and/or perform the necessary equipment maintenance. Check the calibration standards. Reanalyze the affected data. | Vista Analyst/ Supervisor | SOP 49 |

This page intentionally left blank.

SAP Worksheet #26—Sample Handling System

| |
|--|
| SAMPLE COLLECTION, PACKAGING, AND SHIPMENT |
| Sample Collection (Personnel/Organization): Project Field Team, FTL/CH2M. Field SOPs are in Appendix A of this SAP. |
| Sample Packaging (Personnel/Organization): Project Field Team, FTL/CH2M. Field SOPs are in Appendix A of this SAP. |
| Coordination of Shipment (Personnel/Organization): FTL/CH2M. |
| Type of Shipment/Carrier: FedEx Priority Overnight |
| SAMPLE RECEIPT AND ANALYSIS |
| Sample Receipt (Personnel/Organization): Sample Receiving –Vista Analytical, El Dorado Hills, California |
| Sample Custody and Storage (Personnel/Organization): Sample Receiving –Vista Analytical, El Dorado Hills, California |
| Sample Preparation (Personnel/Organization): Vista Analytical, El Dorado Hills, California |
| Sample Determinative Analysis (Personnel/Organization): Vista Analytical, El Dorado Hills, California |
| SAMPLE ARCHIVING |
| Field Sample Storage (No. of days from sample collection): 45 days |
| Sample Extract/Digestate Storage (No. of days from extraction/digestion): 90 days |
| Biological Sample Storage (No. of days from sample collection): N/A |
| SAMPLE DISPOSAL |
| Personnel/Organization): Sample Disposal – Vista Analytical, El Dorado Hills, California |
| Number of Days from Analysis: 45 days |

This page intentionally left blank.

SAP Worksheet #27—Sample Custody Requirements Table

Field Sample Custody Procedures (sample collection, packaging, shipment, and delivery to laboratory):

Samples will be collected by field team members under the supervision of the FTL. As samples are collected, they will be placed into containers and labeled. Labels will be taped to the jar to ensure they do not separate. Samples will be cushioned with packaging material and placed into coolers containing enough ice to keep the samples cooler than 6°C (but not frozen) until they are received by the laboratory.

The chain-of-custody record will be placed into the cooler in a resealable zip-top plastic bag. Coolers will be taped up and shipped to the laboratories via FedEx overnight, with the airbill number indicated on the chain of custody (to relinquish custody). Upon delivery, the laboratory will log each cooler and report the status of the samples to CH2M.

See **Worksheet #21** for SOPs containing sample custody guidance.

The CH2M field team will ship all environmental samples directly to the laboratory performing the analysis. This will require shipment to Vista Analytical in El Dorado Hills, California.

Laboratory Sample Custody Procedures (receipt of samples, archiving, disposal):

Laboratory custody procedures can be found in the laboratory SOPs, which will be provided upon request.

Sample Identification (ID) Procedures:

Sample labels will include, at a minimum, client name, site, sample ID, date/time collected, analysis group or method, preservation, and sampler's initials. The field logbook will identify the sample ID with the location and time collected and the parameters requested. The laboratory will assign each field sample a laboratory sample ID based on information in the chain of custody. The laboratory will send sample log-in forms to the CH2M PC to check that sample IDs and parameters are correct.

Chain-of-Custody Procedures:

Chain-of-custody records will include, at minimum, laboratory contact information, client contact information, sample information, and relinquished by/received by information. Sample information will include sample ID, Date/time collected, number and type of containers, preservative information, analysis method, and comments. The chain-of-custody record will link location of the sample from the field logbook to the laboratory receipt of the sample. The laboratory will use the sample information to populate the Laboratory Information Management Systems database for each sample.

This page intentionally left blank.

SAP Worksheet #28—Laboratory QC Samples Table

Matrix: Groundwater/Soil

Analytical Group: PFAS

Analytical Method/SOP Reference: USEPA Method 537 Modified/SOP 49

| QC Sample | Frequency/Number | Method/ SOP QC Acceptance Limits | CA | Person(s) Responsible for CA | DQI | Measurement Performance Criteria (MPC) |
|-------------------------|--|---|---|------------------------------|-------------------------|--|
| Method Blank | One per prep batch of 20 or fewer samples of similar matrix; or one per day, whichever comes first | No analytes detected > 1/2 LOQ or >1/10 sample concentration or >1/10 regulatory limit, whichever is greater. For common laboratory contaminants, no analytes detected >LOQ. | Correct problem. Reprep and reanalyze method blank and all samples processed with the contaminated blank. If reanalysis cannot be performed, the data must be qualified and explained in the case narrative. | Analyst/ Supervisor | Bias/Contamination | Same as Method/ SOP QC Acceptance Limits |
| LCS | One per prep batch of 20 or fewer samples of similar matrix; or one per day, whichever comes first | See Worksheet #15 | Correct problem. Reprep and reanalyze the LCS and all samples in the associated preparatory batch, if sufficient sample material is available. If reanalysis cannot be performed, the data must be qualified and explained in the case narrative. | | Accuracy/Bias/Precision | |
| MS/MSD | One per prep batch of 20 or fewer samples of similar matrix; or one per day, whichever comes first | See Worksheet #15 . Sample spiked with all analytes at a concentration \geq LOQ and \leq the mid-level calibration concentration. | Examine the project specific requirements. Contact the client as to additional measures to be taken. For the specific analyte(s) in the parent sample, apply J-flag if acceptance criteria are not met and explain in the Case Narrative. RPD \leq 30% | | Precision/Accuracy/Bias | |
| Internal Standards (IS) | Every sample, spiked sample, standard, and method blank | Added to sample prior to extraction. For aqueous samples prepared by serial dilution instead of SPE, added to samples prior to analysis. Extracted Internal Standard Analyte recoveries must be within 50% to 150% of the true value. | If recoveries are acceptable for QC samples, but not field samples, the field samples must be reprep and reanalyzed (greater dilution may be needed). | | Accuracy | |
| Instrument Blanks | Immediately following the highest standard analyzed and daily prior to sample analysis. | Concentration of each analyte must be \leq 1/2 the LOQ. | If acceptance criteria are not met after the highest calibration standard, calibration must be performed using a lower concentration for the highest standard until acceptance criteria is met. If acceptance criteria are not met after the highest standard which is not included in the calibration, the standard cannot be used to determine the highest concentration in samples at which carryover does not occur. If acceptance criteria are not met after sample, additional instrument blanks must be analyzed until acceptance criteria are met. Additional samples shall not be analyzed until acceptance criteria are met. | | Bias/Contamination | |

This page intentionally left blank.

SAP Worksheet #29—Project Documents and Records Table

| Document | Where Maintained |
|---|--|
| <ul style="list-style-type: none"> • Field Notebooks • Chain-of-Custody Records • Air Bills • Custody Seals • CA Forms • Electronic Data Deliverables (EDDs) • ID of QC Samples • Meteorological Data from Field • Sampling instrument calibration logs • Sampling locations and sampling plan • Sampling notes and drilling logs • WQPs • Sample Receipt, Chain of Custody, and Tracking Records • Standard Traceability Logs • Equipment Calibration Logs • Sample Preparation Logs • Run Logs • Equipment Maintenance, Testing, and Inspection Logs • CA Forms • Reported Field Sample Results • Reported Result for Standards, QC Checks, and QC Samples • Instrument printouts (raw data) for Field Samples, Standards, QC Checks, and QC Samples • Data Package Completeness Checklists • Sample disposal records • Extraction/Clean-up Records • Raw Data (archived per Navy CLEAN contract) • DV Reports • CA Forms • Laboratory QA Plan • Method Detection Limit (MDL) Study Information | <ul style="list-style-type: none"> • Field data deliverables such as logbooks entries, chains of custody, airbills, EDDs, and so forth, will be kept on CH2M’s network server. • Field parameter data will be loaded with the analytical data into the Navy database • Analytical laboratory hardcopy deliverables and DV reports will be saved on the network server and archived per the Navy CLEAN contract. • Electronic data from the laboratory will be loaded into Navy database • Following project completion, hardcopy deliverables such as logbooks, chain of custodies, and so forth will be archived at Iron Mountain: Iron Mountain Headquarters 745 Atlantic Avenue Boston, Massachusetts 02111 (800) 899-IRON • Following project completion, hardcopy deliverables including chain of custodies and raw data will be archived at the Washington National Records Center: Washington National Records Center 4205 Suitland Road Suitland, Maryland 20746-8001 (301) 778-1550 |

This page intentionally left blank.

SAP Worksheet #30—Analytical Services Table

| Matrix | Analytical Group | Sample Locations/ID | Analytical Method | Data Package Turnaround Time | Laboratory/Organization | Backup Laboratory/Organization^a |
|------------------|-------------------------|---|---------------------------|-------------------------------------|--------------------------------|---|
| Groundwater/Soil | PFAS | Refer to Worksheets #18 and #20 | USEPA Method 537 Modified | 10 calendar days | Vista Analytical | TBD |

Notes:

^a backup lab will be determined if necessary.

This page intentionally left blank.

SAP Worksheet #31—Planned Project Assessments Table

| Assessment Type | Frequency | Internal or External | Organization Performing Assessment | Person(s) Responsible for Performing Assessment (title and organizational affiliation) | Person(s) Responsible for Responding to Assessment Findings (title and organizational affiliation) | Person(s) Responsible for Identifying and Implementing CA (title and organizational affiliation) | Person(s) Responsible for Monitoring Effectiveness of CA (title and organizational affiliation) |
|-------------------------|--|-----------------------------|---|---|---|---|--|
| Field Performance Audit | One during first quarter sampling event | Internal | CH2M | PM/CH2M | FTL/CH2M | PM/CH2M | PM/CH2M |
| Safe Work Observation | One during each quarterly sampling event | Internal | CH2M | SSC/CH2M | Field Team Member observed/CH2M | HSM/CH2M | SSC/CH2M |
| Field Document Review | Daily during each quarterly sampling event | Internal | CH2M | PM or TM/CH2M | FTL/CH2M | PM/CH2M | PM/CH2M |

This page intentionally left blank.

SAP Worksheet #32—Assessment Findings and Corrective Action Responses

| Assessment Type | Nature of Deficiencies Documentation | Individual(s) Notified of Findings (name, title, organization) | Timeframe of Notification | Nature of CA Response Documentation | Individual(s) Receiving CA Response (name, title, organization) | Timeframe for Response |
|---------------------------------|---|---|----------------------------------|--|--|------------------------------------|
| Field Performance Audit | Checklist and Written Audit Report | FTL/CH2M | Within 1 day of audit | Verbal and Memorandum | FTL/CH2M | Within 1 day of receipt of CA Form |
| Safe Behavior Observation (SBO) | SBO Form | HSM/CH2M | Within 1 week of SBO | Memorandum | Field Team Member/CH2M | Immediately |
| Field Document Review | Markup copy of field documentation | FTL/CH2M | Within 1 day of review | Verbal and Memorandum | FTL/CH2M | Within 1 day of receipt of markup |

This page intentionally left blank.

SAP Worksheet #32-1—Laboratory Corrective Action Form

Person initiating CA: _____ Date: _____

Description of problem and when identified:

Cause of problem, if known or suspected:

Sequence of CA: (including date implemented, action planned and personnel/data affected)

CA implemented by: _____ Date: _____

CA initially approved by: _____ Date: _____

Follow-up date: _____

Final CA approved by: _____ Date: _____

Information copies to:

This page intentionally left blank.

SAP Worksheet #32-2—Field Performance Audit Checklist

Project Responsibilities

Project No.: _____ Date: _____
Project Location: _____ Signature: _____

Team Members

- | | | |
|-----|----|---|
| Yes | No | 1) Is the approved work plan being followed? Comments _____ _____ |
| Yes | No | 2) Was a briefing held for project participants? Comments _____ _____ |
| Yes | No | 3) Were additional instructions given to project participants? Comments _____ _____ |

Sample Collection

- | | | |
|-----|----|---|
| Yes | No | 1) Is there a written list of sampling locations and descriptions? Comments _____ _____ |
| Yes | No | 2) Are samples collected as stated in the Master SOPs? Comments _____ _____ |
| Yes | No | 3) Are samples collected in the type of containers specified in the work plan? Comments _____ _____ |
| Yes | No | 4) Are samples preserved as specified in the work plan? Comments _____ _____ |
| Yes | No | 5) Are the number, frequency, and type of samples collected as specified in the work plan? Comments _____ _____ |

Worksheet #32-2—Field Performance Audit Checklist (continued)

Yes No 6) Are QA checks performed as specified in the work plan??
Comments _____

Yes No 7) Are photographs taken and documented?
Comments _____

Document Control

Yes No 1) Have any accountable documents been lost?
Comments _____

Yes No 2) Have any accountable documents been voided?
Comments _____

Yes No 3) Have any accountable documents been disposed of?
Comments _____

Yes No 4) Are the samples identified with sample tags?
Comments _____

Yes No 5) Are blank and duplicate samples properly identified?
Comments _____

Yes No 6) Are samples listed on a chain-of-custody record?
Comments _____

Yes No 7) Is chain of custody documented and maintained?
Comments _____

SAP Worksheet #32-3—Safe Behavior Observation Form

| <input type="checkbox"/> Federal or <input type="checkbox"/> Commercial Sector (check one) | | <input type="checkbox"/> Construction or <input type="checkbox"/> Consulting (check one) | |
|---|------|--|---|
| Project Number: | | Client/Program: | |
| Project Name: | | Observer: | Date: |
| Position/Title of worker observed: | | Background Information/ comments: | |
| Task/Observation Observed: | | | |
| <ul style="list-style-type: none"> ❖ Identify and reinforce safe work practices/behaviors ❖ Identify and improve on at-risk practices/acts ❖ Identify and improve on practices, conditions, controls, and compliance that eliminate or reduce hazards ❖ Proactive PM support facilitates eliminating/reducing hazards (do you have what you need?) ❖ Positive, corrective, cooperative, collaborative feedback/recommendations | | | |
| Actions & Behaviors | Safe | At-Risk | Observations/Comments |
| Current and accurate Pre-Task Planning/Briefing (for example, Project Safety Plan, safety training and consulting, activity hazard analyses, Pre-task Safety Plan, tailgate briefing, as needed) | | | Positive Observations/Safe Work Practices: |
| Properly trained/qualified/experienced | | | |
| Tools/equipment available and adequate | | | |
| Proper use of tools | | | Questionable Activity/Unsafe Condition Observed: |
| Barricades/work zone control | | | |
| Housekeeping | | | |
| Communication | | | |
| Work Approach/Habits | | | |
| Attitude | | | |
| Focus/attentiveness | | | Observer's CAs/Comments: |
| Pace | | | |
| Uncomfortable/unsafe position | | | |
| Inconvenient/unsafe location | | | |
| Position/Line of fire | | | Observed Worker's CAs/Comments: |
| Apparel (hair, loose clothing, jewelry) | | | |
| Repetitive motion | | | |
| Other | | | |

This page intentionally left blank.

SAP Worksheet #33—QA Management Reports Table

| Type of Report | Frequency (daily, weekly monthly, quarterly, annually, and so forth) | Projected Delivery Date(s) | Person(s) Responsible for Report Preparation (title and organizational affiliation) | Report Recipient(s) (title and organizational affiliation) |
|-----------------------|---|-----------------------------------|--|---|
| Field Audit Report | One during sampling event | Submitted with final report | PM/CH2M | Included in project files. |

This page intentionally left blank.

SAP Worksheet #34-36—Data Verification and Validation (Steps I and IIa/IIb) Process Table

| Data Review Input | Description ^c | Responsible for Verification or Validation | Step I/IIa/IIb ^a | Internal/External ^b |
|---|--|--|-----------------------------|--------------------------------|
| Field Notebooks | Field notebooks will be reviewed internally and placed into the project file for archival at project closeout. | FTL/CH2M | Step I | Internal |
| Chains of Custody and Shipping Forms | Chain of custody forms and shipping documentation will be reviewed internally upon their completion and verified against the packed sample coolers they represent. The shipper's signature on the chain of custody forms will be initialed by the reviewer, a copy of the chains of custody forms retained in the site file, and the original and remaining copies taped inside the cooler for shipment. Chain of custody forms will also be reviewed for adherence to the SAP by the PC. | FTL/CH2M PC/CH2M | Step I | Internal & External |
| Sample Condition upon Receipt | Any discrepancies, missing, or broken containers will be communicated to the PC in the form of laboratory logins. | PC/CH2M | Step I | External |
| Documentation of Laboratory Method Deviations | Laboratory Method Deviations will be discussed and approved by the PC. Documentation will be incorporated into the case narrative, which becomes part of the final hard copy data package. | PC/CH2M | Step I | External |
| EDDs | EDDs will be compared against hard copy laboratory results (10 percent check). | PC/CH2M | Step I | External |
| Case Narrative | Case narratives will be reviewed by the data validator during the DV process. This is verification that they were generated and applicable to the data packages. | Data Validator | Step I | External |
| Laboratory Data | All laboratory data packages will be verified internally by the laboratory performing the work for completeness and technical accuracy prior to submittal. | Laboratory QAO | Step I | Internal |
| Laboratory Data | The data will be verified for completeness by the PC. To ensure completeness, EDDs will be compared to the SAP. This is a verification that all samples were included in the laboratory data and that correct analyte lists were reported. | PC/CH2M | Step I | External |
| Audit Reports | Upon report completion, a copy of all audit reports will be placed in the site file. If CAs are required, a copy of the documented CA taken will be attached to the appropriate audit report in the QA site file. Periodically, and at the completion of site work, site file audit reports and CA forms will be reviewed internally to ensure that all appropriate CAs have been taken and that CA reports are attached. If CAs have not been taken, the site manager will be notified to ensure action is taken. | PM/CH2M PC/CH2M | Step I | Internal |
| CA Reports | CA reports will be reviewed by the PC or PM and placed into the project file for archival at project closeout. | PM/CH2M PC/CH2M | Step I | External |
| Laboratory Methods | During the pre-validation check, ensure that the laboratory analyzed samples using the correct methods specified in the SAP. If methods other than those specified in the SAP were used, the reason will be determined and documented. | PC/CH2M | Step IIa | External |
| Target Compound List and Target Analyte list | During the pre-validation check, ensure that the laboratory reported all analytes from each analysis group as per Worksheet #15 . If the target compound list is not correct, then it must be corrected prior to sending the data for validation. Once the checks are complete, the project manager is notified via email | PC/CH2M | Step IIa | External |
| Laboratory Limits (DL/LOD/LOQ) | During the pre-validation check, the laboratory limits (DL/LOD/LOQ) will be compared to those listed in the project SAP. If limits were not met, the laboratory will be contacted and asked to provide an explanation, which will then be discussed in the associated project report. Often times the cause for minor laboratory limit deviation from those presented in the SAP is due to the quarterly update of laboratory LOD. | PC/CH2M | Step IIb | External |
| Laboratory SOPs | Ensure that approved analytical laboratory SOPs were followed. Any such discrepancies will be discussed first in the data validation narrative and will be included in the associated project report. | Laboratory QAO | Step IIa | Internal |
| Sample Chronology | Holding times from collection to extraction or analysis and from extraction to analysis will be considered during the DV process. | Data Validator | Step IIa and IIb | External |
| Raw Data | Ten percent review of raw data to confirm laboratory calculations. For a recalculated result, the data validator attempts to re-create the reported numerical value. The laboratory is asked for clarification if a discrepancy is identified, which cannot reasonably be attributed to rounding. In general, this is outside 5 percent difference. | Data Validator | Step IIa | External |
| Onsite Screening | All non-analytical field data will be reviewed against SAP requirements for completeness and accuracy based on the field calibration records. | FTL/CH2M | Step IIb | Internal |

SAP Worksheet #34-36—Data Verification and Validation (Steps I and IIa/IIb) Process Table (continued)

| Data Review Input | Description ^c | Responsible for Verification or Validation | Step I/IIa/IIb ^a | Internal/External ^b |
|---|---|--|-----------------------------|--------------------------------|
| Documentation of Method QC Results | Establish that all required QC samples were run and met limits. | Data Validator | Step IIa | External |
| Documentation of Field QC Sample Results | Establish that all required QC samples were run and met limits, and will be discussed in the associated project report. | PC/CH2M | Step IIa | Internal |
| DoD ELAP Evaluation | Ensure that each laboratory is DoD ELAP certified for the analyses they are to perform. Ensure evaluation timeframe does not expire. | PC/CH2M | Step I | External |
| Analytical data for PFAS analyzed for in groundwater ^d | Analytical methods and laboratory SOPs as presented in this SAP will be used to evaluate compliance against QA/QC criteria. Should adherence to QA/QC criteria yield deficiencies, data may be qualified. The data qualifiers used are those presented in National Functional Guidelines for Superfund Organic Data Review (USEPA, 2017) may be used for DV, and the specific qualifiers listed therein may be applied to data should non-conformances against the QA/QC criteria as presented in this SAP be identified. | Data Validator | Step IIa and IIb | External |

Notes:

- ^a Verification (Step I) is a completeness check that is performed before the data review process continues to determine whether the required information (complete data package) is available for further review. Validation (Step IIa) is a review that the data generated is in compliance with analytical methods, procedures, and contracts. Validation (Step IIb) is a comparison of generated data against measurement performance criteria in the SAP (both sampling and analytical).
- ^b Internal or external is in relation to the data generator.
- ^c Should CH2M find discrepancies during the verification or validation procedures above, an email documenting the issue will be circulated to the internal project team, and a Corrections to File Memo will be prepared identifying the issues and the corrective action needed. This memo will be sent to the laboratory, or applicable party, and maintained in the project file.
- ^d Stage 4 data validation will be performed on 10% of all definitive analyses which will include recalculated results from the raw data to verify calculations. The remaining 90% of the definitive data will receive Stage 2B data validation.

SAP Worksheet #37—Usability Assessment

Summarize the usability assessment process and all procedures, including interim steps and any statistics, equations, and computer algorithms that will be used:

- Non-detected site contaminants will be evaluated to ensure that project required QLs in **Worksheet #15** were achieved. If PQLs were achieved and the verification and validation steps yielded acceptable data, then the data are considered usable.
- During verification and validation steps, data may be qualified as estimated with the following qualifiers: J or UJ. The qualifiers represent minor QC deficiencies, which will not affect the usability of the data. When major QC deficiencies are encountered, data will be qualified with an R and in most cases is not considered usable for project decisions.
 - J = Analyte present. Reported value may or may not be accurate or precise.
 - J+ = Analyte present. Reported value is estimated and may be biased high.
 - J- = Analyte present. Reported value is estimated and may be biased low.
 - UJ = Analyte not detected. Associated non-detect value may be inaccurate or imprecise.
 - R = Rejected result. Result not reliable.
- The following additional qualifiers may be given by the validator:
 - N = Tentative ID. Consider Present. Special methods may be needed to confirm its presence or absence in future sampling efforts.
 - NJ = Qualitative ID questionable due to poor resolution. Presumptively present at approximate quantity.
 - U = Not Detected.
- Analytical data will be checked to ensure the values and any qualifiers are appropriately transferred to the electronic database. The checks include comparison of hardcopy data and qualifiers to the EDD. Once the data have been uploaded into the electronic database, another check will be performed to ensure all results were loaded accurately.
- Field and laboratory precision will be compared as RPD between the two results.
- Deviations from the SAP will be reviewed to assess whether CA is warranted and to assess impacts to achievement of project objectives.

Describe the evaluative procedures used to assess overall measurement error associated with the project.

- To assess whether a sufficient quantity of acceptable data is available for decision making, the data will be compared to the 95 percent completeness goal and reconciled with MPC following validation and review of DQI.
- If significant biases are detected with laboratory QA/QC samples, they will be evaluated to assess impact on decision making. Low biases will be described in greater detail as they represent a possible inability to detect compounds that may be present at the site.
- If significant deviations are noted between laboratory and field precision, the cause will be further evaluated to assess impact on decision making.

SAP Worksheet #37—Usability Assessment (continued)

Describe the documentation that will be generated during the usability assessment and how usability assessment results will be presented so that they identify trends, relationships (correlations), and anomalies:

The following will be prepared by CH2M and presented to and submitted to the Navy and NAS Whidbey Island, Oak Harbor for review and decisions on the path forward for the site:

- Data tables will be produced to reflect detected and non-detected site analytes. Data qualifiers will be reflected in the tables and discussed in the data quality evaluation, and will be provided in a technical memorandum.

Identify the personnel responsible for performing the usability assessment.

The CH2M team, including the PM and PC, will review the data and present to the Navy and NAS Whidbey Island, Oak Harbor for review and approval of usability.

References

CH2M HILL, Inc. (CH2M). 2016. *Technical Memorandum – Results of Desktop Evaluation to Verify Off-Base Drinking Water Sources*. September.

CH2M. 2017b. *Final Sampling and Analysis Plan Investigation of Per- and Polyfluoroalkyl Substances in Drinking Water Ault Field and Outlying Landing Field Coupeville, Naval Air Station Whidbey Island, Oak Harbor and Coupeville, Washington*. August.

“Installation Information.” CNIC – Naval Air Station Whidbey Island, 2017.
https://cnic.navy.mil/regions/cnrnw/installations/nas_whidbey_island.html

Sapik, D.B., G.C. Bortleson, B.W. Drost, M.A. Jones, and E.A. Drych. 1988. “Groundwater Resources and Simulation of Flow in Aquifers Containing Fresh Water and Sea Water, Island County, Washington.” *U.S. Geological Survey Water Resources Investigations Report 87-4182*. p. 67.

U.S. Environmental Protection Agency (USEPA). 1998. *Guidance for Quality Assurance Project Plans*.

USEPA. 2005. *Uniform Federal Policy for Quality Assurance Project Plans: Evaluating, Assessing, and Documenting Environmental Data Collection and Use Programs - Part 1: UFP-QAPP Manual*. Intergovernmental Data Quality Task Force. EPA-505-B-04-900A. Final Version 1. March.

USEPA. 2006. *Guidance on Systematic Planning Using the Data Quality Objectives Process*. EPA QA/G-4. EPA/240/B-06/001. February.

Navy. 1993. *Final Remedial Investigation Report for Operable Unit 2, Naval Air Station Whidbey Island. Prepared for Engineering Field Activity Northwest, Naval Facilities Engineering Command by URS Consultants Under Contract No. N62474-89-D-9295, CTO 0054*. June.

Navy. 1994. *Final Remedial Investigation Report for Operable Unit 3, Naval Air Station Whidbey Island. Prepared for Engineering Field Activity Northwest, Naval Facilities Engineering Command by URS Consultants Under Contract No. N62474-89-D-9295, CTO 0074*. January.

Navy. 2016. *Summary Report, Groundwater Sampling for Perfluorinated Compounds, Hanar 5 and Areas 16 and 31, Naval Air Station Whidbey Island, Oak Harbor, Washington*. Prepared for Naval Facilities Engineering Command Northwest by MMEC Group under Contract. No. N62473-12-D-2012, CTP JPO2. April 14.


Navy. 2017a. *Investigation of Perfluorinated Compounds in Drinking Water, Ault Field and Outlying Landing Field Coupeville, Naval Air Station Whidbey Island, Oak Harbor and Coupeville, Washington*. January.

Navy. 2017c. *Final Phase 2 Naval Air Station Whidbey Island Per- and Polyfluoroalkyl Substances Drinking Water Investigation Open House Posters*. February.
https://www.navfac.navy.mil/content/dam/navfac/NAVFAC%20Atlantic/NAVFAC%20Northwest/PDFs/About%20Us/PFAS%20Groundwater%20and%20Drinking%20Water%20Investigation/nw_Final_Poster_ALL_NASWI.pdf

Navy. 2017d. *Interim Per- and Polyfluoroalkyl Substances (PFAS) Site Guidance for NAVFAC Remedial Project Managers (RPMs)/September 2017 Update*. September.

This page intentionally left blank.

Figures



Basemap Data and Imagery Source: Esri

- Legend**
- City
 - Secondary Road
 - Local Connecting Road
 - Important Local Road
 - Base Boundary





Figure 1
 Base Location Map
 Ault Field
 Oak Harbor, WA
 Outlying Landing Field (OLF) Coupeville,
 Coupeville, WA
 For Official Use Only



- Legend**
- Suspected Source Area
 - Drainage Ditch (Part of Area 16)
 - Surface Water
 - ➔ Estimated Groundwater Flow Direction
 - Ault Field 1-mile zone
 - Phase 2 Step-Out
 - Phase 3 Step-Out
 - Hangar
 - Base Boundary

- Parcels**
- Detection for PFOS and/or PFOA





Figure 2
Site Layout Map - Ault Field
Naval Air Station Whidbey Island
Oak Harbor, Washington

DRAFT

For Official Use Only



- Legend**
- Proposed Monitoring Well Locations
 - - - Drainage Ditch
 - - - Surface Water
 - ▨ Wetlands
 - ▭ Proposed Drilling Area
 - ▭ Base Boundary




Figure 3
Proposed East Wells 1, 2, and 3
Naval Air Station Whidbey Island
Oak Harbor, Washington
DRAFT
For Official Use Only



Legend

-  Proposed Monitoring Well Locations
-  Drainage Ditch
-  Surface Water
-  Proposed Drilling Area
-  Base Boundary





Figure 4
Proposed East Wells 4, 5, and 6
Naval Air Station Whidbey Island
Oak Harbor, Washington

DRAFT
For Official Use Only



- Legend**
- Proposed Monitoring Well Locations
 - ⊕ Monitoring Well Location
 - ➔ Groundwater Flow Direction
 - ⬜ Area 2 - 1,000 ft Buffer
 - ⬜ Proposed Drilling Area
 - ▨ Wetlands
 - ▭ Suspected Source Area
 - ▨ Mobile Turret Tower Range LUC
 - ⬜ Base Boundary





Figure 6
Proposed New Wells 7, 8, and 9
Naval Air Station Whidbey Island
Oak Harbor, Washington

DRAFT
For Official Use Only




Legend

- Monitoring Well Location
- ➔ Groundwater Flow Direction
- ▭ Suspected Source Area
- ▭ Area 2 - 1,000 ft Buffer
- ▭ Proposed Drilling Area
- ▭ Wetlands

- ▭ Mobile Turret Tower Range LUC
- ▭ Base Boundary


Notes:
 1. N2-6 is a paired well location.
 2. MW-204 is labeled AFR025 in the field.



1 inch = 0.1 mile
 Imagery Source: Esri

Figure 7
 Existing Wells to be Sampled
 Naval Air Station Whidbey Island
 Oak Harbor, Washington

DRAFT
 For Official Use Only



Legend

- 1-mile Zone
- - - Surface Water
- - - Drainage Ditch
- Suspected Source Area
- Half-mile Step-out Downgradient (Phase 2)
- Half-mile Step-out Downgradient (Phase 3)
- Phase 1 Sampling Area
- Phase 2 Sampling Area
- Phase 3 Sampling Area

- Base Boundary
- - - Inferred Groundwater Flow Direction



0 0.225 0.45
Miles

1 inch = 0.45 mile

Imagery Source: Esri

Figure 8
Phase 1, 2, and 3 Voluntary Drinking Water
Sampling Program - Results Summary
Naval Air Station Whidbey Island
Oak Harbor, Washington

Appendix A
Field Standard Operating Procedures –
CH2M

Chain-of-Custody

I Purpose

The purpose of this SOP is to provide information on chain-of-custody procedures to be used under the CLEAN Program.

II Scope

This procedure describes the steps necessary for transferring samples through the use of Chain-of-Custody Records. A Chain-of-Custody Record is required, without exception, for the tracking and recording of samples collected for on-site or off-site analysis (chemical or geotechnical) during program activities (except wellhead samples taken for measurement of field parameters). Use of the Chain-of-Custody Record Form creates an accurate written record that can be used to trace the possession and handling of the sample from the moment of its collection through analysis. This procedure identifies the necessary custody records and describes their completion. This procedure does not take precedence over region specific or site-specific requirements for chain-of-custody.

III Definitions

Chain-of-Custody Record Form - A Chain-of-Custody Record Form is a printed two-part form that accompanies a sample or group of samples as custody of the sample(s) is transferred from one custodian to another custodian. One copy of the form must be retained in the project file.

Custodian - The person responsible for the custody of samples at a particular time, until custody is transferred to another person (and so documented), who then becomes custodian. A sample is under one's custody if:

- It is in one's actual possession.
- It is in one's view, after being in one's physical possession.
- It was in one's physical possession and then he/she locked it up to prevent tampering.
- It is in a designated and identified secure area.

Sample - A sample is physical evidence collected from a facility or the environment, which is representative of conditions at the point and time that it was collected.

IV. Procedures

The term “chain-of-custody” refers to procedures which ensure that evidence presented in a court of law is valid. The chain-of-custody procedures track the evidence from the time and place it is first obtained to the courtroom, as well as providing security for the evidence as it is moved and/or passed from the custody of one individual to another.

Chain-of-custody procedures, recordkeeping, and documentation are an important part of the management control of samples. Regulatory agencies must be able to provide the chain-of-possession and custody of any samples that are offered for evidence, or that form the basis of analytical test results introduced as evidence. Written procedures must be available and followed whenever evidence samples are collected, transferred, stored, analyzed, or destroyed.

A. Sample Identification

The method of identification of a sample depends on the type of measurement or analysis performed. When *in situ* measurements are made, the data are recorded directly in bound logbooks or other field data records with identifying information.

Information which shall be recorded in the field logbook, when in-situ measurements or samples for laboratory analysis are collected, includes:

- Field Sampler(s),
- Contract Task Order (CTO) Number,
- Project Sample Number,
- Sample location or sampling station number,
- Date and time of sample collection and/or measurement,
- Field observations,
- Equipment used to collect samples and measurements, and
- Calibration data for equipment used

Measurements and observations shall be recorded using waterproof ink.

B. Sample Label

Samples, other than for *in situ* measurements, are removed and transported from the sample location to a laboratory or other location for analysis. Before removal, however, a sample is often divided into portions, depending upon the analyses to be performed. Each portion is preserved in accordance with the Sampling and Analysis Plan. Each sample container is identified by a sample label (see Attachment A). Sample labels are provided, along with sample containers, by the analytical laboratory. The information recorded on the sample label includes:

- Project - CTO Number.
- Station Location - The unique sample number identifying this sample.
- Date - A six-digit number indicating the day, month, and year of sample collection (e.g., 08/21/12).

- Time - A four-digit number indicating the 24-hour time of collection (for example: 0954 is 9:54 a.m., and 1629 is 4:29 p.m.).
- Medium - Water, soil, sediment, sludge, waste, etc.
- Sample Type - Grab or composite.
- Preservation - Type and quantity of preservation added.
- Analysis - VOA, BNAs, PCBs, pesticides, metals, cyanide, other.
- Sampled By - Printed name of the sampler.
- Remarks - Any pertinent additional information.

Using only the work assignment number of the sample label maintains the anonymity of sites. This may be necessary, even to the extent of preventing the laboratory performing the analysis from knowing the identity of the site (e.g., if the laboratory is part of an organization that has performed previous work on the site). The field team should always follow the sample ID system prepared by the project EIS and reviewed by the Project Manager.

C. Chain-of-Custody Procedures

After collection, separation, identification, and preservation, the sample is maintained under chain-of-custody procedures until it is in the custody of the analytical laboratory and has been stored or disposed.

D. Field Custody Procedures

- Samples are collected as described in the site Sampling and Analysis Plan. Care must be taken to record precisely the sample location and to ensure that the sample number on the label matches the Chain-of-Custody Record exactly.
- A Chain-of-Custody Record will be prepared for each individual cooler shipped and will include *only* the samples contained within that particular cooler. The Chain-of-Custody Record for that cooler will then be sealed in a zip-log bag and placed in the cooler prior to sealing. This ensures that the laboratory properly attributes trip blanks with the correct cooler and allows for easier tracking should a cooler become lost during transit.
- The person undertaking the actual sampling in the field is responsible for the care and custody of the samples collected until they are properly transferred or dispatched.
- When photographs are taken of the sampling as part of the documentation procedure, the name of the photographer, date, time, site location, and site description are entered sequentially in the site logbook as photos are taken. Once downloaded to the server or developed, the electronic files or photographic prints shall be serially numbered, corresponding to the logbook descriptions; photographic prints will be stored in the project files. To identify sample

locations in photographs, an easily read sign with the appropriate sample location number should be included.

- Sample labels shall be completed for each sample, using waterproof ink unless prohibited by weather conditions (e.g., a logbook notation would explain that a pencil was used to fill out the sample label if the pen would not function in freezing weather.)

E. Transfer of Custody and Shipment

Samples are accompanied by a Chain-of-Custody Record Form. **A Chain-of-Custody Record Form must be completed for each cooler and should include only the samples contained within that cooler.** A Chain-of-Custody Record Form example is shown in Attachment B. When transferring the possession of samples, the individuals relinquishing and receiving will sign, date, and note the time on the Record. This Record documents sample custody transfer from the sampler, often through another person, to the analyst in the laboratory. The Chain-of-Custody Record is filled out as given below:

- Enter header information (CTO number, samplers, and project name).
- Enter sample specific information (sample number, media, sample analysis required and analytical method grab or composite, number and type of sample containers, and date/time sample was collected).
- Sign, date, and enter the time under “Relinquished by” entry.
- Have the person receiving the sample sign the “Received by” entry. If shipping samples by a common carrier, print the carrier to be used in this space (i.e., Federal Express).
- If a carrier is used, enter the airbill number under “Remarks,” in the bottom right corner;
- Place the original (top, signed copy) of the Chain-of-Custody Record Form in a plastic zipper-type bag or other appropriate sample-shipping package. Retain the copy with field records.
- Sign and date the custody seal, a 1-inch by 3-inch white paper label with black lettering and an adhesive backing. Attachment C is an example of a custody seal. The custody seal is part of the chain-of-custody process and is used to prevent tampering with samples after they have been collected in the field. Custody seals shall be provided by the analytical laboratory.
- Place the seal across the shipping container opening (front and back) so that it would be broken if the container were to be opened.
- Complete other carrier-required shipping papers.

The custody record is completed using waterproof ink. Any corrections are made by drawing a line through and initialing and dating the change, then entering the correct information. Erasures are not permitted.

Common carriers will usually not accept responsibility for handling Chain-of-Custody Record Forms; this necessitates packing the record in the shipping container (enclosed with other documentation in a plastic zipper-type bag). As long as custody forms are sealed inside the shipping container and the custody seals are intact, commercial carriers are not required to sign the custody form.

The laboratory representative who accepts the incoming sample shipment signs and dates the Chain-of-Custody Record, completing the sample transfer process. It is then the laboratory's responsibility to maintain internal logbooks and custody records throughout sample preparation and analysis.

V Quality Assurance Records

Once samples have been packaged and shipped, the Chain-of-Custody copy and airbill receipt become part of the quality assurance record.

VI Attachments

- A. Sample Label
- B. Chain of Custody Form
- C. Custody Seal

VII References

USEPA. *User's Guide to the Contract Laboratory Program*. Office of Emergency and Remedial Response, Washington, D.C. (EPA/540/P-91/002), January 1991.

Attachment A
Example Sample Label



Quality Analytical Laboratories, Inc.
 2567 Fairlane Drive
 Montgomery, Alabama 36116
 PH. (334)271-2440

Client _____
 Sample No. _____
 Location _____
 Analysis _____
 Preservative **HCL** _____
 Date _____ By _____

CEIMIC CORPORATION

10 Dean Knauss Drive, Narragansett, R.I. 02882 • (401) 782-8900

| | |
|---|---------------------|
| SITE NAME | DATE |
| ANALYSIS | TIME |
| | PRESERVATIVE |
| SAMPLE TYPE | |
| <input type="checkbox"/> Grab <input type="checkbox"/> Composite <input type="checkbox"/> Other _____ | |
| COLLECTED BY: | |

Attachment B
Example Chain-of-Custody Record

Attachment C
Example Custody Seal



CUSTODY SEAL

Date _____

Signature _____

Field Measurement of pH, Specific Conductance, Turbidity, Dissolved Oxygen, ORP, and Temperature Using a Water Quality Meter with Flow-Through Cell

I. Purpose and Scope

The purpose of this procedure is to provide a general guideline for using a water quality meter for field measurements of pH, specific conductance, turbidity, dissolved oxygen, oxidation-reduction potential (ORP), and temperature of aqueous samples. The operator's manual should be consulted for detailed operating procedures.

II. Equipment and Materials

- Water Quality Monitoring System with flow-through cell (Horiba, YSI, In-Situ, Ion Science, etc)
- Auto-Calibration Standard Solution (provided by rental company)
- Distilled water in squirt bottle

III. Procedures and Guidelines

A. General Parameters and Specifications:

Note: the general parameters listed below may not be available for every type of meter used. Please refer to the specific meter's manual to determine meter's range of measurement and accuracy.

| <u>Parameter</u> | <u>Range of measurement</u> | <u>Accuracy</u> |
|----------------------|-----------------------------|--------------------|
| pH | 0 to 14 pH units | +/- 0.1 pH units |
| Specific conductance | 0 to 9.99 S/m | +/- 3 % full scale |
| Turbidity | 0 to 800 NTU | +/- 5 % full scale |
| Dissolved oxygen | 0 to 19.99 mg/l | +/- 0.2 mg/l |
| Temperature | 0 to 55 °C | +/- 1.0 °C |
| ORP | -999 to +999 mV | +/- 15 mV |
| Salinity | 0 to 4 % | +/- 0.3 % |

B. Calibration:

Prior to each day's use, clean the probe and flow-through cell using deionized water and calibrate using the Standard Solution. Refer to the specific instrumentation manual for the proper calibration methods.

C. Sample Measurement:

The water quality probes are inserted into a flow-through cell, and the purged groundwater is directed through the cell by connecting the pump discharge tubing to the bottom port on the flow through cell, allowing measurements to be collected before the water contacts the atmosphere. The flow-through cell should be positioned out of direct sunlight to reduce solar heating, and wrapped in aluminum foil to minimize heat loss or gain.

As water passes through the flow-through the flow cell, press MEAS to obtain readings or the readings are displayed on the meter for each parameter (dependent on the type of meter used). Record the water quality parameter data in a field notebook.

Once the parameters have stabilized (see *Low-Flow Groundwater Sampling from Monitoring Wells – EPA Region I and III* or *Low-Flow Groundwater Sampling from Monitoring Wells – EPA Region IV* depending on project site location), remove the tubing from the bottom port of the flow-through cell.

Never collect a groundwater sample for laboratory analysis from the flow-through cell. Rinse the flow-through cell between wells to remove any sediment buildup within the cell.

IV. Key Checks and Preventive Maintenance

- Calibrate meter
- Clean probe with deionized water when done
- Refer to operations manual for recommended maintenance and troubleshooting
- Check batteries, and have a replacement set on hand
- Due to the importance of obtaining these parameters, the field team should have a spare unit readily available in case of an equipment malfunction.

Field Measurement of pH, Specific Conductance, Turbidity, Dissolved Oxygen, ORP, and Temperature Using a Horiba or YSI Water Quality Parameter Meter with Flow-through Cell

I. Purpose and Scope

The purpose of this procedure is to provide a general guideline for using a water quality parameter meter (e.g., Horiba® or YSI) for field measurements of pH, specific conductance, turbidity, dissolved oxygen, oxidation-reduction potential (ORP), and temperature of aqueous samples. The YSI instrument does not measure turbidity. A separate turbidity meter (i.e., Hanna Turbidity Meter) will need to be used in conjunction with the YSI meter. The operator's manual should be consulted for detailed operating procedures.

II. Equipment and Materials

- Water Quality Parameter Meter such as a Horiba® Water Quality Monitoring System or YSI with flow-through cell
- Auto-Calibration Standard Solution (provided by rental company)
- Distilled water in squirt bottle

III. Procedures and Guidelines

A. Parameters and Specifications:

| Parameter | Range of measurement | Accuracy |
|----------------------|-----------------------------|--------------------|
| pH | 0 to 14 pH units | +/- 0.1 pH units |
| Specific conductance | 0 to 9.99 S/m | +/- 3 % full scale |
| Turbidity | 0 to 800 NTU | +/- 5 % full scale |
| Dissolved oxygen | 0 to 19.99 mg/l | +/- 0.2 mg/l |
| Temperature | 0 to 55 °C | +/- 1.0 °C |
| ORP | -999 to +999 mV | +/- 15 mV |
| Salinity | 0 to 4 % | +/- 0.3 % |

B. Calibration:

Prior to each day's use, clean the probe and flow-through cell using deionized water and calibrate using the Standard Solution.

Horiba Calibration procedure:

1. Fill a calibration beaker with standard solution to the recommended fill line.
2. Insert the probe into the beaker. All the parameter sensors will now be immersed in the standard solution except the D.O. sensor; the D.O. calibration is done using atmospheric air.
3. Turn power on and allow some time for the machine to warm-up prior to starting the calibration. When the initial readings appear to stabilize the instrument is ready to calibrate.
4. Press CAL key to put the unit in the calibration mode.
5. Press the ENT key to start automatic calibration. Wait a moment, and the upper cursor will gradually move across the four auto-calibration parameters one by one: pH, COND, TURB, and DO. When the calibration is complete, the readout will briefly show END. The instrument is now calibrated.
6. If the unit is calibrated properly the instrument readings, while immersed in the standard solution, will match the standard solution values provided on the solution container. The typical standard solution values are: pH = 4.0 +/- 3%, conductivity 4.49 mS/cm +/- 3%, and turbidity = 0 NTU +/- 3%.
7. Record the calibration data (e.g. time, instrument ID, solution lot number and expiration date, final calibrated readings, and solution temperature in the field logbook.

YSI Calibration procedure:

1. Press the **On/off** key to display the run screen
2. Press the **Escape** key to display the main menu screen
3. Use the arrow keys to highlight the **Calibrate**
4. Press the **Enter** key. The Calibrate screen is displayed
5. Choose the parameter to calibrate

A. Conductivity Calibration:

This procedure calibrates specific conductance (recommended), conductivity and salinity. Calibrating any one option automatically calibrates the other two.

- 1) Use the arrow keys to highlight the **Conductivity** selection
- 2) Press **Enter**. The Conductivity Calibration Selection Screen is displayed.
- 3) Use the arrow keys to highlight the Specific Conductance selection.
- 4) Press **Enter**. The Conductivity Calibration Entry Screen is displayed.
- 5) Place the correct amount of conductivity standard (see Instrument Manual) into a clean, dry or pre-rinsed transport/calibration cup.
- 6) Carefully immerse the sensor end of the probe module into the solution.
- 7) Gently rotate and/or move the probe module up and down to remove any bubbles from the conductivity cell.

NOTE: The sensor must be completely immersed past its vent hole. Using the recommended volumes from the Instrument Manual Calibration Volumes should ensure that the vent hole is covered.

- 8) Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.
NOTE: Do not over tighten as this could cause damage to the threaded portions.
- 9) Use the keypad to enter the calibration value of the standard you are using.
NOTE: Be sure to enter the value in **mS/cm at 25°C**.
- 10) Press **Enter**. The Conductivity Calibration Screen is displayed.
- 11) Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
- 12) Observe the reading under Specific Conductance. When the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
- 13) Press **Enter**. This returns you to the Conductivity Calibrate Selection Screen
- 14) Press **Escape** to return to the calibrate menu.
- 15) Rinse the probe module and sensors in tap or purified water and dry.

B. Dissolved Oxygen Calibration:

This procedure calibrates dissolved oxygen. Calibrating any one option (% or mg/L) automatically calibrates the other.

- 1) Go to the calibrate screen as described in Section
NOTE: The instrument must be on for at least 20 minutes to polarize the DO sensor before calibrating.
- 2) Use the arrow keys to highlight the **Dissolved Oxygen** selection.
- 3) Press **Enter**. The dissolved oxygen calibration screen is displayed.
- 4) DO calibration in mg/L is carried out in a water sample which has a known concentration of dissolved oxygen (usually determined by a Winkler titration).
- 5) Use the arrow keys to highlight the **DO mg/L** selection.
- 6) Press **Enter**. The DO mg/L Entry Screen is displayed.
- 7) Place the probe module in water with a known DO concentration.
NOTE: Be sure to completely immerse all the sensors.
- 8) Use the keypad to enter the known DO concentration of the water.
- 9) Press **Enter**. The Dissolved Oxygen mg/L Calibration Screen is displayed.
- 10) Stir the water with a stir bar, or by rapidly moving the probe module, to provide fresh sample to the DO sensor.
- 11) Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
- 12) Observe the DO mg/L reading, when the reading is stable (shows no significant change for approximately 30 seconds), press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
- 13) Press **Enter**. This returns you to the DO calibration screen.
- 14) Press **Escape** to return to the calibrate menu.
- 15) Rinse the probe module and sensors in tap or purified water and dry.

C. pH Calibration:

- 1) Go to the calibrate screen.
- 2) Use the arrow keys to highlight the **pH** selection.
- 3) Press **Enter**. The pH calibration screen is displayed.

- Select the **1-point** option only if you are adjusting a previous calibration. If a 2-point or 3-point calibration has been performed previously, you can adjust the calibration by carrying out a one point calibration. The procedure for this calibration is the same as for a 2-point calibration, but the software will prompt you to select only one pH buffer.
 - Select the **2-point** option to calibrate the pH sensor using only two calibration standards. Use this option if the media being monitored is known to be either basic or acidic. For example, if the pH of a pond is known to vary between 5.5 and 7, a two-point calibration with pH 7 and pH 4 buffers is sufficient. A three point calibration with an additional pH 10 buffer will not increase the accuracy of this measurement since the pH is not within this higher range.
 - Select the **3-point** option to calibrate the pH sensor using three calibration solutions. In this procedure, the pH sensor is calibrated with a pH 7 buffer and two additional buffers. The 3-point calibration method assures maximum accuracy when the pH of the media to be monitored cannot be anticipated. The procedure for this calibration is the same as for a 2-point calibration, but the software will prompt you to select a third pH buffer.
- 4) Use the arrow keys to highlight the **2-point** selection.
 - 5) Press **Enter**. The pH Entry Screen is displayed.
 - 6) Place the correct amount of pH buffer into a clean, dry or pre-rinsed transport/calibration cup.
 - NOTE:** For maximum accuracy, the pH buffers you choose should be within the same pH range as the water you are preparing to sample.
 - NOTE:** Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the pH sensor with a small amount of buffer that can be discarded. Be certain that you avoid cross-contamination of buffers with other solutions.
 - 7) Carefully immerse the sensor end of the probe module into the solution.
 - 8) Gently rotate and/or move the probe module up and down to remove any bubbles from the pH sensor.
 - NOTE:** The sensor must be completely immersed. Using the recommended volumes from Table 6.1 Calibration Volumes, should ensure that the sensor is covered.
 - 9) Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.
 - NOTE:** Do not over tighten as this could cause damage to the threaded portions.
 - 10) Use the keypad to enter the calibration value of the buffer you are using **at the current temperature**.
 - NOTE:** pH vs. temperature values are printed on the labels of all YSI pH buffers.
 - 11) Press **Enter**. The pH calibration screen is displayed.
 - 12) Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
 - 13) Observe the reading under pH, when the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
 - 14) Press **Enter**. This returns you to the Specified pH Calibration Screen.

- 15) Rinse the probe module, transport/calibration cup and sensors in tap or purified water and dry.
- 16) Repeat steps 6 through 13 above using a second pH buffer.
- 17) Press **Enter**. This returns you to the pH Calibration Screen.
- 18) Press **Escape** to return to the calibrate menu.
- 19) Rinse the probe module and sensors in tap or purified water and dry.

D. ORP Calibration:

- 1) Go to the calibrate screen.
- 2) Use the arrow keys to highlight the **ORP** selection.
- 3) Press **Enter**. The ORP calibration screen is displayed.
- 4) Place the correct amount of a known ORP solution into a clean, dry or pre-rinsed transport/calibration cup.

NOTE: Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the ORP sensor with a small amount of solution that can be discarded. Be certain that you avoid cross-contamination with other solutions.
- 5) Carefully immerse the sensor end of the probe module into the solution.
- 6) Gently rotate and/or move the probe module up and down to remove any bubbles from the ORP sensor.

NOTE: The sensor must be completely immersed.
- 7) Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.
- 8) Use the keypad to enter the correct value of the calibration solution you are using at the current temperature.
- 9) Press **Enter**. The ORP calibration screen is displayed.
- 10) Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
- 11) Observe the reading under ORP, when the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
- 12) Press **Enter**. This returns you to the Calibrate Screen.
- 13) Rinse the probe module and sensors in tap or purified water and dry. Record the calibration data (e.g. time, instrument ID, solution lot number and expiration date, final calibrated readings, and solution temperature in the field logbook.

C. Sample Measurement:

Horiba measurement procedure:

As water passes through the flow-through the flow cell, press MEAS to obtain reading; record data in a field notebook.

YSI measurement procedure:

As water passes through the flow-through the flow cell, the readings are displayed for each parameter. Record the water quality parameter data in a field notebook. In addition, the data is recorded in the YSI and can be downloaded to a computer following completion of the sampling event.

IV. Key Checks and Preventive Maintenance

- Calibrate meter
- Clean probe with deionized water when done
- Refer to operations manual for recommended maintenance and troubleshooting
- Check batteries, and have a replacement set on hand
- Due to the importance of obtaining these parameters, the field team should have a spare unit readily available in case of an equipment malfunction.

V. References

YSI 556 Multi Probe System Operator Manual



Pure Data for a Healthy Planet.™



YSI 556 MPS
Multi Probe System

**Operations
Manual**

Contents

| | |
|---|-----------|
| 1. Safety | 1 |
| 1.1 General Safety Information | 1 |
| 2. General Information | 7 |
| 2.1 Description..... | 7 |
| 2.2 Unpacking the Instrument..... | 8 |
| 2.3 Features of the YSI 556 Multi-Probe System..... | 9 |
| 2.4 Batteries | 10 |
| 2.5 Power On | 15 |
| 2.6 Setting Display Contrast | 15 |
| 2.7 Backlight..... | 16 |
| 2.8 General Screen Features | 16 |
| 2.9 Keypad Use..... | 17 |
| 2.10 Instrument Reset | 18 |
| 2.11 Menu Flowchart..... | 19 |
| 3. Probe Module | 21 |
| 3.1 Introduction..... | 21 |
| 3.2 Unpacking the Probe Module | 21 |
| 3.3 Features of the YSI 5563 Probe Module | 22 |
| 3.4 Preparing the Probe Module | 22 |
| 3.5 Transport/Calibration Cup | 26 |
| 3.6 Instrument/Cable Connection | 27 |
| 4. Sensors | 29 |
| 5. Report | 33 |
| 6. Calibrate | 37 |
| 6.1 Getting Ready to Calibrate | 37 |
| 6.2 Calibration Procedures..... | 40 |
| 6.3 Return to Factory Settings | 56 |
| 7. Run | 59 |
| 7.1 Real-Time Data..... | 59 |
| 8. File | 61 |
| 8.1 Accessing the File Screen..... | 61 |
| 8.2 Directory | 62 |
| 8.3 View File | 63 |
| 8.4 Upload to PC..... | 64 |
| 8.5 File Memory | 69 |

Contents

| | | |
|------------|---|------------|
| 8.6 | Delete All Files..... | 70 |
| 9. | Logging..... | 73 |
| 9.1 | Accessing the Logging Setup Screen..... | 73 |
| 9.2 | Setting Logging Interval..... | 74 |
| 9.3 | Storing Barometer Readings..... | 74 |
| 9.4 | Creating a Site List..... | 75 |
| 9.5 | Editing a Site List..... | 79 |
| 9.6 | Logging Data Without a Site List..... | 81 |
| 9.7 | Logging Data With a Site List..... | 84 |
| 9.8 | Adding Data to Existing Files..... | 85 |
| 10. | System Setup..... | 89 |
| 10.1 | Accessing the System Setup Screen..... | 89 |
| 10.2 | Date and Time Setup..... | 90 |
| 10.3 | Data Filter..... | 92 |
| 10.4 | Shutoff Time..... | 94 |
| 10.5 | Comma Radix..... | 95 |
| 10.6 | ID..... | 95 |
| 10.7 | GLP Filename..... | 95 |
| 10.8 | TDS Constant..... | 96 |
| 10.9 | Barometer Units..... | 97 |
| 10.10 | Calibrate Barometer..... | 98 |
| 11. | Maintenance..... | 101 |
| 11.1 | Sensor Care and Maintenance..... | 101 |
| 11.2 | Upgrading YSI 556 MPS Software..... | 107 |
| 12. | Storage..... | 111 |
| 12.1 | General Recommendations for Short Term Storage..... | 111 |
| 12.2 | General Recommendations for Long Term Storage..... | 111 |
| 13. | Troubleshooting..... | 115 |
| 14. | Appendix A YSI 556 MPS Specifications..... | 119 |
| 14.1 | Sensor Specifications..... | 119 |
| 14.2 | Instrument Specifications..... | 120 |
| 15. | Appendix B Instrument Accessories..... | 121 |
| 16. | Appendix C Required Federal Communications Notice..... | 123 |
| 17. | Appendix D Health and Safety..... | 125 |
| 18. | Appendix E Customer Service..... | 129 |

Contents

| | | |
|------------|--|------------|
| 18.1 | YSI Environmental Authorized Service Centers | 129 |
| 18.2 | Cleaning Instructions | 131 |
| 18.3 | Packing Procedure | 132 |
| 18.4 | Cleaning Certificate | 132 |
| 18.5 | Warranty | 133 |
| 19. | Appendix F Ferrite Bead Installation | 135 |
| 20. | Appendix G EcoWatch..... | 137 |
| 20.1 | Installing EcoWatch for Windows..... | 137 |
| 20.2 | EcoWatch Tutorial..... | 139 |
| 21. | Appendix H Calibration Record Information | 151 |
| 21.1 | Viewing the Calibration Record (.glp) File | 151 |
| 21.2 | Uploading the Calibration Record (.glp) File | 151 |
| 21.3 | Understanding the Calibration Record (.glp) File..... | 151 |

Contents

1. Safety

1.1 General Safety Information

Read all safety information in this manual carefully before using the YSI 556 Multi-Probe System (MPS). Reagents that are used to calibrate and check this instrument may be hazardous to your health. Take a moment to review *Appendix D Health and Safety*.

WARNING


Warnings are used in this manual when misuse of the instrument could result in death or serious injury to a person.

CAUTION

Cautions are used in this manual when misuse of the instrument could result in mild or serious injury to a person and/or damage to equipment.

IMPORTANT SAFETY INSTRUCTIONS!

SAVE THESE INSTRUCTIONS!

 In essence, the most important safety rule for use of the YSI 556 MPS is to utilize the instrument **ONLY** for purposes documented in this manual. This is particularly true of the YSI 6117 rechargeable battery pack that contains nickel metal hydride (NiMH) batteries. The user should be certain to read all of the safety precautions outlined below before using the instrument.

YSI 6117 Rechargeable Battery Pack Safety Information

Restrictions on Usage

1. Never dispose of the battery pack in a fire.
2. Do not attempt to disassemble the YSI 6117 battery pack.
3. Do not tamper with any of the electronic components or the batteries within the battery pack. Tampering with either the electronic circuitry or the batteries will result in the voiding of the warranty and the compromising of the system performance, but, more importantly, can cause safety

hazards which result from overcharging such as overheating, venting of gas, and loss of corrosive electrolyte.

4. Do not charge the battery pack outside the 0–40°C temperature range.
5. Do not use or store the battery at high temperature, such as in strong direct sunlight, in cars during hot weather, or directly in front of heaters.
6. Do not expose the battery pack to water or allow the terminals to become damp.
7. Avoid striking or dropping the battery pack. If the pack appears to have sustained damage from these actions or malfunctions after an impact or drop, the user should not attempt to repair the unit. Instead, contact YSI Customer Service. Refer to *Appendix E Customer Service*.
8. If the battery pack is removed from the YSI 556 MPS, do not store it in pockets or packaging where metallic objects such as keys can short between the positive and negative terminals.



Precautions for Users with Small Children

Keep the battery pack out of reach of babies and small children.



Danger Notifications – Misuse creates a STRONG possibility of death or serious injury.

FAILURE TO CAREFULLY OBSERVE THE FOLLOWING PROCEDURES AND PRECAUTIONS CAN RESULT IN LEAKAGE OF BATTERY FLUID, HEAT GENERATION, BURSTING, AND SERIOUS PERSONAL INJURY.

1. Never dispose of the battery pack in a fire or heat it.
2. Never allow the positive and negative terminals of the battery pack to become shorted or connected with electrically conductive materials. When the battery pack has been removed from the YSI 556 MPS, store it in a heavy plastic bag to prevent accidental shorting of the terminals.

3. Never disassemble the battery pack and do not tamper with any of the electronic components or the batteries within the battery pack. The battery pack is equipped with a variety of safety features. Accidental deactivation of any of these safety features can cause a serious hazard to the user.
4. The NiMH batteries in the battery pack contain a strong alkaline solution (electrolyte). The alkaline solution is extremely corrosive and will cause damage to skin or other tissues. If any fluid from the battery pack comes in contact with a user's eyes, immediately flush with clean water and consult a physician immediately. The alkaline solution can damage eyes and lead to permanent loss of eyesight.



Warning Notifications – Misuse creates a possibility of death or serious injury

1. Do not allow the battery pack to contact freshwater, seawater, or other oxidizing reagents that might cause rust and result in heat generation. If a battery becomes rusted, the gas release vent may no longer operate and this failure can result in bursting.
2. If electrolyte from the battery pack contacts the skin or clothing, thoroughly wash the area immediately with clean water. The battery fluid can irritate the skin.



Caution Notifications – Misuse creates a possibility of mild or serious injury or damage to the equipment.

1. Do not strike or drop the battery pack. If any impact damage to the battery pack is suspected, contact YSI Customer Service. Refer to *Appendix E Customer Service*.
2. Store the battery pack out of reach of babies and small children.
3. Store the battery pack between the temperatures of -20 and 30°C.
4. Before using the battery pack, be sure to read the operation manual and all precautions carefully. Then store this information carefully to use as a reference when the need arises.

 **YSI 616 Cigarette Lighter Charger Safety Information**


1. This section contains important safety and operating instructions for the YSI 556 MPS cigarette lighter battery charger (YSI 616; RadioShack Number 270-1533E). **BE SURE TO SAVE THESE INSTRUCTIONS.**
2. Before using the YSI 616 cigarette lighter charger, read all instructions and cautionary markings on battery charger, battery pack, and YSI 556 MPS.
3. Charge the YSI 6117 battery pack with the YSI 616 cigarette lighter charger **ONLY** when the YSI 6117 is installed in the YSI 556 MPS.
4. Do not expose charger to rain, moisture, or snow.
5. Use of an attachment not recommended or sold by the battery charger manufacturer may result in a risk of fire, electric shock, or injury to persons.
6. To reduce risk of damage to cigarette lighter and cord, pull by cigarette lighter rather than cord when disconnecting charger.
7. Make sure that the cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
8. Do not operate charger with damaged cord or cigarette lighter connector – replace it immediately.
9. Do not operate charger if it has received a sharp blow, been dropped, or otherwise damaged in any way; contact YSI Customer Service. Refer to *Appendix E Customer Service*.
10. Do not disassemble charger other than to change the fuse as instructed. Replace the part or send it to YSI Product Service if repair is required (refer to *Appendix E Customer Service*). Incorrect reassembly may result in a risk of electric shock or fire.
11. To reduce risk of electric shock, unplug charger before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.

 **YSI 556 MPS Water Leakage Safety Information**


The YSI 556 MPS has been tested and shown to comply with IP67 criterion, i.e. submersion in 1 meter of water for 30 minutes with no leakage into either the battery compartment or the main case. However, if the instrument is submersed for periods of time in excess of 30 minutes, leakage may occur with subsequent damage to the batteries, the rechargeable battery pack circuitry, and/or the electronics in the main case.

If leakage into the battery compartment is observed when using alkaline C cells, remove batteries, dispose of batteries properly, and dry the battery compartment completely, ideally using compressed air. If corrosion is present on the battery terminals, contact YSI Customer Service for instructions. Refer to *Appendix E Customer Service*.

If leakage into the battery compartment is observed when using the YSI 6117 rechargeable battery pack, remove the battery assembly and set aside to dry. Return the battery pack to YSI Product Service for evaluation of possible damage. Finally dry the battery compartment completely, ideally using compressed air. If corrosion is present on the battery terminals, contact YSI Customer Service for instructions. Refer to *Appendix E Customer Service*.

 **CAUTION:** If water has contacted the rechargeable battery pack, do not attempt to reuse it until it has been evaluated by YSI Product Service (refer to *Appendix E Customer Service*). Failure to follow this precaution can result in serious injury to the user.

If it is suspected that leakage into the main cavity of the case has occurred, remove the batteries immediately and return the instrument to YSI Product Service for damage assessment. Refer to *Appendix E Customer Service*.

 **CAUTION:** Under no circumstances should the user attempt to open the main case.

2. General Information

2.1 Description

The rugged and reliable YSI 556 MPS (Multi-Probe System) combines the versatility of an easy-to-use, easy-to-read handheld unit with all the functionality of a multi-parameter system. Featuring a waterproof, impact-resistant case, the YSI 556 MPS simultaneously measures dissolved oxygen, conductivity, temperature, and optional pH and ORP. A simple cellular phone style keypad and large display make the instrument easy to use. The YSI 556 MPS is compatible with YSI EcoWatch™ for Windows™ software.

The YSI 556 MPS assists the user in conforming to Good Laboratory Practice (GLP) standards which help ensure that quality control/quality assurance methods are followed. Battery life is displayed with a fuel gauge, and the user can choose standard alkaline batteries or an optional rechargeable battery pack.

The 1.5 MB memory can store more than 49,000 data sets. Other options include a flow cell and barometer. The internal barometer can be user-calibrated and displayed along with other data, used in dissolved oxygen calibrations, and logged to memory for tracking changes in barometric pressure.

Features

- Waterproof - meets IP67 specifications
- Field-replaceable DO electrode module; pH and pH/ORP sensors
- Compatible with Ecowatch™ for Windows™ data analysis software
- Assists with Good Laboratory Practice Standards (GLP)
- Choice of DO membrane material for different applications
- Easy-to-use, screw-on cap DO membranes
- User-upgradable software from YSI website
- Three-year warranty on the instrument; one-year on the probe modules
- Available with 4, 10, and 20 m cable lengths
- Stores over 49,000 data sets, time and date stamped

- Auto temperature compensating display contrast
- Optional barometer
- Optional rechargeable battery pack or standard alkaline batteries

2.2 Unpacking the Instrument

1. Remove the instrument from the shipping box. Note that the probe module and sensors are shipped in a separate box and will be unpacked later in Section 3.2 *Unpacking the Probe Module*.

NOTE: Do not discard any parts or supplies.

2. Use the packing list to ensure all items are present.
3. Visually inspect all components for damage.

NOTE: If any parts are missing or damaged, contact your YSI Service Center immediately. Refer to *Appendix E Customer Service* or www.ysi.com.

2.3 Features of the YSI 556 Multi-Probe System




Figure 2.1 Front View of YSI 556 MPS




Figure 2.2 Back View of YSI 556 MPS

2.4 Batteries

2.4.1 Battery Life

Standard Alkaline Batteries

With the standard battery configuration of 4 alkaline C cells, the YSI 556 MPS will operate continuously for approximately 180 hours. Assuming a standard usage pattern when sampling of 3 hours of “on time” in a typical day, the alkaline cells will last approximately 60 days.

Optional Rechargeable Battery Pack

When fully charged, the optional rechargeable battery pack will provide approximately 50 hours of battery life.

2.4.2 Inserting 4 C Batteries




Figure 2.3 Inserting C Cells

⚠ CAUTION: Install batteries properly to avoid damage to the instrument.

1. Loosen the four screws in the battery lid on the back of the instrument using any screwdriver.
2. Remove the battery lid.
3. Insert four C batteries between the clips following the polarity (+ and -) labels on the bottom of the battery compartment.
4. Check gasket for proper placement on the battery lid.
5. Replace the battery lid and tighten the 4 screws securely and evenly.

NOTE: Do not over-tighten the screws.

2.4.3 Inserting Optional Rechargeable Battery Pack




Figure 2.4 Inserting Battery Pack

⚠ CAUTION: Read all cautions and warnings that come with the battery pack *before* using the battery pack.

1. Loosen the four screws in the battery lid on the back of the instrument using any screwdriver.
2. Remove the C battery lid and store for future use. Remove C batteries, if installed.
3. Check for proper placement of gasket on the rechargeable battery pack and lid.
4. Install the rechargeable battery pack and lid and tighten the 4 screws securely and evenly.

NOTE: Do not over tighten the screws.

2.4.4 Charging the Optional Rechargeable Battery Pack




Figure 2.5 Charging the Battery Pack

⚠ CAUTION: Do not use or store the battery pack at extreme temperatures such as in strong direct sunlight, in cars during hot weather or close to heaters.

1. Install the rechargeable battery pack into the instrument as described in Section 2.4.3 *Inserting Optional Rechargeable Battery Pack*.
2. Attach the charger adapter cable (YSI 6119) to the instrument.

NOTE: Wall power supplies for use in countries outside the US and Canada can be found in *Appendix B Instrument Accessories*.

3. Insert the barrel connector of the wall power supply into the barrel of the adapter cable.

⚠ CAUTION: Do not charge the battery pack continuously for more than 48 hours.

⚠ CAUTION: Do not drop or expose to water.

⚠ CAUTION: Do not charge the battery pack at temperatures below 0°C or above 40°C.

4. Plug the wall power supply into an AC power outlet for approximately 2 hours to obtain an 80% to 90% charge and for 6 hours to get a full charge.


NOTE: The battery pack can be recharged whether the instrument is on or off.


2.4.5 Storing the Battery Pack

Remove the battery pack from the instrument when the instrument will not be used for extended periods of time to prevent over discharge of the battery pack.

Store the battery pack in a heavy plastic bag to prevent accidental shorting of the terminals. Store between -20 and 30°C .

2.4.6 Optional Cigarette Lighter Charger

 **CAUTION: Read all warnings and cautions that come with the charger before using the charger.**

 **CAUTION: Only use cigarette lighter charger when *rechargeable* battery pack is inserted into instrument.**

 **CAUTION: Do not mishandle cigarette lighter charger. Do not expose to moisture.**

1. Plug the barrel connector of the cigarette lighter charger into the mating end of the YSI 6119 Charger Adapter Cable.
2. Attach the MS-19 end of the YSI 6119 Charger Adapter Cable to the instrument.
3. Make one of the following modifications to the other end of the charger:

Slide the adapter ring off the plug to use the device with an American or Japanese vehicle.

American and Japanese Vehicles




Figure 2.6 Charger Plug Adapter Use

Leave the adapter ring on the plug and position it so that the slots on the adapter ring line up with the plug's spring clips to use the device on a European vehicle.

European Vehicles




Figure 2.7 European Charger Plug Adapter Use

NOTE: If the charger stops working properly, refer to Section 13 *Troubleshooting*.

2.5 Power On

Press and release the on/off button in the upper left corner of the instrument keypad to turn the instrument on or off. See Figure 2.1 Front View of YSI 556 MPS.

2.6 Setting Display Contrast

The display contrast automatically compensates for temperature changes. However, under extreme temperature conditions you may wish to optimize the display by manual adjustment as follows:

1. Press and *hold down* the backlight key in the upper right corner of the keypad and press the “up” arrow to increase (darken) the contrast.
2. Press and *hold down* the backlight key in the upper right corner of the keypad and press the “down” arrow to decrease (lighten) the contrast.

2.7 Backlight

Press and *release* the backlight key in the upper right corner of the keypad to turn the backlight on or off. See Figure 2.1 Front View of YSI 556 MPS.

NOTE: The backlight turns off automatically after two minutes of non-use.

2.8 General Screen Features




Figure 2.8 Main Menu Screen

2.9 Keypad Use




Figure 2.9 Keypad Features

| KEY | LETTER/ NUMBER |
|-----|----------------|
| 1 | 1 |
| 2 | ABC2abc3 |
| 3 | DEF3def3 |
| 4 | GHI4ghi4 |
| 5 | JKL5jkl5 |
| 6 | MNO6mno6 |
| 7 | PQRS7pqrs7 |
| 8 | TUV8tuv8 |
| 9 | WXYZ9wxyz9 |
| 0 | 0 |

Figure 2.10 Keypad Letters & Numbers

1. See Figure 2.10 Keypad Letters & Numbers and press the appropriate key repeatedly until letter or number desired appears in display.

NOTE: Press the key repeatedly in rapid succession to get to the desired letter or number. If you pause for more than a

second, the cursor automatically scrolls to the right to prepare for the next input.

EXAMPLE 1: Press the **6** key *once* and *release* to display an uppercase “M.”

EXAMPLE 2: Press the **6** key *four times* and *release* to display the number “6.”

EXAMPLE 3: Press the **6** key *five times* and *stop* to display a lowercase “m.”


2. Press the left arrow key to go back and reenter a number or letter that needs to be changed.
3. Press the **Enter** key when your entry is complete.

NOTE: The instrument software permits only numeric entries in many instances, such as when setting the clock or entering calibration parameters.

2.10 Instrument Reset

The YSI 556 MPS is characterized by sophisticated software that should provide trouble-free operation. However as with all high-capability software packages, it is always possible that the user will encounter circumstances in which the instrument does not respond to keypad entry. If this occurs, the instrument function can easily be restored by removing and then reapplying battery power. Simply remove either your C-cells or rechargeable battery pack from the battery compartment, wait 30 seconds and then replace the batteries. See Section 2.4 *Batteries* for battery removal/reinstallation instructions.

2.11 Menu Flowchart



3. Probe Module

3.1 Introduction

The YSI 5563 Probe module is used for measuring dissolved oxygen, temperature, conductivity, and optional pH and ORP. The probe module is rugged, with the sensors enclosed in a heavy duty probe sensor guard with attached sinking weight. A 4, 10 or 20 meter cable is directly connected to the probe module body making it waterproof. An MS-19 connector at the end of the cable makes the YSI 5563 fully compatible with the YSI 556 Multi-Probe System.

3.2 Unpacking the Probe Module

1. Remove the YSI 5563 Probe module from the shipping boxes.

NOTE: Do not discard any parts or supplies.

2. Use the packing list to ensure all items are present.
3. Visually inspect all components for damage.

NOTE: If any parts are missing or damaged, contact your YSI Service Center immediately. Refer to *Appendix E Customer Service* or www.ysi.com.

3.3 Features of the YSI 5563 Probe Module




Figure 3.1 Probe Module

3.4 Preparing the Probe Module


To prepare the probe module for calibration and operation, you need to install the sensors into the connectors on the probe module bulkhead. In addition to sensor installation, you need to install a new DO membrane cap.

3.4.1 Sensor Installation


Whenever you install, remove or replace a sensor, it is extremely important that the entire probe module and all sensors be thoroughly dried prior to the removal of a sensor or a sensor port plug. This will prevent water from entering the port. Once you remove a sensor or plug, examine the connector inside the probe module sensor port. If any moisture is present, use compressed air to completely dry the connector. If the connector is corroded, return the probe module to your dealer or directly to YSI Customer Service. Refer to *Appendix E Customer Service*.

Conductivity/Temperature and pH, pH/ORP Sensor Installation

1. Unscrew and remove the probe sensor guard.
2. Using the sensor installation tool supplied in the YSI 5511 maintenance kit, unscrew and remove the sensor port plugs.

**Figure 3.2 Port Plug Removal**

3. Locate the port with the connector that corresponds to the sensor that is to be installed.

**Figure 3.3 Sensor Port Identification**

4. Apply a thin coat of o-ring lubricant (supplied in the YSI 5511 maintenance kit) to the o-rings on the connector side of the sensor (see Figure 3.4 O-Ring Lubrication).




Figure 3.4 O-Ring Lubrication

⚠ CAUTION: Make sure that there are NO contaminants between the O-ring and the sensor. Contaminants that are present under the O-ring may cause the O-ring to leak.

5. Be sure the probe module sensor port is free of moisture and then insert the sensor into the correct port. Gently rotate the sensor until the two connectors align.
6. With connectors aligned, screw down the sensor nut using the sensor installation tool.




Figure 3.5 Sensor Installation

⚠ CAUTION: Do not cross thread the sensor nut. Tighten the nut until it is flush with the face of the probe module bulkhead. Do not over tighten.




Figure 3.6 Bulkhead Seating

7. Repeat steps 3-6 for any other sensors.
8. Replace the probe sensor guard.

Dissolved Oxygen Sensor Installation

The YSI 5563 comes with the DO sensor already installed. Refer to Section *11.1.2 DO Sensor Replacement* for instructions on installing the YSI 558 Replaceable DO Module Kit.

3.4.2 Membrane Cap Selection

The YSI 5563 is shipped with a YSI 5909 kit that contains membrane caps made with 2 mil polyethylene (PE), a material which should be ideal for most field applications of the 556. However, YSI also offers membrane caps made with two other materials (1 mil polyethylene and 1 mil Teflon) which some users may also prefer. All membranes available for the 556/5563 system provide comparable accuracy if used properly. The difference between the two thicknesses of PE is found in the trade-off of flow dependence and response time as described below. Teflon is offered because some users may prefer to continue using the traditional membrane material used by YSI. To avoid confusion, the membrane caps are color coded as described below and can be ordered in kits as noted:

- 1 mil Teflon – Black Caps (Kit = YSI 5906)
- 1 mil Polyethylene (PE) – Yellow Caps (Kit = YSI 5908)
- 2 mil Polyethylene (PE) – Blue Caps (Kit = YSI 5909)

The 1 mil Teflon caps will offer traditional, reliable performance for most dissolved oxygen applications. The 1 mil PE caps will provide a significantly faster dissolved oxygen response (as long as your 556 Data Filter is set correctly as described below in Sections 10.2 and 10.3.1)) while also giving readings which are significantly less flow dependent than the 1 mil Teflon caps. Finally, 2 mil PE caps will show a large reduction in flow dependence over 1 mil Teflon while not significantly increasing the response time. Generally, one of the PE caps is likely to provide better performance for your application.

IMPORTANT: No matter which type of membrane cap you select, you will also have to confirm your selection in the 556

software from the Sensor menu as described in Section 4 *Sensors*.

3.4.3 Membrane Cap Installation

NOTE: The YSI 5563 DO sensor (already installed in the probe module) was shipped dry. A shipping membrane was installed to protect the electrode. **A new membrane cap must be installed before the first use.**

1. Unscrew and remove the probe sensor guard.
2. Unscrew, remove, and discard the old membrane cap.
3. Thoroughly rinse the sensor tip with distilled water.
4. Prepare the electrolyte according to the directions on the electrolyte solution bottle.
5. Hold the new membrane cap and fill it at least 1/2 full with the electrolyte solution.
6. Screw the membrane cap onto the sensor moderately tight. A small amount of electrolyte should overflow.



CAUTION: Do not touch the membrane surface.

7. Screw the probe sensor guard on moderately tight.

3.5 Transport/Calibration Cup

The YSI 5563 Probe module has been supplied with a convenient transport/calibration cup. This cup is an ideal container for calibration of the different sensors, minimizing the amount of solution needed. Refer to Section 6 *Calibrate*.

3.5.1 Transport/Calibration Cup Installation

1. Remove probe sensor guard, if already installed.
2. Ensure that an o-ring is installed in the o-ring groove on the threaded end of the probe module body.
3. Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.

NOTE: Do not overtighten as this could cause damage to the threaded portions.




Figure 3.7 Transport/Calibration Cup Installation

3.6 Instrument/Cable Connection

Attach the cable to the instrument as follows:

1. Line up the pins and guides on the cable with the holes and indentations on the cable connector at the bottom of the YSI 556 instrument. See Figure 2.1 Front View of YSI 556 MPS.
2. Holding the cable firmly against the cable connector, turn the locking mechanism clockwise until it snaps into place.

Remove the cable from the instrument by turning the cable connector counterclockwise until the cable disengages from the instrument.

4. Sensors

The Sensors Enabled screen allows the user to enable or disable each of the sensors and select which membrane material will be used for the dissolved oxygen sensor. Disabled sensors will not be displayed on the screen in real time or logged to files.

1. Press the **On/off** key to display the run screen.
2. Press the **Escape** key to display the main menu screen.




Figure 4.1 Main Menu Screen

3. Use the arrow keys to highlight the **Sensor** selection.
4. Press the **Enter** key to display the sensors enabled screen.




Figure 4.2 Sensors Enabled Screen Before DO Membrane Selection

A black dot to the left of a sensor indicates that sensor is enabled. Sensors with an empty circle are disabled.

Highlight the “DO None” entry as shown above and press **Enter** to display the membrane choice screen. Consult Section 3.4.2 *Membrane Cap Selection* for information on the advantages of each type of membrane material. Blue membrane caps using 2 mil polyethylene (PE) were shipped with your YSI 5563 and are likely to be the best choice for most 556 field applications.




Figure 4.3 Membrane Selection Screen

Highlight the desired membrane choice – in this case, 2 mil PE -- and press Enter to activate your selection with a dot to the left of the screen. Then press **Escape** to return to the Sensor menu that now shows your DO membrane selection.




Figure 4.4 Sensors Enabled Screen After DO Membrane Selection

NOTE: The Temperature sensor cannot be disabled. Most other sensors require temperature compensation for accurate readings. In addition, the conductivity sensor must be activated in order to obtain accurate dissolved oxygen mg/L readings.

- 5.** Use the arrow keys to highlight the sensor you want to change, then press the **Enter** key to enable or disable it.
- 6.** Repeat step 5 for each sensor you want to change.
- 7.** Press the **Escape** key to return to the main menu screen.

5. Report

The Report Setup screen allows the user to select which sample parameters and units the YSI 556 MPS will display on the screen. It does NOT determine which parameters are logged to memory. Refer to Section 4 *Sensors*.

1. Press the **On/off** key to display the run screen.
2. Press the **Escape** key to display the main menu screen.




Figure 5.1 Main Menu

3. Use the arrow keys to highlight the **Report** selection.
4. Press the **Enter** key to display the report setup screen.




Figure 5.2 Report Setup Screen

NOTE: A black dot to the left of a parameter indicates that parameter is selected for display. Parameters with an empty circle will not be displayed.

NOTE: You may have to scroll down past the bottom of the screen to see all the parameters.

5. Use the arrow keys to highlight the parameter you want to change, then press the **Enter** key. If you can't find the parameter you want, even after scrolling down past the bottom of the screen, the sensor used for that parameter is disabled. Refer to Section 4 *Sensors*.
6. If you selected Temperature, Specific Conductivity, Conductivity, Resistance or Total Dissolved Solids, the Units screen will appear.




Figure 5.3 Units Screen

7. Use the arrow keys to select the units desired, then press the **Enter** key to return to the report setup screen.
If you selected Salinity, Dissolved Oxygen %, Dissolved Oxygen mg/L, pH, pH mv or ORP mv, the selection dot will simply toggle on or off.
8. Repeat steps 5 and 6 for each parameter you want to change.

NOTE: All parameters may be enabled at the same time.




Figure 5.4 All Parameters Displayed

9. Press the **Escape** key to return to the Main menu screen.

6. Calibrate

All of the sensors, except temperature, require periodic calibration to assure high performance. You will find specific calibration procedures for all sensors that require calibration in the following sections. If a sensor listed is not installed in your probe module, skip that section and proceed to the next sensor until the calibration is complete.



CAUTION: Reagents that are used to calibrate and check this instrument may be hazardous to your health. Take a moment to review *Appendix D Health and Safety*. Some calibration standard solutions may require special handling.

6.1 Getting Ready to Calibrate

6.1.1 Containers Needed to Calibrate the Probe Module

The transport/calibration cup that comes with your probe module serves as a calibration chamber for all calibrations and minimizes the volume of calibration reagents required.

Instead of the transport/calibration cup, you may use laboratory glassware to perform calibrations. If you do not use the transport/calibration cup that is designed for the probe module, you are cautioned to do the following:

- ✓ Perform all calibrations with the Probe Sensor Guard installed. This protects the sensors from possible physical damage.
- ✓ Use a ring stand and clamp to secure the probe module body to prevent the module from falling over. Most laboratory glassware has convex bottoms.
- ✓ Ensure that all sensors are immersed in calibration solutions. Many of the calibrations factor in readings from other sensors (e.g., temperature sensor). The top vent hole of the conductivity sensor must also be immersed during some calibrations.

6.1.2 Calibration Tips

1. If you use the Transport/Calibration Cup for dissolved oxygen (DO) calibration, make certain to loosen the seal to allow pressure equilibration before calibration. The DO calibration is a water-saturated air calibration.
2. The key to successful calibration is to ensure that the sensors are completely submersed when calibration values are entered. Use recommended volumes when performing calibrations.
3. For maximum accuracy, use a small amount of previously used calibration solution to pre-rinse the probe module. You may wish to save old calibration standards for this purpose.
4. Fill a bucket with ambient temperature water to rinse the probe module between calibration solutions.
5. Have several clean, absorbent paper towels or cotton cloths available to dry the probe module between rinses and calibration solutions. Shake the excess rinse water off of the probe module, especially when the probe sensor guard is installed. Dry off the outside of the probe module and probe sensor guard. Making sure that the probe module is dry reduces carry-over contamination of calibrator solutions and increases the accuracy of the calibration.
6. If you are using laboratory glassware for calibration, you do not need to remove the probe sensor guard to rinse and dry the sensors between calibration solutions. The inaccuracy resulting from simply rinsing the sensor compartment and drying the outside of the guard is minimal.
7. If you are using laboratory glassware, remove the stainless steel weight from the bottom of the probe sensor guard by turning the weight counterclockwise. When the weight is removed, the calibration solutions have access to the sensors without displacing a lot of fluid. This also reduces the amount of liquid that is carried between calibrations.
8. Make certain that port plugs are installed in all ports where sensors are not installed. It is extremely important to keep these electrical connectors dry.

6.1.3 Recommended Volumes

Follow these instructions to use the transport/calibration cup for calibration procedures.

- ✓ Ensure that an o-ring is installed in the o-ring groove of the transport/calibration cup bottom cap, and that the bottom cap is securely tightened.

NOTE: Do not over-tighten as this could cause damage to the threaded portions.

- ✓ Remove the probe sensor guard, if it is installed.
- ✓ Remove the o-ring, if installed, from the probe module and inspect the installed o-ring on the probe module for obvious defects and, if necessary, replace it with the extra o-ring supplied.
- ✓ Some calibrations can be accomplished with the probe module upright or upside down. A separate clamp and stand, such as a ring stand, is required to support the probe module in the inverted position.
- ✓ To calibrate, follow the procedures in the next section, Calibration Procedures. The approximate volumes of the reagents are specified below for both the upright and upside down orientations.
- ✓ When using the Transport/Calibration Cup for dissolved oxygen % saturation calibration, make certain that the vessel is vented to the atmosphere by loosening the bottom cap or cup assembly and that approximately 1/8” of water is present in the cup.

| Sensor to Calibrate | Upright | Upside Down |
|---------------------|---------|-------------|
| Conductivity | 55ml | 55ml |
| pH/ORP | 30ml | 60ml |

Table 6.1 Calibration Volumes

6.2 Calibration Procedures

6.2.1 Accessing the Calibrate Screen

1. Press the **On/off** key to display the run screen.
2. Press the **Escape** key to display the main menu screen.
3. Use the arrow keys to highlight the **Calibrate** selection.




Figure 6.1 Main Menu

4. Press the **Enter** key. The Calibrate screen is displayed.




Figure 6.2 Calibrate Screen

6.2.2 Conductivity Calibration

This procedure calibrates specific conductance (recommended), conductivity and salinity. Calibrating any one option automatically calibrates the other two.

1. Go to the calibrate screen as described in Section 6.2.1 Accessing the Calibrate Screen.
2. Use the arrow keys to highlight the **Conductivity** selection. See Figure 6.2 Calibrate Screen.
3. Press **Enter**. The Conductivity Calibration Selection Screen is displayed.




Figure 6.3 Conductivity Calibration Selection Screen

4. Use the arrow keys to highlight the Specific Conductance selection.
5. Press **Enter**. The Conductivity Calibration Entry Screen is displayed.




Figure 6.4 Conductivity Calibration Entry Screen

6. Place the correct amount of conductivity standard (see Table 6.1 Calibration Volumes) into a clean, dry or pre-rinsed transport/calibration cup.

⚠ WARNING: Calibration reagents may be hazardous to your health. See *Appendix D Health and Safety* for more information.

NOTE: For maximum accuracy, the conductivity standard you choose should be within the same conductivity range as the samples you are preparing to measure. However, we do not recommend using standards less than 1 mS/cm. For example:

- ✓ For fresh water use a 1 mS/cm conductivity standard.
- ✓ For brackish water use a 10 mS/cm conductivity standard.
- ✓ For seawater use a 50 mS/cm conductivity standard.

NOTE: Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the conductivity sensor with a small amount of standard that can be discarded. Be certain that you avoid cross-contamination of solutions. Make certain that there are no salt deposits around the oxygen and pH/ORP sensors, particularly if you are employing standards of low conductivity.

7. Carefully immerse the sensor end of the probe module into the solution.
8. Gently rotate and/or move the probe module up and down to remove any bubbles from the conductivity cell.

NOTE: The sensor must be completely immersed past its vent hole. Using the recommended volumes from Table 6.1 Calibration Volumes, should ensure that the vent hole is covered.

9. Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.

NOTE: Do not overtighten as this could cause damage to the threaded portions.

10. Use the keypad to enter the calibration value of the standard you are using.

NOTE: Be sure to enter the value in **mS/cm at 25°C**.

11. Press **Enter**. The Conductivity Calibration Screen is displayed.




Figure 6.5 Conductivity Calibration Screen

12. Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors

will appear on the screen and will change with time as they stabilize.

13. Observe the reading under Specific Conductance. When the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.




Figure 6.6 Calibrated

14. Press **Enter**. This returns you to the Conductivity Calibrate Selection Screen, See Figure 6.3 Conductivity Calibration Selection Screen.
15. Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.
16. Rinse the probe module and sensors in tap or purified water and dry.

6.2.3 Dissolved Oxygen Calibration

This procedure calibrates dissolved oxygen. Calibrating any one option (% or mg/L) automatically calibrates the other.

1. Go to the calibrate screen as described in Section 6.2.1 *Accessing the Calibrate Screen*.

NOTE: The instrument must be on for at least 20 minutes to polarize the DO sensor before calibrating.

2. Use the arrow keys to highlight the **Dissolved Oxygen** selection. See Figure 6.2 Calibrate Screen.
3. Press **Enter**. The dissolved oxygen calibration screen is displayed.




Figure 6.7 DO Calibration Screen

DO Calibration in % Saturation

1. Use the arrow keys to highlight the DO% selection.
2. Press **Enter**. The DO Barometric Pressure Entry Screen is displayed.




Figure 6.8 DO Barometric Pressure Entry Screen

3. Place approximately 3 mm (1/8 inch) of water in the bottom of the transport/calibration cup.
4. Place the probe module into the transport/calibration cup.

NOTE: Make sure that the DO and temperature sensors are **not** immersed in the water.

5. Engage only 1 or 2 threads of the transport/calibration cup to ensure the DO sensor is vented to the atmosphere.
6. Use the keypad to enter the current local barometric pressure.

NOTE: If the unit has the optional barometer, no entry is required.

NOTE: Barometer readings that appear in meteorological reports are generally corrected to sea level and must be uncorrected before use (refer to Section 10.10 *Calibrate Barometer, Step 2*).

7. Press **Enter**. The DO% saturation calibration screen is displayed.




Figure 6.9 DO Sat Calibration Screen

8. Allow approximately ten minutes for the air in the transport/calibration cup to become water saturated and for

the temperature to equilibrate before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.

- 9.** Observe the reading under DO %. When the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue. See Figure 6.6 Calibrated.
- 10.** Press **Enter**. This returns you to the DO calibration screen, See Figure 6.7 DO Calibration Screen.
- 11.** Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.
- 12.** Rinse the probe module and sensors in tap or purified water and dry.

DO Calibration in mg/L

DO calibration in mg/L is carried out in a water sample which has a known concentration of dissolved oxygen (usually determined by a Winkler titration).

- 1.** Go to the DO calibrate screen as described in Section 6.2.3 *Dissolved Oxygen Calibration*, steps 1 through 3.
- 2.** Use the arrow keys to highlight the **DO mg/L** selection.
- 3.** Press **Enter**. The DO mg/L Entry Screen is displayed.




Figure 6.10 DO mg/L Entry Screen

4. Place the probe module in water with a known DO concentration.
- NOTE:** Be sure to completely immerse all the sensors.
5. Use the keypad to enter the known DO concentration of the water.
 6. Press **Enter**. The Dissolved Oxygen mg/L Calibration Screen is displayed.




Figure 6.11 DO mg/L Calibration Screen

7. Stir the water with a stir bar, or by rapidly moving the probe module, to provide fresh sample to the DO sensor.
8. Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
9. Observe the DO mg/L reading, when the reading is stable (shows no significant change for approximately 30 seconds), press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
10. Press **Enter**. This returns you to the DO calibration screen. See Figure 6.7 DO Calibration Screen.
11. Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.
12. Rinse the probe module and sensors in tap or purified water and dry.

6.2.4 pH Calibration

1. Go to the calibrate screen as described in *Section 6.2.1 Accessing the Calibrate Screen*.
2. Use the arrow keys to highlight the **pH** selection. See Figure 6.2 Calibrate Screen.
3. Press **Enter**. The pH calibration screen is displayed.




Figure 6.12 pH Calibration Screen

- Select the **1-point** option only if you are adjusting a previous calibration. If a 2-point or 3-point calibration has been performed previously, you can adjust the calibration by carrying out a one point calibration. The procedure for this calibration is the same as for a 2-point calibration, but the software will prompt you to select only one pH buffer.
 - Select the **2-point** option to calibrate the pH sensor using only two calibration standards. Use this option if the media being monitored is known to be either basic or acidic. For example, if the pH of a pond is known to vary between 5.5 and 7, a two-point calibration with pH 7 and pH 4 buffers is sufficient. A three point calibration with an additional pH 10 buffer will not increase the accuracy of this measurement since the pH is not within this higher range.
 - Select the **3-point** option to calibrate the pH sensor using three calibration solutions. In this procedure, the pH sensor is calibrated with a pH 7 buffer and two additional buffers. The 3-point calibration method assures maximum accuracy when the pH of the media to be monitored cannot be anticipated. The procedure for this calibration is the same as for a 2-point calibration, but the software will prompt you to select a third pH buffer.
4. Use the arrow keys to highlight the **2-point** selection.
 5. Press **Enter**. The pH Entry Screen is displayed.




Figure 6.13 pH Entry Screen

6. Place the correct amount (see Table 6.1 Calibration Volumes) of pH buffer into a clean, dry or pre-rinsed transport/calibration cup.

⚠ WARNING: Calibration reagents may be hazardous to your health. See *Appendix D Health and Safety* for more information.

NOTE: For maximum accuracy, the pH buffers you choose should be within the same pH range as the water you are preparing to sample.

NOTE: Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the pH sensor with a small amount of buffer that can be discarded. Be certain that you avoid cross-contamination of buffers with other solutions.

7. Carefully immerse the sensor end of the probe module into the solution.
8. Gently rotate and/or move the probe module up and down to remove any bubbles from the pH sensor.

NOTE: The sensor must be completely immersed. Using the recommended volumes from Table 6.1 Calibration Volumes, should ensure that the sensor is covered.

9. Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.

NOTE: Do not overtighten as this could cause damage to the threaded portions.

10. Use the keypad to enter the calibration value of the buffer you are using **at the current temperature**.

NOTE: pH vs. temperature values are printed on the labels of all YSI pH buffers.

11. Press **Enter**. The pH calibration screen is displayed.




Figure 6.14 pH Calibration Screen

12. Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
13. Observe the reading under pH, when the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
14. Press **Enter**. This returns you to the Specified pH Calibration Screen, See Figure 6.13 pH Entry Screen.

15. Rinse the probe module, transport/calibration cup and sensors in tap or purified water and dry.
16. Repeat steps 6 through 13 above using a second pH buffer.
17. Press **Enter**. This returns you to the pH Calibration Screen, See Figure 6.12 pH Calibration Screen.
18. Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.
19. Rinse the probe module and sensors in tap or purified water and dry.

6.2.5 ORP Calibration

1. Go to the calibrate screen as described in Section 6.2.1 *Accessing the Calibrate Screen*.
2. Use the arrow keys to highlight the **ORP** selection. See Figure 6.2 Calibrate Screen.
3. Press **Enter**. The ORP calibration screen is displayed.





Figure 6.15 Specified ORP Calibration Screen

4. Place the correct amount (see Table 6.1 Calibration Volumes) of a known ORP solution (we recommend Zobell solution) into a clean, dry or pre-rinsed transport/calibration cup.

 **WARNING:** Calibration reagents may be hazardous to your health. See *Appendix D Health and Safety* for more information.

NOTE: Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the ORP sensor with a small amount of solution that can be discarded. Be certain that you avoid cross-contamination with other solutions.

5. Carefully immerse the sensor end of the probe module into the solution.
6. Gently rotate and/or move the probe module up and down to remove any bubbles from the ORP sensor.

NOTE: The sensor must be completely immersed. Using the recommended volumes from Table 6.1 Calibration Volumes should ensure that the sensor is covered.

7. Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.

NOTE: Do not overtighten as this could cause damage to the threaded portions.

8. Use the keypad to enter the correct value of the calibration solution you are using at the current temperature. Refer to Table 6.2 Zobel Solution Values.

| Temperature °C | Zobell Solution Value, mV |
|----------------|---------------------------|
| -5 | 270.0 |
| 0 | 263.5 |
| 5 | 257.0 |
| 10 | 250.5 |
| 15 | 244.0 |
| 20 | 237.5 |
| 25 | 231.0 |
| 30 | 224.5 |
| 35 | 218.0 |
| 40 | 211.5 |
| 45 | 205.0 |
| 50 | 198.5 |

Table 6.2 Zobel Solution Values

9. Press **Enter**. The ORP calibration screen is displayed.




Figure 6.16 ORP Calibration Screen

10. Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.

NOTE: Verify that the temperature reading matches the value you used in Table 6.2 Zobel Solution Values.

11. Observe the reading under ORP, when the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
12. Press **Enter**. This returns you to the Calibrate Screen. See Figure 6.2 Calibrate Screen.
13. Rinse the probe module and sensors in tap or purified water and dry.

6.3 Return to Factory Settings

1. Go to the calibrate screen as described in Section 6.2.1 *Accessing the Calibrate Screen*.
2. Use the arrow keys to highlight the **Conductivity** selection. See Figure 6.2 Calibrate Screen.

NOTE: We will use the Conductivity sensor as an example; however, this process will work for any sensor.

3. Press **Enter**. The Conductivity Calibration Selection Screen is displayed. See Figure 6.3 Conductivity Calibration Selection Screen.
4. Use the arrow keys to highlight the **Specific Conductance** selection.
5. Press **Enter**. The Conductivity Calibration Entry Screen is displayed. See Figure 6.4 Conductivity Calibration Entry Screen.
6. Press and hold the **Enter** key down and press the **Escape** key.




Figure 6.17 ORP Calibration Screen

7. Use the arrow keys to highlight the **YES** selection.

CAUTION: This returns a sensor to the factory settings. For example, in selecting to return specific conductance to the factory setting, salinity and conductivity will automatically return to their factory settings.

- 8.** Press **Enter**. This returns you to the Conductivity Calibrate Selection Screen, See Figure 6.3 Conductivity Calibration Selection Screen.
- 9.** Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.

7. Run

The Run screen displays data from the sensors in real-time and allows the user to log sample data to memory for later analysis. Refer to Section 9 *Logging* for details on logging sample data.

7.1 Real-Time Data

NOTE: Before measuring samples you must prepare the probe module (refer to Section 3.4 *Preparing the Probe Module*), attach the probe module to the instrument (refer to Section 3.6 *Instrument/Cable Connection*) and calibrate the sensors (refer to Section 6 *Calibrate*).

1. Press the **On/off** key.

OR select Run from the main menu to display the run screen.




Figure 7.1 Run Screen

2. Make sure the probe sensor guard is installed.
3. Place the probe module in the sample. Be sure to completely immerse all the sensors.
4. Rapidly move the probe module through the sample to provide fresh sample to the DO sensor.
5. Watch the readings on the display until they are stable.

- 6.** Refer to Section 9 *Logging* for instructions on logging sample data.

8. File

The File menu allows the user to view, upload or delete sample data and calibration record files stored in the YSI 556 MPS.

8.1 Accessing the File Screen

1. Press the **On/off** key to display the run screen.
2. Press the **Escape** key to display the main menu screen.




Figure 8.1 Main Menu Screen

3. Use the arrow keys to highlight the **File** selection.
4. Press the **Enter** key. The file screen is displayed.



Figure 8.2 File Screen

8.2 Directory

1. Go to the file screen as described in Section 8.1 *Accessing the File Screen*.
2. Use the arrow keys to highlight the **Directory** selection. See Figure 8.2 File Screen.
3. Press the **Enter** key. The file list screen is displayed.

NOTE: Files are listed in the order in which they are logged to memory. Sample Data files have the file extension **.dat**, while Calibration Record files have the file extension **.glp**.

| Filename | Samples | Bytes |
|----------------|---------|-------|
| RED.dat | 26 | 955 |
| CAT.dat | 63 | 2028 |
| OHIO.dat | 118 | 3623 |
| 00008004.glp | 6 | 130 |

736.8mmHg



01/20/2001 13:57:40  

Figure 8.3 File List Screen

4. Use the arrow keys to highlight a file.
5. Press the **Enter** key. The file details screen is displayed.




Figure 8.4 File Details Screen

6. Press the **Enter** key to view the file data. Refer to Section 8.3 *View File* for details.
7. Press the **Escape** key repeatedly to return to the main menu screen.

8.3 View File

1. Go to the file screen as described in Section 8.1 *Accessing the File Screen*. See Figure 8.2 File Screen.
2. Use the arrow keys to highlight the **View file** selection.
3. Press the **Enter** key. A list of files is displayed. See Figure 8.3 File List Screen.

4. Use the arrow keys to highlight an individual file.

NOTE: You may have to scroll down to see all the files.

5. Press the **Enter** key. The file data is displayed with the file name at the top of the display.

NOTE: If no file name was specified, the data is stored under the default name NONAME1.dat.

| OHIO.dat | | |
|------------|----------|-------|
| Date | Time | Temp |
| m/d/y | hh:mm:ss | C |
| 01/20/2001 | 13:56:13 | 22.54 |
| 01/20/2001 | 13:56:13 | 22.54 |
| 01/20/2001 | 13:56:14 | 22.54 |
| 01/20/2001 | 13:56:14 | 22.54 |
| 01/20/2001 | 13:56:15 | 22.54 |
| 01/20/2001 | 13:56:15 | 22.54 |
| 01/20/2001 | 13:56:16 | 22.54 |
| 01/20/2001 | 13:56:16 | 22.54 |
| 01/20/2001 | 13:56:17 | 22.54 |

736.7mmHg


01/20/2001 13:59:34 

Figure 8.5 File Data Screen

6. Use the arrow keys to scroll horizontally and/or vertically to view all the data.
7. Press the **Escape** key repeatedly to return to the main menu screen.

8.4 Upload to PC

EcoWatch™ for Windows™ must be used as the PC software interface to the YSI 556 MPS. Refer to *Appendix G EcoWatch* for more information. EcoWatch for Windows is available at no cost via a download from the YSI Web Site (www.ysi.com) or by contacting YSI Customer Support. Refer to *Appendix E Customer Service*.

8.4.1 Upload Setup

1. Disconnect the YSI 5563 Probe Module from the YSI 556 MPS instrument.
2. Connect the YSI 556 MPS to a serial (Comm) port of your computer via the 655173 PC Interface cable as shown in the following diagram:






Figure 8.6 Computer/Instrument Interface

- 3.** Open EcoWatch for Windows on your computer.
NOTE: See *Appendix G EcoWatch* for installation instructions.
- 4.** Click on the sonde/probe icon  in the upper toolbar.
- 5.** Set the Comm port number to match the port the YSI 556 MPS is connected to. After this setup procedure, the following screen will be present on your PC monitor:



8.4.2 Uploading a .DAT File

1. Setup the instrument as described in Section 8.4.1 *Upload Setup*.
2. Go to the YSI 556 MPS file screen as described in Section 8.1 *Accessing the File Screen*.
3. Use the arrow keys to highlight the **Upload to PC** selection. See Figure 8.2 File Screen.
4. Press the **Enter** key. The file list screen is displayed. See Figure 8.3 File List Screen.
5. Use the arrow keys to highlight the DAT file that you wish to transfer and press **Enter**, both the YSI 556 MPS and PC displays show the progress of the file transfer.





Figure 8.7 File Transfer Progress Screen

NOTE: After transfer, the file will be located in the C:\ECOWWIN\DATA folder of your PC, designated with a .DAT extension.

6. After the file transfer is complete, close the terminal window (small window on the PC) by clicking on the “X” at its upper right corner.



7. Press the **Escape** key on the YSI 556 MPS repeatedly to return to the main menu screen.

8.4.3 Uploading a Calibration Record (.glp) File

For more information on the calibration record, Refer to *Appendix H Calibration Record Information*.

1. Setup up the instrument as described in Section 8.4.1 *Upload Setup*.
2. Go to the YSI 556 MPS file screen as described in Section 8.1 *Accessing the File Screen*.
3. Use the arrow keys to highlight the **Upload to PC** selection. See Figure 8.2 File Screen.
4. Press the **Enter** key. The file list screen is displayed. See Figure 8.3 File List Screen.
5. Use the arrow keys to highlight the calibration record file that you wish to transfer and press **Enter**.
6. You will then be given a choice of uploading the file in three formats; **Binary, Comma & “” Delimited, and ASCII Text**.

NOTE: The binary format is reserved for future YSI software packages.

7. Choose an option and press **Enter**, both the YSI 556 and PC displays show the progress of the file transfer.

NOTE: After transfer, the file will be located in the C:\ECOWWIN\DATA folder of your PC, designated with the appropriate file extension.

NOTE: To view the Calibration Record data after upload, simply open the .txt file in a general text editor such as Wordpad or Notepad.

8. After the file transfer is complete, close the terminal window (small window on the PC) by clicking on the “X” at its upper right corner.
9. Press the **Escape** key repeatedly to return to the main menu screen.

8.5 File Memory

1. Go to the file screen as described in Section 8.1 *Accessing the File Screen*.
2. Use the arrow keys to highlight the **File memory** selection. See Figure 8.2 File Screen.
3. Press the **Enter** key. The file bytes used screen is displayed.



| File bytes used | |
|---|----------------|
| Directory | 6400 |
| In files | 152832 |
| In deleted files | 0 |
| Free | 1413632 |
| Total | 1572864 |
| <hr/> <div style="display: flex; justify-content: space-between;"> 12/07/2000 16:39:19 737.0mmHg </div> <div style="display: flex; justify-content: space-between;">   </div> | |

Figure 8.8 File Bytes Used Screen

4. The amount of free memory is listed in line 4 of the file bytes used screen.

NOTE: If the amount of free memory is low, it may be time to delete all files (after first uploading all data to a PC). Refer to Section 8.6 *Delete All Files*.

5. Press the **Escape** key repeatedly to return to the main menu screen.

8.6 Delete All Files

NOTE: It is not possible to delete individual files in order to free up memory. The only way to free up memory is to delete ALL files present. Take care to transfer all files to your computer (refer to Section 8.4 *Upload to PC*) before deleting them.

1. Go to the file screen as described in Section 8.1 *Accessing the File Screen*.
2. Use the arrow keys to highlight the **Delete all files** selection. See Figure 8.2 File Screen.
3. Press the **Enter** key. The Delete all Files screen is displayed.




Figure 8.9 Delete All Files Screen

4. Use the arrow keys to highlight the **Delete** selection.
5. Press the **Enter** key.




Figure 8.10 Deleting

The progress of file deletion is displayed in bar graph format.

NOTE: Deleting all files in the directory will not change any information in the site list.

6. Press the **Escape** key repeatedly to return to the main menu screen.

9. Logging

9.1 Accessing the Logging Setup Screen

1. Press the **On/off** key to display the run screen.
2. Press the **Escape** key to display the main menu screen.




Figure 9.1 Main Menu

3. Use the arrow keys to highlight the **Logging setup** selection.
4. Press the **Enter** key. The logging setup screen is displayed.




Figure 9.2 Logging Setup Screen

9.2 Setting Logging Interval

Follow steps below to set the interval for logging a data stream.

NOTE: If you do not specify an interval, the instrument will use a default interval setting of 1 second.

NOTE: It is not necessary to set a logging interval when logging a single sample.

1. Go to the logging setup screen as described in Section 9.1 *Accessing the Logging Setup Screen*.
2. Use the keypad to enter an interval between 1 second and 15 minutes. Refer to Section 2.9 *Keypad Use*.

NOTE: The interval field has hour, minute and second entry fields. Any entry over 15 minutes will change automatically to a 15-minute setting.

3. Press the **Enter** key. The data stream interval is set.
4. Press the **Escape** key repeatedly to return to the main menu screen.

9.3 Storing Barometer Readings

NOTE: The **Store barometer** option is only available on instruments that are equipped with the optional barometer.

1. Go to the logging setup screen as described in Section 9.1 *Accessing the Logging Setup Screen*.
2. Use the arrow keys to highlight the **Store barometer** selection. See Figure 9.2 Logging Setup Screen.
3. Press the **Enter** key until a check mark is entered in the box next to the store barometer selection if you want to log barometric readings.

OR press the **Enter** key until the box next to the barometer selection is empty if you do not want to log barometric readings.




Figure 9.3 Store Barometer

4. Press the **Escape** key repeatedly to return to the main menu screen.

9.4 Creating a Site List

The site list option allows you to define file and site descriptions in the office or laboratory before moving to field logging studies. This is usually more convenient than entering the information at the site and is particularly valuable if you are visiting certain sites on a regular basis. The following section describes how to set up site lists which contain entries designated “Site Descriptions” that will be instantly available to the user in the field to facilitate the logging of data with pre-established naming of files and sites. There are two kinds of **Site Descriptions** available for use in Site lists:

- **Site Descriptions** associated with applications where data from a single site is always logged to a single file. This type is referred to as a “Single-Site Description” and is characterized by two parameters – a file name and a site name. Files logged to YSI 556 MPS memory under a **Single-Site Description** will be characterized primarily by the file name, but will also have the Site name attached, so that it is viewable in either the YSI 556 MPS **File directory** or in EcoWatch for Windows after upload to a PC

- Site Descriptions** associated with applications where data from multiple sites are logged to a single file. This type is referred to as a “Multi-site Description” and is characterized by three parameters – a file name, a site name, and a site number. Files logged to YSI 556 MPS memory under a **Multi-site Description** are characterized by a file name, but not a site name, since multiple sites are involved. However, each data point has a Site Number attached to it so that the user can easily determine the sampling site when viewing the data from the YSI 556 MPS **File** menu or processing the data in EcoWatch for Windows after upload to a PC.




Figure 9.4 Single-Site Descriptions




Figure 9.5 Multiple-Site Descriptions

NOTE: Site lists containing Single Site Descriptions are usually input with the designation **Store Site Number** INACTIVE in the YSI 556 MPS **Logging setup** menu. Thus, no site numbers appear in the first **Site list** example. Conversely, **Site lists** containing **Multi-Site Descriptions** MUST be input with the **Store Site Number** selection ACTIVE as shown in the second example.

To create a site list:

1. Go to the logging setup screen as described in Section 9.1 *Accessing the Logging Setup Screen*.
2. Use the arrow keys to highlight the **Use site list** selection.
3. Press the **Enter** key. A check mark is entered in the box next to the use site list selection *and* two new entries appear on the logging setup screen. See Figure 9.6 Logging Setup Screen.




Figure 9.6 Logging Setup Screen

4. Use the arrow keys to highlight the **Store site number** selection.
5. If you are creating Multi-Site Descriptions (which require that the site **number** be stored in your data files), press the **Enter** key until a check mark appears in the box next to the store site number selection.

OR Press the **Enter** key until the box next to the store site number selection is empty, to create Single-Site Descriptions. The site **name** will be stored in the header of your data files.

6. Use the arrow keys to highlight the **Edit site list** selection.
7. Press the **Enter** key. The edit site list screen is displayed. See Figure 9.7 Edit Site List Screen. The **Filename** field is ready for input.

```

Edit site list
-----
Site list
Filename Site name Site Num
[blacked out]
0

←+▲ or ←+▼ to move a site
←+▶ to insert a site
←+◀ to delete a site
Tip: Leave blank to use the same
filename as the previous site.

-----
01/25/2001 11:42:21 745.3mmHg
[blacked out]

```

Figure 9.7 Edit Site List Screen

8. Use the keypad to enter a filename up to 8 characters in length. Refer to Section 2.9 *Keypad Use*.
 9. Press the **Enter** key. The cursor moves to the right for the entry of a **Site name**.
 10. Use the keypad to enter a site name up to 11 characters in length. Refer to Section 2.9 *Keypad Use*.
- NOTE:** If the store site number selection is *not* checked, skip to Step 13.
11. Press the **Enter** key. The cursor moves to the site number entry position.

- 12.** Use the keypad to enter a site number up to 7 characters in length. Refer to Section 2.9 *Keypad Use*.
- 13.** Press **Enter**. The cursor moves to the next filename entry position.
- 14.** Repeat Steps 8 to 13 until all filenames and sites have been entered.
- 15.** Press **Escape** repeatedly to return to the main menu screen.


9.5 Editing a Site List

- 1.** Go to the logging setup screen as described in Section 9.1 *Accessing the Logging Setup Screen*.
- 2.** Use the arrow keys to highlight the **Edit Site List** selection. See Figure 9.6 Logging Setup Screen.
- 3.** Press the **Enter** key. The edit site list screen is displayed.
- 4.** Edit the site list using the keystrokes described below.

NOTE: Editing the site list will not have any effect on files stored in the instrument memory.

To MOVE a site:
Use the arrow keys to highlight a site. Press the Up or Down arrow key while holding down the Enter key.

To INSERT a site above another site:
Use the arrow keys to highlight the site. Press the Right arrow key while holding down the Enter key. Use keypad to input letters. Refer to Section 2.9 *Keypad Use*.



To DELETE a site:
Use the arrow keys to highlight a site. Press the Left arrow key while holding down the Enter key.

To use the same file name as the previous site: Leave the filename blank.

Figure 9.8 Keystrokes for Editing Site List

9.6 Logging Data Without a Site List

1. Follow Steps 1 through 5 in Section 7.1 Real-Time Data.
2. Use the arrow keys to highlight the **Log one sample** selection on the run screen if only a single sample is being logged.

OR Use the arrow keys to highlight the **Start logging** selection on the run screen if a data stream is being logged.




Figure 9.9 Run Screen

3. Press the **Enter** key. The Enter information screen is displayed.




Figure 9.10 Enter Information Screen

NOTE: The last filename used will be displayed.

4. Use the keypad to enter a file name. Refer to Section 2.9 *Keypad Use*.

NOTE: The instrument will assign a default file name of NONAME if no file name is specified.

5. Press the **Enter** key to input the file name.
6. Use the arrow keys to highlight the **Site description** field in the enter information screen.

NOTE: Entering a Site Description is optional. You may leave the Site Description blank and skip to Step 9.

7. Use the keypad to enter a site description name. Refer to Section 2.9 *Keypad Use*.
8. Press the **Enter** key to input the site description.

NOTE: If you want to change the logging setup, such as sampling interval or storing the barometer reading, use the arrow keys to highlight the **Configure** field, press the **Enter** key, then refer to Section 9.2 *Setting Logging Interval* or 9.3 *Storing Barometer Readings* for details.

9. Use the arrow keys to highlight the **OK** field in the center of the information screen.
10. Press the **Enter** key to start logging.

NOTE: If the parameter mismatch screen is displayed, refer to Section 9.8 *Adding Data to Existing Files*.

11. If a single point is being logged, the header on the run screen changes momentarily from **Menu** to **Sample logged** to confirm that the point was successfully logged. Skip to Step 13.




Figure 9.11 Sample Logged Screen

If a continuous stream of points is being logged, the start logging entry in the run screen changes from **Start logging** to **Stop logging**.




Figure 9.12 Logging Screen

12. At the end of the logging interval, press **Enter** to stop logging.
13. Refer to Section 8.3 *View File* to view the data on the instrument display.

9.7 Logging Data With a Site List

1. If you have not already created a site list, refer to Section 9.4 *Creating a Site List*.
2. Follow Steps 1 through 5 in Section 7.1 Real-Time Data.
3. Use the arrow keys to highlight the **Log one sample** selection on the run screen if only a single sample is being logged.

OR Use the arrow keys to highlight the **Start logging** selection on the run screen if a data stream is being logged. See Figure 9.9 Run Screen.

4. Press the **Enter** key. The Pick a site screen is displayed.




Figure 9.13 Pick a Site Screen

5. Use the arrow keys to highlight the **site** of your choice.

NOTE: If the site of your choice is grayed out in the site list, refer to Section 9.8 *Adding Data to Existing Files*.

NOTE: Refer to Section 9.5 *Editing a Site List* if you want to edit the site list.

6. Press the **Enter** key to start logging.

NOTE: If the parameter mismatch screen is displayed, refer to Section 9.8 *Adding Data to Existing Files*.

7. If a single point is being logged, the header on the run screen changes momentarily from **Menu** to **Sample logged** to confirm that the point was successfully logged. See Figure 9.11 Sample Logged Screen. Skip to Step 9.

If a continuous stream of points is being logged, the start logging entry in the run screen changes from **Start logging** to **Stop logging**. See Figure 9.12 Logging Screen.

8. At the end of the logging interval, press **Enter** to stop logging.
9. Refer to Section 8.3 *View File* to view the data on the instrument display.

9.8 Adding Data to Existing Files

In order to add new data to an existing file, the current logging and sensor setup must be *exactly* the same as when the file was created. The following settings must be the same:

- **Sensors enabled** (refer to Section 4 *Sensors*)
- **Store Barometer** (refer to Section 9.3 *Storing Barometer Readings*)
- **Store Site Number** (refer to Section 9.4 *Creating a Site List*)

If the current logging setup is not exactly the same as when the file was created, a parameter mismatch screen is displayed.




Figure 9.14 Parameter Mismatch Screen

NOTE: The right column shows parameters used when the file was created. The left column shows current parameters.

1. Press the **Down Arrow** key to scroll down and find the mismatch(es).
2. Use the following chart to resolve the mismatch(es).

| Mismatch | Action | Reference |
|---|---------------------------------------|---|
| Sensor(s) missing from left column | Enable the missing sensor(s) | Section 4 <i>Sensors</i> |
| Extra sensor(s) listed in left column | Disable the extra sensor(s) | Section 4 <i>Sensors</i> |
| Barometer missing from left column, but present in right column | Enable the Store Barometer setting | Section 9.3 <i>Storing Barometer Readings</i> |
| Barometer present in left column, but missing from right column | Disable the Store Barometer setting | Section 9.3 <i>Storing Barometer Readings</i> |
| Store Site Number missing from left column, but present in right column | Enable the Store Site Number setting | Section 9.4 <i>Creating a Site List</i> |
| Store Site Number present in left column, but missing from right column | Disable the Store Site Number setting | Section 9.4 <i>Creating a Site List</i> |

- 3.** Return to Section *9.6 Logging Data Without a Site List* or *9.7 Logging Data With a Site List*.

10. System Setup

The YSI 556 MPS has a number of features that are user-selectable or can be configured to meet the user's preferences. Most of these choices are found in the **System setup** menu.

10.1 Accessing the System Setup Screen

1. Press the **On/off** key to display the run screen. See Figure 2.1 Front View of YSI 556 MPS.
2. Press the **Escape** key to display the main menu screen.
3. Use the arrow keys to highlight the **System setup** selection.




Figure 10.1 Main Menu

4. Press the **Enter** key. The system setup screen is displayed.




Figure 10.2 System Setup Screen

NOTE: The first line of the **System setup** menu shows the current software version of your YSI 556 MPS. As software enhancements are introduced, you will be able to upgrade your YSI 556 MPS from the YSI Web site. Refer to Section 11.2 *Upgrading YSI 556 MPS Software* for details.

10.2 Date and Time Setup

1. Go to the system setup screen as described in Section 10.1 *Accessing the System Setup Screen*.
2. Use the arrow keys to highlight the **Date & time** selection on the system setup screen. See Figure 10.2 System Setup Screen.
3. Press **Enter**. The date and time setup screen is displayed.




Figure 10.3 Date Setup Screen

NOTE: A black dot to the left of a date format indicates that format is selected.

4. Use the arrow keys to highlight your desired date format.
5. Press **Enter**.
6. Use the arrow keys to highlight the 4-digit year selection.
7. Press **Enter**. A check mark appears in the check box next to the 4-digit year selection.

NOTE: If unchecked, a 2-digit year is used.

8. Use the arrow keys to highlight the **Date** selection.
9. Press **Enter**. A cursor appears over the first number in the date.
10. Enter the proper number from the keypad for the highlighted date digit. The cursor moves automatically to the next date digit. Refer to Section 2.9 *Keypad Use* for more keypad information.
11. Repeat Step 10 until all date digits are correct.

- 12.** Press **Enter** to input the specified date.
- 13.** Use the arrow keys to highlight the **Time** selection.
- 14.** Press **Enter**. A cursor appears over the first number in the time selection.
- 15.** Enter the proper number from the keypad for the highlighted time digit. The cursor moves automatically to the next time digit.

NOTE: Use military format when entering time. For example, 2:00 PM is entered as 14:00.
- 16.** Repeat Step 15 until all time digits are correct.
- 17.** Press **Enter** to input the correct time.
- 18.** Press the **Escape** key repeatedly to return to the Main menu screen.

10.3 Data Filter

The Data Filter is a software filter that eliminates sensor noise and provides more stable readings.

NOTE: YSI recommends using the default values for the data filter for most field applications.

However, users who are primarily interested in a fast response from their dissolved oxygen sensor should consider a change of the default time constant setting of 8 seconds to one of 2 seconds. This change can be made according to the instructions in Section *10.3.1 Changing the Data Filter Settings* below. The disadvantage of lowering the time constant is that field pH readings may appear somewhat noisy if the cable is in motion.

10.3.1 Changing the Data Filter Settings

- 1.** Go to the system setup screen as described in Section *10.1 Accessing the System Setup Screen*.

2. Use the arrow keys to highlight the **Data filter** selection. See Figure 10.1 Main Menu.
3. Press the **Enter** key. The Data filter setup screen is displayed.




Figure 10.4 Data Filter Screen

4. With Enabled highlighted, press the **Enter** key to Enable or Disable the data filter. A black dot to the left of the selection indicates the data filter is enabled.
5. Use the arrow keys to highlight the **Time constant** field.

NOTE: This value is the time constant in seconds for the software data filter. Increasing the time constant will result in greater filtering of the data, but will also slow down the apparent response of the sensors.
6. Use the keypad to enter a value. The default value is 8 and this value is ideal for most 556 field applications. As described in Section 10.3 *Data Filter* above, users who wish to decrease the response time of the DO readings at the expense of some noise for the pH readings determined concurrently, should change the Time Constant to a value of 2.
7. Press the **Enter** key to enter the time constant.

8. Use the arrow keys to highlight the **Threshold** field.

NOTE: This value determines when the software data filter will engage/disengage, speeding the response to large changes in a reading. When the difference between two consecutive readings is larger than the threshold, then the reading is displayed unfiltered. When the difference between two consecutive readings drops below the threshold, readings will be filtered again.

9. Use the keypad to enter a value. The default value is 0.01.
10. Press the **Enter** key to enter the threshold.
11. Press the **Escape** key repeatedly to return to the Main menu screen.

10.4 Shutoff Time

The YSI 556 MPS shuts off automatically after 30 minutes of inactivity. The shut off time may be changed as described below.

1. Go to the system setup screen as described in Section 10.1 *Accessing the System Setup Screen*.
2. Use the arrow keys to highlight the **Shutoff time** selection on the system setup screen. See Figure 10.2 System Setup Screen.
3. Use the keypad to enter a value from 0 to 60 minutes. The default value is 30.

NOTE: To disable the automatic shutoff feature, enter a zero (0).

4. Press the **Enter** key to enter the correct shutoff time.
5. Press the **Escape** key repeatedly to return to the main menu screen.

10.5 Comma Radix

The user can toggle between a period (default) and comma for the radix mark by selecting this item and pressing the **Enter** key as follows:

1. Go to the system setup screen as described in Section *10.1 Accessing the System Setup Screen*.
2. Use the arrow keys to highlight the **Comma radix** selection on the system setup screen. See Figure 10.2 System Setup Screen.
3. Press the **Enter** key. A check mark appears in the check box next to the comma radix selection indicating that the radix mark is a comma.

10.6 ID

This selection allows you to enter an identification name/number for your YSI 556 MPS. This ID name/number is logged in the header of each file.

1. Go to the system setup screen as described in Section *10.1 Accessing the System Setup Screen*.
2. Use the arrow keys to highlight the **ID** selection. See Figure 10.1 Main Menu.
3. Use the keypad to enter an alphanumeric ID up to 15 characters in length. Refer to Section *2.9 Keypad Use*.
4. Press the **Enter** key to enter the ID.
5. Press the **Escape** key repeatedly to return to the main menu screen.

10.7 GLP Filename

This selection allows you to enter a different filename for the YSI 556 MPS Calibration Record file.

NOTE: The default filename is the “556 PC board Serial Number.glp.”

- 6.** Go to the system setup screen as described in Section *10.1 Accessing the System Setup Screen*.
- 7.** Use the arrow keys to highlight the **GLP Filename** selection. See Figure 10.1 Main Menu.
- 8.** Use the keypad to enter a filename up to 8 characters in length. Refer to Section *2.9 Keypad Use*.
- 9.** Press the **Enter** key to enter the new filename.

Press the **Escape** key repeatedly to return to the main menu screen.

10.8 TDS Constant

This selection allows you to set the constant used to calculate Total Dissolved Solids (TDS). TDS in g/L is calculated by multiplying this constant times the specific conductance in mS/cm.

10.8.1 Changing the TDS Constant

- 1.** Go to the system setup screen as described in Section *10.1 Accessing the System Setup Screen*.
- 2.** Use the arrow keys to highlight the **TDS Constant** selection. See Figure 10.1 Main Menu.
- 3.** Use the keypad to enter a value. Refer to Section *2.9 Keypad Use*. The default value is 0.65.
- 4.** Press the **Enter** key to enter the correct TDS constant.
- 5.** Press the **Escape** key repeatedly to return to the main menu screen.

10.9 Barometer Units

The following information is only for instruments with the barometer option.

1. Go to the system setup screen as described in Section 10.1 *Accessing the System Setup Screen*.
2. Use the arrow keys to highlight the **Barometer units** selection on the system setup screen. See Figure 10.2 System Setup Screen.
3. Press the **Enter** key. The Barometer units screen will appear.




Figure 10.5 Barometer Units Screen

A black dot indicates the currently selected units.

4. Use the arrow keys to highlight your desired barometric unit.
5. Press the **Enter** key to select your choice. A black dot will appear in the circle next to your selected units.
6. Press the **Escape** key repeatedly to return to the main menu screen.

10.10 Calibrate Barometer


The optional barometer has been factory calibrated to provide accurate readings. However, some sensor drift may occur over time, requiring occasional calibration by the user, as follows:

1. Determine your local barometric pressure from an independent laboratory barometer or from your local weather service.
2. If the barometric pressure (BP) reading is from your local weather station, reverse the equation that corrects it to sea level.

NOTE: For this equation to be accurate, the barometric pressure units must be in mm Hg.

$$\text{True BP} = (\text{Corrected BP}) - [2.5 * (\text{Local Altitude}/100)]$$

3. Go to the system setup screen as described in Section 10.1 *Accessing the System Setup Screen*.
4. Use the arrow keys to highlight the **Calibrate barometer** selection on the system setup screen. See Figure 10.2 System Setup Screen.
5. Press the **Enter** key. The Calibrate Barometer screen is displayed.



- 6.** Use the keypad to input the known barometric pressure value as determined in Step 2.
- 7.** Press the **Enter** key. The new barometer reading is displayed as well as the approximate offset from the factory reading.

NOTE: To return the sensor to the factory setting, subtract the offset amount from the current setting and repeat Steps 5 to 7.

- 8.** Press the **Escape** key repeatedly to return to the main menu screen.

11. Maintenance

11.1 Sensor Care and Maintenance

Once the sensors have been properly installed, remember that periodic cleaning and DO membrane changes are required.

11.1.1 DO Sensor

For best results, we recommend that the KCl solution and the membrane cap be changed at least once every 30 days.

1. It is important to recognize that oxygen dissolved in the sample is consumed during sensor operation. It is therefore essential that the sample be continuously stirred at the sensor tip. If stagnation occurs, your readings will be artificially low. Stirring may be accomplished by mechanically moving the sample around the sensor tip, or by rapidly moving the sensor through the sample. The rate of stirring should be at least 1 foot per second.
2. Membrane life depends on usage. Membranes will last a long time if installed properly and treated with care. Erratic readings are a result of loose, wrinkled, damaged, or fouled membranes, or from large (more than 1/8" diameter) bubbles in the electrolyte reservoir. If erratic readings or evidence of membrane damage occurs, you should replace the membrane and the electrolyte solution. The average replacement interval is two to four weeks.
3. If the membrane is coated with oxygen consuming (e.g. bacteria) or oxygen producing organisms (e.g. algae), erroneous readings may occur.
4. Chlorine, sulfur dioxide, nitric oxide, and nitrous oxide can affect readings by behaving like oxygen at the sensor. If you suspect erroneous readings, it may be necessary to determine if these gases are the cause.
5. Avoid any environment that contains substances that may attack the probe module and sensor materials. Some of these substances are concentrated acids, caustics, and strong

solvents. The sensor materials that come in contact with the sample include FEP Teflon, acrylic plastic, EPR rubber, stainless steel, epoxy, polyetherimide and the PVC cable covering.

6. It is possible for the silver anode, which is the entire silver body of the sensor, to become contaminated. This will prevent successful calibration. To restore the anode, refer to Section *11.1.1 DO Sensor, Silver Anode Cleaning*.
7. For correct sensor operation, the gold cathode must always be bright. If it is tarnished (which can result from contact with certain gases), or plated with silver (which can result from extended use with a loose or wrinkled membrane), the gold surface must be restored. To restore the cathode, refer to Section *11.1.1 DO Sensor, Gold Cathode Cleaning*.
8. To keep the electrolyte from drying out, store the sensor in the transport/calibration cup with at least 1/8" of water.

Silver Anode Cleaning

After extended use, a thick layer of AgCl builds up on the silver anode reducing the sensitivity of the sensor. The anode must be cleaned to remove this layer and restore proper performance. The cleaning can be chemical or mechanical:

Chemical Cleaning: Remove the membrane cap and soak the entire anode section in a 14% ammonium hydroxide solution for 2 to 3 minutes, followed by a thorough rinsing with distilled or deionized water. The anode should then be thoroughly wiped with a wet paper towel to remove the residual layer from the anode.

Mechanical Cleaning: Sand off the dark layer from the silver anode with 400 grit wet/dry sandpaper. Wrap the sandpaper around the anode and twist the sensor. Rinse the anode with clean water after sanding, followed by wiping thoroughly with a wet paper towel.

NOTE: After cleaning, a new membrane cap must be installed. Refer to Section *3.4.3 Membrane Cap Installation*.

Turn the instrument on and allow the system to stabilize for at least 30 minutes. If, after several hours, you are still unable to calibrate, contact your dealer or YSI Customer Service. Refer to *Appendix E Customer Service*.

Gold Cathode Cleaning

For correct sensor operation, the gold cathode must be textured properly. It can become tarnished or plated with silver after extended use. The gold cathode can be cleaned by using the adhesive backed sanding disc and tool provided in the YSI 5238 Probe Reconditioning Kit.

Using the sanding paper provided in the YSI 5238 Probe Reconditioning Kit, wet sand the gold with a twisting motion about 3 times or until all silver deposits are removed and the gold appears to have a matte finish. Rinse the cathode with clean water after sanding, followed by wiping thoroughly with a wet paper towel. If the cathode remains tarnished, contact your dealer or YSI Customer Service. Refer to *Appendix E Customer Service*.

NOTE: After cleaning, a new membrane cap must be installed. Refer to Section 3.4.3 *Membrane Cap Installation*.

11.1.2 DO Sensor Replacement

1. Remove the probe sensor guard.



CAUTION: Thoroughly dry the sensor so that no water enters the probe module sensor port when the sensor is removed.

2. Insert the long end of the hex key wrench into the small hole in the side of the probe module bulkhead. Turn the wrench counterclockwise and remove the screw. (You do not have to remove the screw all the way to release the sensor.)
3. Pull the old DO sensor module straight out of the probe module body.

NOTE: The DO sensor is not threaded, it is keyed, so it cannot be removed by twisting.




Figure 11.1 DO Sensor Replacement

4. Insert the new DO sensor module. Make sure that the inside of the probe module sensor port and the o-ring on the sensor are clean, with no contaminants, such as grease, dirt, or hair. The DO sensor is keyed, or has a flat side, so that it cannot be aligned improperly.

NOTE: Make sure the DO sensor bottoms out before the set screw is inserted.

5. Insert the set screw into the small hole in the side of the probe module bulkhead, and turn clockwise to rethread.

⚠ CAUTION: Make sure that you do not cross-thread the set screw. Use the hex key wrench to tighten the screw in properly, making sure that the screw does not stick out of the side of the probe module bulkhead. The probe sensor guard will not thread


on properly and damage may result if the screw is allowed to stick out.

NOTE: The YSI 5563 DO sensor is shipped dry. A shipping membrane was installed to protect the electrode. A new membrane cap must be installed before the first use. Refer to Section 3.4.1 *Sensor Installation*.

11.1.3 YSI 5564 pH and 5565 Combination pH/ORP Sensor Cleaning

Cleaning is required whenever deposits or contaminants appear on the glass and/or platinum surfaces of these sensors or when the response of the sensor becomes slow.

1. Remove the sensor from the probe module.
2. Initially, simply use clean water and a soft clean cloth, lens cleaning tissue, or cotton swab to remove all foreign material from the glass bulb (YSI 5564 and YSI 5565) and platinum button (YSI 5565). Then use a moistened cotton swab to carefully remove any material that may be blocking the reference electrode junction of the sensor.

 **CAUTION:** When using a cotton swab with the YSI 5564 or YSI 5565, be careful NOT to wedge the swab tip between the guard and the glass sensor. If necessary, remove cotton from the swab tip, so that the cotton can reach all parts of the sensor tip without stress.

NOTE: If good pH and/or ORP response is not restored by the above procedure, perform the following additional procedure:

1. Soak the sensor for 10-15 minutes in clean water containing a few drops of commercial dishwashing liquid.
2. GENTLY clean the glass bulb and platinum button by rubbing with a cotton swab soaked in the cleaning solution.
3. Rinse the sensor in clean water, wipe with a cotton swab saturated with clean water, and then re-rinse with clean water.

NOTE: If good pH and/or ORP response is still not restored by the above procedure, perform the following additional procedure:

- 1.** Soak the sensor for 30-60 minutes in one molar (1 M) hydrochloric acid (HCl). This reagent can be purchased from most distributors. Be sure to follow the safety instructions included with the acid.
- 2.** GENTLY clean the glass bulb and platinum button by rubbing with a cotton swab soaked in the acid.
- 3.** Rinse the sensor in clean water, wipe with a cotton swab saturated with clean water, and then re-rinse with clean water. To be certain that all traces of the acid are removed from the sensor crevices, soak the sensor in clean water for about an hour with occasional stirring.

NOTE: If biological contamination of the reference junction is suspected or if good response is not restored by the above procedures, perform the following additional cleaning step:

- 1.** Soak the sensor for approximately 1 hour in a 1 to 1 dilution of commercially available chlorine bleach.
- 2.** Rinse the sensor with clean water and then soak for at least 1 hour in clean water with occasional stirring to remove residual bleach from the junction. (If possible, soak the sensor for period of time longer than 1 hour in order to be certain that all traces of chlorine bleach are removed.) Then re-rinse the sensor with clean water and retest.

11.1.4 Temperature/Conductivity Sensor Cleaning

The single most important requirement for accurate and reproducible results in conductivity measurement is a clean cell. A dirty cell will change the conductivity of a solution by contaminating it. The small cleaning brush included in the YSI 5511 Maintenance Kit is ideal for this purpose.

To clean the conductivity cell:

1. Dip the brush in clean water and insert it into each hole 15-20 times.
2. Rinse the cell thoroughly in deionized or clean tap water.

NOTE: In the event that deposits have formed on the electrodes, perform the following additional procedure:

1. Use a mild detergent solution in combination with the brush. Dip the brush in the solution and insert it into each hole 15-20 times.
2. Rinse the cell thoroughly in deionized or clean tap water.

NOTE: After cleaning, check the response and accuracy of the conductivity cell with a calibration standard.


NOTE: If this procedure is unsuccessful, or if sensor performance is impaired, it may be necessary to return the sensor to a YSI authorized service center for service. Refer to *Appendix E Customer Service*.

The temperature portion of the sensor requires no maintenance.

11.2 Upgrading YSI 556 MPS Software


1. Access the YSI Environmental Software Downloads page as described in *Appendix G EcoWatch* Step 1 through 3.
2. Click on the **YSI Instruments Software Updates** link (or scroll down until you see YSI 556 MPS).
3. Click on the file icon to the right of the **YSI 556 MPS** listing and save the file to a temporary directory on your computer.
4. After the download is complete, run the file (that you just downloaded) and follow the on screen instructions to install the YSI Code Updater on your computer. If you encounter difficulties, contact YSI customer service for advice. Refer to *Appendix E Customer Service*.

5. If necessary, disconnect the YSI 5563 Probe Module from the YSI 556 MPS instrument.
6. Connect the YSI 556 MPS to a serial port of your computer via the 655173 PC interface cable. See Figure 8.6 Computer/Instrument Interface.
7. Press the **On/off** key on the YSI 556 MPS to display the run screen.
8. Run the YSI Code Updater software that you just installed on your computer. The following window will be displayed:




9. Set the Comm port number to match the port that you connected the 655173 PC Interface Cable to, then click on the **Start Code Update** button.

The YSI 556 MPS screen will blank out and a progress indicator will be displayed on the PC.



When the update is finished (indicated on the PC screen), the YSI 556 MPS will return to the Run screen. See Figure 7.1 Run Screen.



- 10.** Close the YSI Code Updater window (on the PC) by clicking on the "X" in the upper right corner of the window.

- 11.** Disconnect the YSI 556 MPS from the 655173 PC interface cable and reconnect it to the YSI 5563 Probe Module. Refer to Section 3.6 *Instrument/Cable Connection*.

12. Storage

Proper storage between periods of usage will not only extend the life of the sensors, but will also ensure that the unit will be ready to use as quickly as possible in your next application.

12.1 General Recommendations for Short Term Storage

No matter what sensors are installed in the instrument, it is important to keep them moist without actually immersing them in liquid. Immersing them could cause some of them to drift or result in a shorter lifetime.

YSI recommends that short term storage of all multi-parameter instruments be done by placing approximately 1/2 inch of tap water in the transport/calibration cup that was supplied with the instrument, and by placing the probe module with all of the sensors installed into the cup. The use of a moist sponge instead of a 1/2 inch of tap water is also acceptable, as long as its presence does not compromise the attachment of the cup to the probe module. The transport/calibration cup should be sealed to prevent evaporation.

NOTE: Ensure that an o-ring is installed in the o-ring groove on the threaded end of the probe module body. See Figure 3.7 Transport/Calibration Cup Installation.



CAUTION: The water level has to be low enough so that none of the sensors are actually under water. Check the transport/calibration cup periodically to make certain that the water is still present or the sponge is still moist.

NOTE: If the storage water (tap water) is accidentally lost during field use, environmental water can be used.


12.2 General Recommendations for Long Term Storage

12.2.1 Probe Module Storage

1. Remove the pH or pH/ORP sensor from the probe module and store according to the individual sensor storage instructions found in Section *12.2.2 Sensor Storage*.
2. Seal the empty port with the provided port plug.

NOTE: Leave the conductivity/temperature sensor and dissolved oxygen sensor, with membrane cap still on, in the probe module.

3. Place 1/2" of water, deionized, distilled or tap, in the transport/calibration cup.

 **CAUTION:** The water level has to be low enough so that none of the sensors are actually under water. Check the transport/calibration cup periodically to make certain that the water is still present or the sponge is still moist.

4. Insert the probe module into the cup.

NOTE: Ensure that an o-ring is installed in the o-ring groove on the threaded end of the probe module body. See Figure 3.7 Transport/Calibration Cup Installation.

12.2.2 Sensor Storage

Temperature/Conductivity Sensor

No special precautions are required. Sensor can be stored dry or wet, as long as solutions in contact with the thermistor and conductivity electrodes are not corrosive (for example, chlorine bleach). However, it is recommended that the sensor be cleaned with the provided brush prior to long term storage. Refer to Section 11.1.4 *Temperature/Conductivity Sensor Cleaning*.

pH and Combination pH/ORP Sensor

The key to sensor storage is to make certain that the reference electrode junction does not dry out. Junctions which have been allowed to dry out due to improper storage procedures can usually be rehydrated by soaking the sensor for several hours (overnight is recommended) in a solution which is 2 molar in potassium chloride. If potassium chloride solution is not available, soaking the sensor in tap water or commercial pH buffers may restore sensor function. However in some cases the sensor may have been irreparably damaged by the dehydration and will require replacement.



CAUTION: Do not store the sensor in distilled or deionized water as the glass sensor may be damaged by exposure to this medium.


- 1.** Remove the pH or pH/ORP sensor from the probe module.
- 2.** Seal the empty port with the provided port plug.
- 3.** Place the sensor in the storage vessel (plastic boot or bottle) which was on the sensor at delivery. The vessel should contain a solution which is 2 molar in potassium chloride.

NOTE: Make certain that the vessel is sealed to prevent evaporation of the storage solution.

13. Troubleshooting

The following sections describe problems you may encounter when using the YSI 556 MPS and provides suggestions to overcome the symptom.

| PROBLEM | POSSIBLE SOLUTION |
|--|---|
| Display Problems | |
| No display is visible after pressing the on/off key. | If C cells are used, make certain that they are installed properly with regard to polarity and that good batteries are used. If a rechargeable battery pack is used, place the pack in the instrument and charge for 30 minutes. |
| Instrument software appears to be locked up as evidenced by no response to keypad entries or display not changing. | First, attempt to reset the instrument by simply turning off and then on again. If this fails, remove battery power from the instrument for 30 seconds and then reapply power. When using C cells, remove the battery lid and one of the batteries; when using the rechargeable battery pack, remove the pack completely from the instrument. After 30 seconds replace the battery or battery pack and check for instrument function. |
| The 556 display flashes and the instrument speaker makes a continuous clicking sound. | The battery voltage is low. Change to new C cells or recharge the 6117 battery pack. |
| Water Damage to Instrument | |
| Leakage detected in battery compartment when using C cells | Dispose of batteries properly. Dry the battery compartment using compressed air if possible. If corrosion is present on battery terminals, contact YSI Customer Service. |
| Water has contacted rechargeable battery pack | Remove battery pack immediately. Send battery pack to YSI Product Service for evaluation. CAUTION: DO NOT REUSE BATTERY PACK UNTIL YSI PRODUCT SERVICE HAS EVALUATED IT. |
| Leakage suspected into the main cavity of the instrument case | Remove the batteries immediately. Return the instrument to YSI Product Service. |

| PROBLEM | POSSIBLE SOLUTION |
|---|---|
| Optional Cigarette Lighter Charger | |
| <p>Power cord fuse blown</p>  <p>The diagram shows a cylindrical adapter with a cap on one end and a power cord on the other. A fuse is located inside the adapter. Labels include: Adapter Cap, Power Cord Adapter Body, Fuse, 5.5mm, 2.1mm, and (Positive Tip). A small diagram below shows a positive terminal (+) and a negative terminal (-).</p> | <ol style="list-style-type: none"> 1. Unscrew adapter’s cap, remove tip and pull out fuse. 2. Replace fuse with a new 2-amp fast-blow fuse from an electronics store such as Radio Shack. 3. Reassemble the adapter and securely screw the cap back onto the adapter body. |
| File Problems | |
| <p>Upload of files from YSI 556 MPS to PC fails</p> | <ol style="list-style-type: none"> 1. Make sure that cable is connected properly to both 556 and PC. 2. Make certain that the proper Comm port is selected in EcoWatch for Windows. |
| <p>Barometer data is not stored with sensor data file.</p> | <p>Make sure Store barometer is active in the 556 Logging setup menu.</p> |
| <p>Site Descriptions in the Site List are “grayed-out” and not available for appending files with additional data.</p> | <p>There is a parameter mismatch between the current 556 setup and that initially used. Change the current logging and sensor setup to match the setup that was initially used to create the file.</p> |
| Sensor Problems | |
| <p>Dissolved Oxygen reading unstable or inaccurate. Out of Range message appears during calibration.</p> | <p>Sensor not properly calibrated. Follow DO cal procedures.</p> |
| | <p>Membrane not properly installed or may be punctured. Replace membrane cap.</p> |
| | <p>DO sensor electrodes require cleaning. Follow DO cleaning procedure. Use 5511 Maintenance kit.</p> |
| | <p>Water in sensor connector. Dry connector; reinstall sensor.</p> |
| | <p>Algae or other contaminant clinging to DO sensor. Rinse DO sensor with clean water.</p> |
| | <p>Barometric pressure entry is incorrect. Repeat DO cal procedure.</p> |
| | <p>Calibrated at extreme temperature. Recalibrate at (or near) sample temperature.</p> |
| | <p>DO sensor has been damaged. Replace sensor.</p> <p>Internal failure. Return probe module for service.</p> |

| PROBLEM | POSSIBLE SOLUTION |
|---|--|
| Sensor Problems | |
| pH or ORP readings are unstable or inaccurate. Out of Range message appears during calibration. | Sensor requires cleaning. Follow sensor cleaning procedure. |
| | Sensor requires calibration. Follow cal procedures. |
| | pH sensor reference junction has dried out from improper storage. Soak sensor in tap water or buffer until readings become stable. |
| | Water in sensor connector. Dry connector; reinstall sensor. |
| | Sensor has been damaged. Replace sensor. |
| | Calibration solutions out of spec or contaminated with other solution. Use new calibration solutions. |
| | ORP fails Zobell check. Take into account temperature dependence of Zobell solution readings. |
| | Internal failure. Return probe module for service. |
| Conductivity unstable or inaccurate. Out of Range message appears during calibration. | Conductivity improperly calibrated. Follow calibration procedure. |
| | Conductivity sensor requires cleaning. Follow cleaning procedure. |
| | Conductivity sensor damaged. Replace sensor. |
| | Calibration solution out of spec or contaminated. Use new calibration solution. |
| | Internal failure. Return probe module for service. |
| | Calibration solution or sample does not cover entire sensor. Immerse sensor fully. |
| Temperature, unstable or inaccurate | Water in connector. Dry connector; reinstall sensor. |
| | Sensor has been damaged. Replace the 5560 sensor. |
| Installed sensor has no reading | The sensor has been disabled. Enable sensor. |
| | Water in sensor connector. Dry connector; reinstall sensor. |
| | Sensor has been damaged. Replace the sensor. |
| | Report output improperly set up. Set up report output. |
| | Internal failure. Return probe module for service. |

If these guidelines and tips fail to correct your problem or if any other symptoms occur, contact YSI Customer Service for Advice. Refer to *Appendix E Customer Service*.

14. Appendix A YSI 556 MPS Specifications

14.1 Sensor Specifications

| Dissolved Oxygen | |
|--|--|
| Sensor Type | Steady state polarographic |
| Range: % air sat'n mg/L | <ul style="list-style-type: none"> ▪ 0 to 500% air saturation ▪ 0 to 50 mg/L |
| Accuracy: % air sat'n mg/L | <ul style="list-style-type: none"> ▪ 0 to 200% air saturation: ±2% of the reading or 2% air saturation; whichever is greater ▪ 200 to 500% air saturation: ±6% of the reading ▪ 0 to 20 mg/L: ±2% of the reading or 0.2 mg/L; whichever is greater ▪ 20 to 50 mg/L: ±6% of the reading |
| Resolution: % air sat'n mg/L | <ul style="list-style-type: none"> ▪ 0.1% air saturation ▪ 0.01 mg/L |
| Temperature | |
| Sensor Type: | YSI Precision™ thermistor |
| Range: | -5 to 45°C |
| Accuracy: | ±0.15°C |
| Resolution: | 0.01°C |
| Conductivity | |
| Sensor Type: | 4-electrode cell with auto-ranging |
| Range: | 0 to 200 mS/cm |
| Accuracy: | ±0.5% of reading or ±0.001 mS/cm; whichever is greater—4 meter cable ±1.0% of reading or ±0.001 mS/cm; whichever is greater—20 meter cable |
| Resolution: | 0.001 mS/cm to 0.1 mS/cm (range-dependent) |
| Salinity | |
| Sensor Type: | Calculated from conductivity and temperature |
| Range: | 0 to 70 ppt |
| Accuracy: | ±1.0% of reading or 0.1 ppt; whichever is greater |
| Resolution: | 0.01 ppt |



| <i>pH (optional)</i> | |
|------------------------------|-----------------------------|
| Sensor Type: | Glass combination electrode |
| Range: | 0 to 14 units |
| Accuracy: | ±0.2 units |
| Resolution: | 0.01 units |
| <i>ORP (optional)</i> | |
| ORP Sensor Type: | Platinum button |
| Range: | -999 to +999 mV |
| Accuracy: | ±20 mV |
| Resolution: | 0.1 mV |

| <i>Barometer (optional)</i> | |
|------------------------------------|--|
| Range: | 500 to 800 mm Hg |
| Accuracy: | ±3 mm Hg within ±15°C temperature range from calibration point |
| Resolution: | 0.1 mm Hg |

14.2 Instrument Specifications

| | |
|-------------------------------|---|
| Memory Size: | 1.5 MB Flash Memory 49,000 data sets (@ 6 parameters per set plus time stamp) 100 Sites |
| Size: | 11.9 cm width x 22.9 cm length (4.7 in. x 9 in.) |
| Weight with batteries: | 0.92 kg (2.1 lbs) |
| Power: | 4 alkaline C-cells; optional rechargeable pack |
| Cables: | 4, 10, and 20 m (13.1, 32.8, 65.6 ft.) lengths |
| Warranty: | 3-Years for the instrument; 1-Year for the probe modules and cable |

15. Appendix B Instrument Accessories

| ITEM # | ACCESSORY |
|---------|--|
| 5563-4 | 4m Cable with DO/temp/conductivity |
| 5563-10 | 10m Cable with DO/temp/conductivity |
| 5563-20 | 20m Cable with DO/temp/conductivity |
| 5564 | pH Kit |
| 5565 | pH/ORP Kit |
| 6118 | Rechargeable Battery Pack Kit for use in US |
| 5094 | Rechargeable Battery Pack Kit with universal charger and three adapter cables for use in international applications  |
| 5095 | Rechargeable Battery Pack Kit with universal charger and two adapter cables for use in international applications  |
| 5083 | Flow Cell – probe module is secured in the flow cell and groundwater is pumped through it |
| 616 | Charger, Cigarette Lighter – used to power up the instrument from a car's cigarette lighter |
| 4654 | Tripod |
| 614 | Ultra Clamp, C Clamp –used to clamp the instrument to a table top or car dashboard |
| 6081 | Large Carrying Case, Hard-sided |
| 5085 | Hands-free Harness |
| 5065 | Carrying Case, Form-fitted, for use in the field – has a clear vinyl window, shoulder strap, belt loop strap and hand strap |

16. Appendix C Required Federal Communications Notice

The Federal Communications Commission defines this product as a computing device and requires the following notice.

This equipment generates and uses radio frequency energy and if not installed and used properly, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class A or Class B computing device in accordance with the specification in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna
- Relocate the computer with respect to the receiver
- Move the computer away from the receiver
- Plug the computer into a different outlet so that the computer and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet, prepared by the Federal Communications Commission, helpful: "How to Identify and Resolve Radio-TV Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402, Stock No.0004-000-00345-4.

17. Appendix D Health and Safety

YSI Conductivity solutions: 3161, 3163, 3165, 3167, 3168, 3169

INGREDIENTS:

- Iodine
- Potassium Chloride
- Water

WARNING: INHALATION MAY BE FATAL.

 **CAUTION: AVOID INHALATION, SKIN CONTACT, EYE CONTACT OR INGESTION. MAY EVOLVE TOXIC FUMES IN FIRE.**

Harmful if ingested or inhaled. Skin or eye contact may cause irritation. Has a corrosive effect on the gastro-intestinal tract, causing abdominal pain, vomiting, and diarrhea. Hyper-sensitivity may cause conjunctivitis, bronchitis, skin rashes etc. Evidence of reproductive effects.

FIRST AID:

INHALATION: Remove victim from exposure area. Keep victim warm and at rest. In severe cases seek medical attention.

SKIN CONTACT: Remove contaminated clothing immediately. Wash affected area thoroughly with large amounts of water. In severe cases seek medical attention.

EYE CONTACT: Wash eyes immediately with large amounts of water, (approx. 10 minutes). Seek medical attention immediately.

INGESTION: Wash out mouth thoroughly with large amounts of water and give plenty of water to drink. Seek medical attention immediately.

YSI pH 4.00, 7.00, and 10.00 Buffer Solutions: 3821, 3822, 3823**pH 4 INGREDIENTS:**

- Potassium Hydrogen Phthalate
- Formaldehyde
- Water

pH 7 INGREDIENTS:

- Sodium Phosphate, Dibasic
- Potassium Phosphate, Monobasic
- Water

pH 10 INGREDIENTS:

- Potassium Borate, Tetra
- Potassium Carbonate
- Potassium Hydroxide
- Sodium (di) Ethylenediamine Tetraacetate
- Water



CAUTION - AVOID INHALATION, SKIN CONTACT, EYE CONTACT OR INGESTION. MAY AFFECT MUCOUS MEMBRANES.

Inhalation may cause severe irritation and be harmful. Skin contact may cause irritation; prolonged or repeated exposure may cause Dermatitis. Eye contact may cause irritation or conjunctivitis. Ingestion may cause nausea, vomiting and diarrhea.

FIRST AID:

INHALATION - Remove victim from exposure area to fresh air immediately. If breathing has stopped, give artificial respiration. Keep victim warm and at rest. Seek medical attention immediately.

SKIN CONTACT - Remove contaminated clothing immediately. Wash affected area with soap or mild detergent and large amounts of water (approx. 15-20 minutes). Seek medical attention immediately.

EYE CONTACT - Wash eyes immediately with large amounts of water (approx. 15-20 minutes), occasionally lifting upper and lower lids. Seek medical attention immediately.

INGESTION - If victim is conscious, immediately give 2 to 4 glasses of water and induce vomiting by touching finger to back of throat. Seek medical attention immediately.

YSI Zobell Solution: 3682**INGREDIENTS:**

- Potassium Chloride
- Potassium Ferrocyanide Trihydrate
- Potassium Ferricyanide



CAUTION - AVOID INHALATION, SKIN CONTACT, EYE CONTACT OR INGESTION. MAY AFFECT MUCOUS MEMBRANES.

May be harmful by inhalation, ingestion, or skin absorption. Causes eye and skin irritation. Material is irritating to mucous membranes and upper respiratory tract. The chemical, physical, and toxicological properties have not been thoroughly investigated.

Ingestion of large quantities can cause weakness, gastrointestinal irritation and circulatory disturbances.

FIRST AID:

INHALATION - Remove victim from exposure area to fresh air immediately. If breathing has stopped, give artificial respiration. Keep victim warm and at rest. Seek medical attention immediately.

SKIN CONTACT - Remove contaminated clothing immediately. Wash affected area with soap or mild detergent and large amounts of water (approx. 15-20 minutes). Seek medical attention immediately.

EYE CONTACT - Wash eyes immediately with large amounts of water (approx. 15-20 minutes), occasionally lifting upper and lower lids. Seek medical attention immediately.

INGESTION - If victim is conscious, immediately give 2 to 4 glasses of water and induce vomiting by touching finger to back of throat. Seek medical attention immediately.

18. Appendix E Customer Service

For information on Authorized Service Centers, refer to *Authorized Service Centers* in this appendix.

Equipment exposed to biological, radioactive, or toxic materials must be cleaned and disinfected before being returned or presented for service. A cleaning certificate must accompany the equipment. Refer to *18.2 Cleaning Instructions* in this appendix.

18.1 YSI Environmental Authorized Service Centers

For information on the nearest authorized service center, please contact:

YSI Technical Support • 1725 Brannum Lane
Yellow Springs, Ohio • 45387 • Phone: +1 (937) 767-7241
Phone: 800-897-4151 (US) • Email: environmental@ysi.com

or visit our website for the most current information:

www.ysi.com

18.2 Cleaning Instructions

Equipment exposed to biological, radioactive, or toxic materials must be cleaned and disinfected before being serviced.

Biological contamination is presumed for any instrument, probe, or other device that has been used with body fluids or tissues, or with wastewater. Radioactive contamination is presumed for any instrument, probe or other device that has been used near any radioactive source.

If an instrument, probe, or other part is returned or presented for service without a Cleaning Certificate, and if in our opinion it represents a potential biological or radioactive hazard, our service personnel reserve the right to withhold service until appropriate cleaning, decontamination, and certification has been completed. We will contact the sender for instructions as to the disposition of the equipment. Disposition costs will be the responsibility of the sender.

When service is required, either at the user's facility or at a YSI Service Center, the following steps must be taken to ensure the safety of service personnel.

- In a manner appropriate to each device, decontaminate all exposed surfaces, including any containers. 70% isopropyl alcohol or a solution of 1/4-cup bleach to 1-gallon tap water is suitable for most disinfecting. Instruments used with wastewater may be disinfected with .5% Lysol if this is more convenient to the user.
- The user shall take normal precautions to prevent radioactive contamination and must use appropriate decontamination procedures should exposure occur.
- If exposure has occurred, the customer must certify that decontamination has been accomplished and that no radioactivity is detectable by survey equipment.
- Any product being returned to the YSI Repair Center should be packed securely to prevent damage.
- Cleaning must be completed and certified on any product before returning it to YSI.

18.5 Warranty

The instrument is warranted for three years against defects in workmanship and materials when used for its intended purposes and maintained according to instructions. The probe module and cables are warranted for one year. The dissolved oxygen, temperature/conductivity, pH, and pH/ORP combination sensors are warranted for one year. Damage due to accidents, misuse, tampering, or failure to perform prescribed maintenance is not covered. The warranty period for chemicals and reagents is determined by the expiration date printed on their labels. Within the warranty period, YSI will repair or replace, at its sole discretion, free of charge, any product that YSI determines to be covered by this warranty.

To exercise this warranty, write or call your local YSI representative, or contact YSI Customer Service in Yellow Springs, Ohio. Send the product and proof of purchase, transportation prepaid, to the Authorized Service Center selected by YSI. Repair or replacement will be made and the product returned transportation prepaid. Repaired or replaced products are warranted for the balance of the original warranty period, or at least 90 days from date of repair or replacement.

Limitation of Warranty

This Warranty does not apply to any YSI product damage or failure caused by (i) failure to install, operate or use the product in accordance with YSI's written instructions, (ii) abuse or misuse of the product, (iii) failure to maintain the product in accordance with YSI's written instructions or standard industry procedure, (iv) any improper repairs to the product, (v) use by you of defective or improper components or parts in servicing or repairing the product, or (vi) modification of the product in any way not expressly authorized by YSI.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. YSI'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT OF THE PRODUCT, AND THIS SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY DEFECTIVE PRODUCT COVERED BY THIS WARRANTY. IN NO EVENT SHALL YSI BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY DEFECTIVE PRODUCT COVERED BY THIS WARRANTY.

19. Appendix F Ferrite Bead Installation

⚠ WARNING: If you are using your YSI 556 in a European Community (CE) country or in Australia or New Zealand, you must attach a ferrite bead to the 655173 PC Interface Cable and the YSI 6117 Charger Adapter Cable in order to comply with the Residential, Commercial and Light Industrial Class B Limits for radio-frequency emissions specified in EN55011 (CISPR11) for Industrial, Scientific and Medical laboratory equipment. These ferrite assemblies are supplied as part of cable kits.

1. Make a small loop (approximately 5 cm in diameter) in the cable near the YSI 556 MS-19 connector.
2. Lay the open ferrite bead assembly under the loop with the cable cross-over position within the cylinder of the ferrite bead.




Figure 19.1 Ferrite Bead Installation

3. Snap the two pieces of the bead together making certain that the tabs lock securely.
4. When the installation is complete, the 655173 and YSI 6117 cables should resemble the following drawings.




Figure 19.2 Cables with Ferrite Beads

20. Appendix G EcoWatch

EcoWatch™ for Windows™ must be used as the PC software interface to the YSI 556 MPS. EcoWatch is a powerful tool that can also be used with YSI 6-series sondes. Many features of the software will only be utilized by advanced users or are not relevant to the 556 MPS at all. This section is designed in tutorial format to familiarize you with the commonly used features of EcoWatch so that it will be possible to:

- Upload data from a 556 MPS to a PC
- Assemble plots and reports of your data
- Zoom in on certain segments of the plots of your data to facilitate analysis
- Show statistical data for your studies
- Export data in spreadsheet-compatible formats
- Print plots and reports

The advanced features of EcoWatch can be explored by downloading a 6-series manual from the YSI Web Site (www.y.si.com), purchasing a hard copy of the manual through YSI Customer Service (Item # 069300), or utilizing the on-line help feature of the software.

20.1 Installing EcoWatch for Windows

EcoWatch for Windows is available at no cost via a download from the YSI Web Site.

1. Access the YSI Web Site at www.y.si.com.
2. Click on the **Login** link and login (or register if you have not previously registered).



3. Click on the EcoWatch link and save the file to a directory on your computer.


4. After the download is complete, run the EcoWatch file (that you just downloaded) and follow the on screen instructions to install the software on your computer.

If you encounter difficulties in the download procedure, contact YSI Customer Service. Refer to *Appendix E Customer Service*. Alternatively, you may purchase the software on CD ROM (Item #006075) by contacting YSI Customer Service.

This EcoWatch tutorial is designed to teach you the commonly used operations associated with the software when used with your 556 MPS.

After you have uploaded a file, Refer to Section [8.4 Upload to PC](#), you will see two files in the C:\ECOWWIN\DATA directory; the file you transferred and a file supplied by YSI designated SAMPLE.DAT. This SAMPLE.DAT file is referred to in the remainder of this tutorial section. After following the instructions below for the analysis of SAMPLE.DAT, you apply the same analysis to the data file which was uploaded from your 556 MPS to assure that you are familiar with the basic features and capabilities of EcoWatch for Windows.

To start the analysis of the SAMPLE.DAT file, note that a shortened menu bar is visible and many of the tools in the toolbar appear dimmed or “grayed out” before any file is opened (see below).




Full activation of EcoWatch features will be realized after a file is opened.




To open the sample data file:


5. 1. Click the **File** menu  button in the toolbar.
6. 2. Select the **SAMPLE.DAT** file.
7. 3. Click **OK** to open the file.




The following display will appear:




Note that the data in this file appears as a graph of temperature, specific conductance, dissolved oxygen, pH, ORP, and depth, all versus time. The graphs are scaled automatically so that all data fits comfortably on the computer screen. Note also that this data file was obtained with a 6-series sonde for which a depth sensor is available. Depth is NOT a current parameter for the 556 MPS.

The **Table**  and **Graph**  buttons on the toolbar are on/off switches that are used to display or hide the graph and table pages respectively. When displaying a graph and a table at the same time, you can control the relative size of the two pages by placing the cursor over the small bar that separates them and then dragging it to the desired location. Click the **Table**  button to generate the following dual display of data.



Now click the **Graph**  button (turn it off) to display only a report of your data as shown below. Note that the size of the report can be varied by clicking on the  and  buttons in the Toolbar.




Now return to the original graphic display by toggling the **Table**




button “off” and **Graph**




button “on”.




From the **Setup** menu, click **Graph**. Click **2 Traces per Graph** and notice that the parameters are now graphed in pairs for easy comparison of parameters.




Click **1 Trace per Graph** to return the display to the original setting. Move the cursor to any position in the graph, then click and hold the right mouse button.





Note that the exact measurements for this point in time are displayed to the left of the graph. While holding down the right mouse button, move to another area on the graph. Notice how the measurements change as you move. When you release the mouse button, the display returns to normal.

To view statistical information for the study, click the **Statistics**  button on the toolbar. On the statistics window, click on any min or max value to display the time when it occurred.




After viewing statistics, click the “x” at the upper right to close the window and return to the normal display.


Now click on the delimiter  icon in the toolbar and then move the displayed icon to the graph. Click at the two points shown by dotted lines in the display below, being sure that the first click is to the left of the second.





The data between the two selected points will then be graphed in higher resolution as shown below.




To return to the complete data set, select **Graph** from the toolbar and then click **Cancel Limits**.


Now select the  icon from the Toolbar to create a new data file which will allow your data to be imported into spreadsheets. Select the default export settings for a Comma Delimited File (.CDF) and click OK. A new spreadsheet-importable file (SAMPLE.CDF) is now present in the same folder as the SAMPLE.DAT file.



Now select the  icon from the toolbar to print the plot. Accept the default settings and click OK to complete the printing operation.



Finally, end the tutorial by saving the **Data Display** in the format shown. From the **File** menu, click **Save Data Display**.



Then type “Default” for the file name and click **Save**. The parameters, colors, format, and x-axis time interval associated with the current display are now saved and can be accessed any time in the future. Nine different data displays may be saved for any data file. You can easily switch between various displays of the data. The data files can be accessed by clicking **Load Data Display** from the file menu and then selecting the desired presentation.

20.2.1 Summary of Toolbar Capability

The EcoWatch toolbar includes buttons for some of the most common commands in EcoWatch, such as **File Open**. To display or hide the toolbar, open the **View** menu and click on the **Toolbar** command. A check mark appears next to the menu item when the toolbar is displayed.


















The toolbar is displayed across the top of the application window, below the menu bar.



Click To:



Open an existing data file (.DAT). EcoWatch displays the **Open** dialog box, in which you can locate and open the desired file.

-  Save the working Data Display of the active data file. EcoWatch displays the **Save Data Display** dialog box in which you can overwrite existing Data Display or save to a new one.
-  Export data as a graph in Window Meta File (.WMF) format or as data in Comma Delimited (.CDF) format.
-  Copy the whole graph page or data from the selection on the table to the clipboard.
-  Print the active graph page or table page depending on which one is currently active.
-  Open a new terminal window to communicate with the sonde.
-  Access context sensitive help (Shift+F1).
-  Toggle table window during file processing.
-  Toggle graph window during file processing.
-  Display study statistics.
-  Display study info.
-  Limit the data to be processed in a study.
-  Enlarge a selective portion of graph.
-  Center the graph under the cursor.
-  Enlarge graph or table 20%.
-  Reduce graph or table 20%.
-  Return graph or table to its normal state (unzoom)
-  Redraw the graph.

20.2.2 Other Capabilities

The above tutorial and function list for the toolbar provide basic information to allow you to view and analyze the field data which was stored in your 556 MPS. Some of the other commonly used capabilities of EcoWatch which the user may want to explore are listed below:

- Customize the units for each parameter, e.g., report uS/cm instead of mS/cm for conductivity.
- Customize the order of parameters in each plot or report.
- Customize the colors and fonts of each data display.
- Manually scale the y-axis sensitivity for each parameter.
- Merging of two or more data files with compatible parameter formats
- View information about the study such as number of points, instrument serial number, etc. which was stored in the 556 with the data.
- Print data reports in different statistical formats.
- Create plots of parameter vs. parameter rather than parameter vs. time.

These additional features of EcoWatch for Windows are explained in detail in the YSI 6-series manual (which can be downloaded at no cost from the YSI Web Site as described above) and the Help selection in the EcoWatch menubar. To purchase a hard copy of the 6-series manual, contact YSI Customer Service using the contact information in *Appendix E Customer Service*.

21. Appendix H Calibration Record Information

When your YSI 556 MPS sensors are initially calibrated, relevant information about the sensors will be stored in a separate file in the YSI 556 MPS memory.

NOTE: This file, by default, will have the name “556 Circuit Board Serial Number.glp.” The circuit board serial number is assigned at the factory and has a hexadecimal format such as 000080A4. Thus the default calibration record file would be designated 00080A4.glp. Refer to Section 10.7 *GLP Filename* to change the filename.

The information in the calibration record will track the sensor performance of your instrument and should be particularly useful for programs operating under Good Laboratory Practices (GLP) protocols.

21.1 Viewing the Calibration Record (.glp) File

NOTE: Make certain that you have performed a calibration on at least one of the sensors associated with your YSI 556 MPS.

1. Follow the procedures outlined in Section 8.3 *View File*.

21.2 Uploading the Calibration Record (.glp) File

NOTE: Make certain that you have performed a calibration on at least one of the sensors associated with your YSI 556 MPS.

1. Follow the procedures outlined in Section 8.4 *Upload to PC*.

21.3 Understanding the Calibration Record (.glp) File

1. Open a calibration record file. Refer to Section 8.3 *View File*.
2. Use the arrow keys to scroll horizontally and/or vertically to view all the data.

| 00008003 .glp | | |
|---------------|----------|----------|
| m/d/y | hh:mm:ss | S/N |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:17:51 | 00008003 |
| 01/24/2001 | 08:25:40 | 00008003 |
| 01/24/2001 | 08:25:40 | 00008003 |

735.9mmHg

01/24/2001 08:39:53

Figure 21.1 Calibration Record Screen 1

| 00008003 .glp | | |
|----------------------|------|----------|
| | Type | Value |
| Conductivity gain | | 1.000000 |
| DO gain | | 1.000000 |
| pH gain (pH-7) *K/mV | | -5.05833 |
| pH offset (pH-7) *K | | 0.000000 |
| ORP offset mV | | 0.000000 |
| TDS constant | | 0.650000 |
| Barometer offset PSI | | 0.000000 |
| DO gain | | 1.110250 |
| pH gain (pH-7) *K/mV | | -5.05833 |
| pH offset (pH-7) *K | | -12.2899 |

735.9mmHg

01/24/2001 08:39:19

Figure 21.2 Calibration Record Screen 2

NOTE: Each sensor (not parameter) is characterized by either 1 line (Conductivity, Dissolved Oxygen, ORP, TDS, or Barometer (Optional)) or 2 lines (pH) of calibration documentation.

The left hand portion of each calibration entry shows the date and time that a calibration of a particular sensor was performed. In addition, each calibration entry is characterized by the instrument serial number, as defined by YSI. See Figure 21.1 Calibration Record Screen 1. The right hand portion shows the YSI designation of the calibration constants and their values after their calibration has been performed. A more detailed description of the calibration constants is provided below:

- **Conductivity Gain** – A relative number which describes the sensitivity of the sensor. Basically, the value represents the calculated cell constant divided by the typical value of the cell constant (5 cm^{-1}).
- **DO Gain** – A relative number which describes the sensitivity of the sensor. Basically, the value represents the sensor current at the time of calibration divided by the typical value of the sensor current (15 μA).
- **pH Gain** – A number which basically represents the sensitivity of the pH sensor. To remove the effect of temperature on the slope of the relationship of probe output in mv versus pH, the value of pH/mv is multiplied by the temperature in degrees Kelvin (K).
- **pH Offset** – A number which basically represents the offset (or intercept) of the relationship of probe output in mv versus pH, the value of pH is multiplied by the temperature in degrees Kelvin (K).

Anytime you perform a calibration, information concerning the calibration constants will be logged to the Calibration Record file (.glp file). However, if the **Delete All Files** command is used, Refer to Section 8.6 *Delete All Files*, the Calibration Record file will also be lost. It is critical that this file should be uploaded to your PC prior to issuing a **Delete All Files** command. Refer to Section 8.4 *Upload to PC*.



Y S I incorporated

YSI Environmental
1700/1725 Brannum Lane
Yellow Springs, OH
45387 USA
937.767.7241
937.767.9353 fax
environmental@YSI.com

www.YSI.com

©2004 YSI Incorporated

A655279C
655279Web
January 2004

Preparing Field Log Books

I. Purpose

This SOP provides general guidelines for entering field data into log books during site investigation and remediation activities.

II. Scope

This is a general description of data requirements and format for field log books. Log books are needed to properly document all field activities in support of data evaluation and possible legal activities.

III. Equipment and Materials

- Log book
- Indelible pen

IV. Procedures and Guidelines

Properly completed field log books are a requirement for much of the work we perform under the Navy CLEAN contract. Log books are legal documents and, as such, must be prepared following specific procedures and must contain required information to ensure their integrity and legitimacy. This SOP describes the basic requirements for field log book entries.

A. PROCEDURES FOR COMPLETING FIELD LOG BOOKS

1. Field notes commonly are kept in bound, hard-cover logbooks used by surveyors and produced, for example, by Peninsular Publishing Company and Sesco, Inc. Pages should be water-resistant and notes should be taken only with water-proof, non-erasable permanent ink, such as that provided in Sanford Sharpie® permanent markers.
2. On the inside cover of the log book the following information should be included:
 - Company name and address
 - Log-holders name if log book was assigned specifically to that person
 - Activity or location

- Project name
 - Project manager's name
 - Phone numbers of the company, supervisors, emergency response, etc.
3. All lines of all pages should be used to prevent later additions of text, which could later be questioned. Any line not used should be marked through with a line and initialed and dated. Any pages not used should be marked through with a line, the author's initials, the date, and the note "Intentionally Left Blank."
 4. If errors are made in the log book, cross a single line through the error and enter the correct information. All corrections shall be initialed and dated by the personnel performing the correction. If possible, all corrections should be made by the individual who made the error.
 5. Daily entries will be made chronologically.
 6. Information will be recorded directly in the field log book during the work activity. Information will not be written on a separate sheet and then later transcribed into the log book.
 7. Each page of the log book will have the date of the work and the note takers initials.
 8. The final page of each day's notes will include the note-takers signature as well as the date.
 9. Only information relevant to the subject project will be added to the log book.
 10. The field notes will be copied and the copies sent to the Project Manager or designee in a timely manner (at least by the end of each week of work being performed).

B. INFORMATION TO BE INCLUDED IN FIELD LOG BOOKS

1. Entries into the log book should be as detailed and descriptive as possible so that a particular situation can be recalled without reliance on the collector's memory. Entries must be legible and complete.
2. General project information will be recorded at the beginning of each field project. This will include the project title, the project number, and project staff.
3. Scope: Describe the general scope of work to be performed each day.
4. Weather: Record the weather conditions and any significant changes in the weather during the day.
5. Tail Gate Safety Meetings: Record time and location of meeting, who was present, topics discussed, issues/problems/concerns identified,

and corrective actions or adjustments made to address concerns/problems, and other pertinent information.

6. Standard Health and Safety Procedures: Record level of personal protection being used (e.g., level D PPE), record air monitoring data on a regular basis and note where data were recording (e.g., reading in borehole, reading in breathing zone, etc). Also record other required health and safety procedures as specified in the project specific health and safety plan.
7. Instrument Calibration; Record calibration information for each piece of health and safety and field equipment.
8. Personnel: Record names of all personnel present during field activities and list their roles and their affiliation. Record when personnel and visitors enter and leave a project site and their level of personal protection.
9. Communications: Record communications with project manager, subcontractors, regulators, facility personnel, and others that impact performance of the project.
10. Time: Keep a running time log explaining field activities as they occur chronologically throughout the day.
11. Deviations from the Work Plan: Record any deviations from the work plan and document why these were required and any communications authorizing these deviations.
12. Health and Safety Incidents: Record any health and safety incidents and immediately report any incidents to the Project Manager.
13. Subcontractor Information: Record name of company, record names and roles of subcontractor personnel, list type of equipment being used and general scope of work. List times of starting and stopping work and quantities of consumable equipment used if it is to be billed to the project.
14. Problems and Corrective Actions: Clearly describe any problems encountered during the field work and the corrective actions taken to address these problems.
15. Technical and Project Information: Describe the details of the work being performed. The technical information recorded will vary significantly between projects. The project work plan will describe the specific activities to be performed and may also list requirements for note taking. Discuss note-taking expectations with the Project Manager prior to beginning the field work.
16. Any conditions that might adversely affect the work or any data obtained (e.g., nearby construction that might have introduced excessive amounts of dust into the air).

17. Sampling Information; Specific information that will be relevant to most sampling jobs includes the following:
- Description of the general sampling area – site name, buildings and streets in the area, etc.
 - Station/Location identifier
 - Description of the sample location – estimate location in comparison to two fixed points – draw a diagram in the field log book indicating sample location relative to these fixed points – include distances in feet.
 - Sample matrix and type
 - Sample date and time
 - Sample identifier
 - Draw a box around the sample ID so that it stands out in the field notes
 - Information on how the sample was collected – distinguish between “grab,” “composite,” and “discrete” samples
 - Number and type of sample containers collected
 - Record of any field measurements taken (i.e. pH, turbidity, dissolved oxygen, and temperature, and conductivity)
 - Parameters to be analyzed for, if appropriate
 - Descriptions of soil samples and drilling cuttings can be entered in depth sequence, along with PID readings and other observations. Include any unusual appearances of the samples.

C. SUGGESTED FORMAT FOR RECORDING FIELD DATA

1. Use the left side border to record times and the remainder of the page to record information (see attached example).
2. Use tables to record sampling information and field data from multiple samples.
3. Sketch sampling locations and other pertinent information.
4. Sketch well construction diagrams.

V. Attachments

Example field notes.

471 MAY 12, 2003 EXAMPLE

0715 ARRIVE ON SITE AT XYZ SITE.
 CH2M HILL STAFF:
 JOHN SMITH: FIELD TEAM LEADER
 BOB BUILDER: SITE SAFETY COORD.
 WEATHER: OVERCAST + COOL, 45°F
 CHANCE OF LATE SHOWERS
 SCORE: • COLLECT GROUNDWATER SAMPLES FOR LTM WORK AT SITE 14
 • SCHEDULE SURVEY CREW
 AT SITE 17
 BB ~~arr~~ (55) Calibrates
 PID: 101 ppm/100 ppm OK
 PID Model #, SERIAL #
 BB Calibrates HORIBA METER
 Model #, SERIAL #
 → List Calibration Results
 0738 SURVEY CREW ARRIVES ON SITE
 → List NAMES
 0745 BB Holds H+S TALK on Slips, trips, Falls, Ticks + AIR Monitoring
 IS + SURVEY CREW ATTEND
 No H+S ISSUES IDENTIFIED as concerns. All work s in "Level D."
 0755 IS conducts site-wide AIR Monitoring
 All readings = 0.0 ppm in

TS
5-12-03

MAY 12, 2003 EXAMPLE 48

0805 BREATHING ZONE (BZ)
 Mobilize to well MW-22 to sample / surveyors setting up
 AT SITE 17
 0815 PM (PAUL PAPER PUSHER) calls AND informs IS to collect Geo sample
 AT well MW-44 today for 24 hr TAT ANALYSIS OF VOCs
 0820 Purging MW-22
 → RECORD WATER QUALITY DATA
 0843 Collect sample AT MW-22 for total TAL Metals AND VOCs. No dissolved metals needed per PPT
 0905 IS + BB Mobilize to site 17 to show surveyors wells to survey.
 Mobilize to well MW-22 to collect sample
 0950 Can not access well MW-22 due to BASE OPERATIONS. Contact Paul Paperpusher and he started he will check on Gateway Access with BASE contact.
 0955 Mobilize to well MW-19

TS
5-12-03

TS
5-12-03

Locating and Clearing Underground Utilities

I. Purpose

The purpose of this SOP is to provide general guidelines and specific procedures that must be followed on Navy CLEAN projects for locating underground utilities and clearing dig locations in order to maximize our ability to avoid hitting underground utilities and to minimize liabilities to CH2M HILL and its subcontractors and health and safety risks to our project staff.

This SOP shall be used by Activity Managers and Project Managers to, in-turn, develop Activity-specific and project-specific utility location procedures. The activity and project-specific procedures will become part of work plans and project instructions and will be used to prepare scopes of work (SOWs) for the procurement of utility location subcontractors to meet the needs of individual projects.

This SOP also identifies the types of utility locating services that are available from subcontractors and the various tools that are used to locate utilities, and discusses when each type of service and tool may or may not be applicable.

II. Scope

Depending on the Navy/Marine Activity we typically find ourselves in one of two scenarios:

Scenario 1

The Activity provides utility locating (or dig clearance) services through the public works department or similar organization, or has a contract with an outside utility clearance service. Some of these services are provided in the form of dig permits which are required before you can dig or drill. In other cases, no official permit is required and the process is somewhat vague.

Scenario 2

The Activity does not get involved in any utility locating processes aside from possibly providing the most recent utility maps, and relies on CH2M HILL to clear the dig locations.

Table 1 provides an up to date summary of which scenarios apply to the various primary Activities served under the Navy CLEAN program.

Scenario 1 is preferred because under this scenario the Navy tends to assume the responsibility if the location is improperly cleared, a utility is struck, and property damage results. However, our experience has been that the clearance services provided by the Navy do not meet the standards that we consider to be adequate, in that they often simply rely on available base maps to mark utilities and do not verify locations

using field geophysics. And if they do use locating tools, they do not provide adequate documentation or marking to confirm that a location has been cleared. So while the Navy's process may protect us from liability for property damage, it does not adequately protect our staff and subcontractors from health risks nor does it compensate us for down time, should a utility be hit.

Therefore, regardless of what services the Navy provides, in most cases we still need to supplement this effort with clearance services from our own third party utility location subcontractor following the procedures and guideline outlined in Section IV of this SOP. The cost implications of providing this service will range from \$500 to several \$1,000 depending on the size of the project.

The scope of services that we ask our subcontractors to provide can involve utility marking/mapping or the clearing of individual dig locations. In the former we ask our subs to mark all utilities within a "site" and often ask them to prepare a map based on their work. In the later, we ask them to clear (identify if there are any utilities within) a certain radius of a proposed dig/drill location.

The appropriate requested scope of services for a project will depend on the project. Clearing individual boreholes is often less expensive and allows the sub to concentrate their efforts on a limited area. However, if the scope of the investigation is fluid (all borehole locations are not predetermined) it may be best to mark and map an entire site or keep the subcontractor on call.

Clearance of individual dig locations should be done to a minimum 20-foot radius around the location.

An example SOW for a utility subcontractor procurement is provided in Attachment A.

III. Services and Equipment

This section provides a general description of the services available to help us locate subsurface utilities and describes the types of equipment that these services may (or may not) use to perform their work. It identifies the capabilities of each type of equipment to help the PM specify what they should require from our utility location subs.

Services

The services that are available to us for identifying and marking underground utilities are:

- The local public/private utility-run service such as Miss Utility
- Utility location subcontractors (hired by us)

Attachment B provides a detailed description of each type of organization. It also provides contact numbers and web sites for the various Miss-Utility-type organizations in the areas where we do work for the Navy and contacts and services provided by several subcontractors that we have used or spoken to in the past.

Equipment

Attachment C provides a summary of the various types of equipment used for subsurface utility location. It describes the capabilities and limitations of each in order to help the PM determine if the equipment being used by a subcontractor is adequate.

It is important to make the potential subcontractors aware of the possible types of utilities (and utility materials) that are at the site, and to have them explain in their bid what types of equipment they will use to locate utilities / clear dig locations, and what the limitations of these equipment are.

A list of in-house experts that can be used to help you evaluate bids or answer questions you may have is provided in **Appendix C**.

IV. Procedures and Guidelines

This section presents specific procedures to be followed for the utility location work to be conducted by CH2M HILL and our subcontractors. In addition, a PM will have to follow the procedures required by the Activity to obtain their approvals, clearances and dig permits where necessary. These “dig permit” requirements vary by Activity and must be added to the project-specific SOP, or project instructions. It is preferable that the Activity perform their clearance processes before we follow up with our clearance work.

Activity Notification and Dig Permit Procedures

Identify Activity-specific permit and/or procedural requirements for excavation and drilling activities. Contact the Base Civil Engineer and obtain the appropriate form to begin the clearance process.

Activity Specific: To be provided by Activity or Project Manager

CH2M HILL Utility Clearance Procedures

Do not begin subsurface construction activities (e.g., trenching, excavation, drilling, etc.) until a check for underground utilities and similar obstructions has been conducted by CH2M HILL as a follow-up to the services provided by the Navy. The use of as-built drawings and utility company searches must be supplemented with a geophysical or other survey by a qualified, independent survey contractor (subcontracted to CH2M HILL) to identify additional and undiscovered buried utilities.

Examples of the type of geophysical technologies include (these are further described in Attachment C):

- **Ground Penetrating Radar (GPR)**, which can detect pipes, including gas pipes, tanks, conduits, cables etc, both metallic and non-metallic at depths up to 30 feet depending on equipment. Sensitivity for both minimum object size and maximum depth detectable depends on equipment selected, soil conditions, etc.
- **Radio Frequency (RF)**, involves inducing an RF signal in the pipe or cable and using a receiver to trace it. Some electric and telephone lines emit RF naturally and can be detected without an induced signal. This method requires knowing where the conductive utility can be accessed to induce RF field if necessary.

- **Dual RF**, a modified version of RF detection using multiple frequencies to enhance sensitivity but with similar limitations to RF
- **Ferromagnetic Detectors**, are metal detectors that will detect ferrous and non-ferrous utilities. Sensitivity is limited, e.g. a 100 mm iron disk to a depth of about one meter or a 25 mm steel paper clip to a depth of about 20 cm.
- **Electronic markers**, are emerging technologies that impart a unique electronic signature to materials such as polyethylene pipe to facilitate location and tracing after installation. Promising for future installations but not of help for most existing utilities already in place.

The following procedures shall be used to identify and mark underground utilities during subsurface construction activities on the project:

- Contact utility companies or the state/regional utility protection service (such as Miss Utility) at least two (2) working days prior to intrusive activities to advise of the proposed work, and ask them to establish the location of the utility underground installations prior to the start of actual excavation: this is a law. These services will only mark the location of public-utility-owned lines and not Navy-owned utilities. In many cases there will not be any public-utility-owned lines on the Activity. There may also be Base-access issues to overcome.
- Procure and schedule the independent survey.
- The survey contractor shall determine the most appropriate geophysical technique or combinations of techniques to identify the buried utilities on the project site, based on the survey contractor's experience and expertise, types of utilities anticipated to be present and specific site conditions. *The types of utilities must be provided to the bidding subcontractors in the SOW and procedures to be used must be specified by the bidder in their bid. It is extremely helpful to provide the sub with utility maps, with the caveat that all utilities are not necessarily depicted.*
- The survey subcontractor shall employ the same geophysical techniques used to identify the buried utilities, to survey the proposed path of subsurface investigation/construction work to confirm no buried utilities are present.
- Obtain utility clearances for subsurface work on both public and private property.
- Clearances provided by both the "Miss Utility" service and the CH2M HILL-subcontracted service are to be in writing, signed by the party conducting the clearance. The Miss Utility service will have standard notification forms/letters which typically simply state that they have been to the site and have done their work. The CH2M HILL subcontractor shall be required to fill out the form provided in Attachment D (this can be modified for a particular project) indicating that each dig/drill location has been addressed. *This documentation requirement (with a copy of the form) needs to be provided in the subcontractor SOW.*
- Marking shall be done using the color coding presented in Attachment E. The type of material used for marking must be approved by the Activity prior to marking. Some base commanders have particular issues with persistent spray paint on their

sidewalks and streets. *Any particular marking requirements need to be provided in the subcontractor SOW.*

- Protect and preserve the markings of approximate locations of facilities until the markings are no longer required for safe and proper excavations. If the markings of utility locations are destroyed or removed before excavation commences or is completed, the Project Manager must notify the utility company or utility protection service to inform them that the markings have been destroyed.
- Perform a field check prior to drilling/ digging (preferably while the utility location sub is still at the site) to see if field utility markings coincide with locations on utility maps. Look for fire hydrants, valves, manholes, light poles, lighted signs, etc to see if they coincide with utilities identified by the subcontractor.
- Underground utility locations must be physically verified (or dig locations must be physically cleared) by hand digging using wood or fiberglass-handled tools, air knifing, or by some other acceptable means approved by CH2M HILL, when the dig location (e.g. mechanical drilling, excavating) is expected to be within 5 feet of a marked underground system. Hand clearance shall be done to a depth of four feet unless a utility cross-section is available that indicates the utility is at a greater depth. In that event, the hand clearance shall proceed until the documented depth of the utility is reached.
- Conduct a site briefing for employees at the start of the intrusive work regarding the hazards associated with working near the utilities and the means by which the operation will maintain a safe working environment. Detail the method used to isolate the utility and the hazards presented by breaching the isolation.
- Monitor for signs of utilities during advancement of intrusive work (e.g., sudden change in advancement of auger or split spoon during drilling or change in color, texture or density during excavation that could indicate the ground has been previously disturbed).

IV. Attachments

- A- Example SOW for Utility Location Subcontractor Procurement
- B - Services Available for Identifying and Marking Underground Utilities
- C - Equipment Used for Identifying Underground Utilities
- D - Utility Clearance Documentation Form
- E - Utility Marking Color Codes

Attachment A – Example SOW for Subcontracting Underground Utilities Locating Services

CTO-**XXX**

Scope of Work

Subsurface Utility Locating

Site **XX**

Navy Activity

City, State

A licensed and insured utility locator will be subcontracted to identify and mark out subsurface utilities for an environmental investigation/remediation project at Site **XX** of **<<insert name of base, city, and state>>**. The subcontractor will need to be available beginning at **<<insert time>>** on **<<insert date>>**. It is estimated that the work can be completed within **XX** days.

Proposed Scope of Work

The subcontractor will identify and mark all subsurface utilities (**CHOOSE 1**) that lie within a radius of 20 feet of each of **XX** sampling locations at Site **XX** shown on the attached Figure 1; (OR) that lie within the bounds of Site **XX** as delineated on the attached Figure 1. (If multiple sites are to be cleared, provide maps of each site with sample locations or clearance boundaries clearly delineated and a scale provided.)

Utilities will be identified using all reasonably available as-built drawings, electronic locating devices, and any other means necessary to maintain the safety of drilling and sampling personnel and the protection of the base infrastructure. The location of utilities identified from as-built drawings or other maps must be verified in the field prior to marking.

Base utility drawings for the Site(s) (**CHOOSE 1**) can be found at **<<insert specific department and address or phone number on the base>>** and should be reviewed by the subcontractor and referenced as part of the utility locating. (OR), will be provided to the subcontractor by CH2M HILL upon the award of the subcontract. (OR), are not available. Utility drawings shall not be considered definitive and must be field verified.

Field verification will include detection using nonintrusive subsurface detection equipment (magnetometers, GPR, etc) as well as opening manhole covers to verify pipe directions. As part of the bid, the Subcontractor shall provide a list of the various subsurface investigation tools they propose to have available and use at the site and what the limitations are of each tool.

A CH2M HILL representative shall be present to coordinate utility clearance activities and identify points and features to be cleared.

Field Marking and Documentation

All utilities located within **(CHOOSE 1) a 20-ft radius of the XX proposed soil boring locations (OR) within the boundary of the site(s)** as identified on the attached figure(s) will be marked using **paint (some Bases such as the WNY may have restrictions on the use of permanent paint)** and/or pin flags color coded to indicate electricity, gas, water, steam, telephone, TV cable, fiber optic, sewer, etc. The color coding shall match the industry standard as described on the attached form. In addition, the **Buried Utility Location Tracking Form** (attached) will be completed by the Subcontractor based upon what is identified in the field during the utility locating and submitted back to CH2M HILL (field staff or project manager) within 24 hours of completing the utility locating activities.

(OPTIONAL) The subcontractor shall also provide a map (or hand sketch) of the identified utilities to the Engineer within XX days of field demobilization. The map shall include coordinates or ties from fixed surface features to each identified subsurface utility.

Bid Sheet/Payment Units

The subcontractor will bid on a time and materials basis for time spent on site and researching utility maps. Mobilization (including daily travel to the site) should be bid as a lump sum, as well as the preparation of the AHA **and any required mapping**. The per diem line item should be used if the field crew will require overnight accommodations at the project site.

Health and Safety Requirements

The utility locating subcontractor is to provide and assume responsibility for an adequate corporate Health and Safety Plan for onsite personnel. Standard personal safety equipment including: hard hat, safety glasses, steel-toed boots, gloves are recommended for all project activities. Specific health and safety requirements will be established by the Subcontractor for each project. The health and safety requirements will be subject to the review of CH2M HILL.

The subcontractor shall also prepare and provide to the Engineer, at least 48 hours prior to mobilization, an acceptable Activity Hazard Analysis (AHA) using the attached AHA form or similar.

It is also required that all subcontractor personnel who will be on site attend the daily 15-minute health and safety tailgate meeting at the start of each day in the field.

Subcontractor personnel showing indications of being under the influence of alcohol or illegal drugs will be sent off the job site and their employers will be notified. Subcontractor personnel under the influence of prescription or over-the-counter medication that may impair their ability to operate equipment will not be permitted to do so. It is expected that the subcontractor will assign them other work and provide a capable replacement (if necessary) to operate the equipment to continue work.

Security

The work will be performed on US Navy property. CH2M HILL will identify the Subcontractor personnel who will perform the work to the appropriate Navy facility point-of-contact, and will identify the Navy point-of-contact to the Subcontractor crew. The Subcontractor bears final responsibility for coordinating access of his personnel onto Navy property to perform required work. This responsibility includes arranging logistics and providing to CH2M HILL, in advance or at time of entry as specified, any required identification information for the Subcontractor personnel. Specifically, the following information should be submitted with the bid package for all personnel that will perform the work in question (this information is required to obtain a base pass):

- Name
- Birth Place
- Birth Date
- Social Security Number
- Drivers License State and Number
- Citizenship

Please be advised that no weapons, alcohol, or drugs will be permitted on the Navy facility at any time. If any such items are found, they will be confiscated, and the Subcontractor will be dismissed.

Quality Assurance

The Subcontractor will be licensed and insured to operate in the State of <<state>> and will comply with all applicable federal, state, county and local laws and regulations. The subcontractor will maintain, calibrate, and operate all electronic locating instruments in accordance with the manufacturer's recommendations. Additionally, the Subcontractor shall make all reasonable efforts to review as-built engineering drawings maintained by Base personnel, and shall notify the CH2M HILL Project Manager in writing (email is acceptable) whenever such documentation was not available or could not be reviewed.

Subcontractor Standby Time

At certain periods during the utility locating activities, the Subcontractor's personnel may be asked to stop work and standby when work may normally occur. During such times, the Subcontractor will cease activities until directed by the CH2M HILL representative to resume operations. Subcontractor standby time also will include potential delays caused by the CH2M HILL representative not arriving at the site by the agreed-upon meeting time for start of the work day. Standby will be paid to the

Subcontractor at the hourly rate specified in the Subcontractor's Bid Form attached to these specifications.

Cumulative Subcontractor standby will be accrued in increments no shorter than 15 minutes (i.e., an individual standby episode of less than 15 minutes is not chargeable).

During periods for which standby time is paid, the surveying equipment will not be demobilized and the team will remain at the site. At the conclusion of each day, the daily logs for the Subcontractor and CH2M HILL representative will indicate the amount of standby time incurred by the Subcontractor, if any. Payment will be made only for standby time recorded on CH2M HILL's daily logs.

Down Time

Should equipment furnished by the Subcontractor malfunction, preventing the effective and efficient prosecution of the work, or inclement weather conditions prevent safe and effective work from occurring, down time will be indicated in the Subcontractor's and CH2M Hill representative's daily logs. No payment will be made for down time.

Schedule

It is anticipated that the subsurface utility locating activities will occur on <<insert date>>. It is estimated that the above scope will be completed within XXX days.

Attachment B - Services Available for Identifying and Marking Underground Utilities

The services that are available to us for identifying and marking underground utilities are:

- The Activity's PWC (or similar organization)
- The local public/private utility -run service such as Miss Utility
- Utility location subcontractors (hired by CH2M HILL)

Each are discussed below.

Navy Public Works Department

A Public Works Department (PWD) is usually present at each Activity. The PWD is responsible for maintaining the public works at the base including management of utilities. In many cases, the PWD has a written permit process in place to identify and mark-out the locations of Navy-owned utilities [Note: The PWD is usually NOT responsible for the locations/mark-outs of non-Navy owned, public utilities (e.g., Washington Gas, Virginia Power, municipal water and sewer, etc.). Therefore, it is likely that we will have to contact other organizations besides the PWD in order to identify non-Navy owned, public utilities].

At some Activities, there may not be a PWD, the PWD may not have a written permit process in place, or the PWD may not take responsibility for utility locating and mark-outs. In these cases, the PWD should still be contacted since it is likely that they will have the best understanding of the utility locations at the Activity (i.e., engineering drawings, institutional knowledge, etc.). Subsequently, the PWD should be brought into a cooperative arrangement (if possible) with the other services employed in utility locating and mark-out in order to have the most comprehensive assessment performed.

At all Activities we should have a contact (name and phone number), and preferably an established relationship, with PWD, either directly or through the NAVFAC Atlantic, Midlant, or Washington NTR or Activity Environmental Office that we can work with and contact in the event of problems.

Miss Utility or "One Call" Services for Public Utility Mark-outs

Miss Utility or "One Call" service centers are information exchange centers for excavators, contractors and property owners planning any kind of excavation or digging. The "One Call" center notifies participating public utilities of the upcoming excavation work so they can locate and mark their underground utilities in advance to prevent possible damage to underground utility lines, injury, property damage and service outages. In some instances, such with southeastern Virginia bases, the Navy has entered into agreement with Ms. Utilities and is part of the response process for Miss

Utilities. Generally, a minimum of 48 hours is required for the public utility mark-outs to be performed. The “One Call” services are free to the public. Note that the “One Call” centers only coordinate with participating public utilities. There may be some public utilities that do NOT participate in the “One Call” center which may need to be contacted separately. For example, in Washington, DC, the Miss Utility “One Call” center does not locate and mark public sewer and water lines. Therefore, the municipal water and sewer authority must be contacted separately to have the sewer and water lines marked out. The AM should contact the appropriate one-call center to determine their scope of services.

For the Mid-Atlantic region, the following “One Call” service centers are available.

| Name | Phone | Website | Comments |
|--|------------------------------|--|--|
| Miss Utility of DELMARVA | 800-257-7777 | www.missutility.net | Public utility mark-outs in Delaware, Maryland, Washington, DC, and Northern Virginia |
| Miss Utility of Southern Virginia (One Call) | 800-552-7001 | not available | Public utility mark-outs in Southern Virginia |
| Miss Utility of Virginia | 800-257-7777 800-552-7007 | www.missutilityofvirginia.com | General information on public utility mark-outs in Virginia, with links to Miss Utility of DELMARVA and Miss Utility of Southern Virginia (One Call) |
| Miss Utility of West Virginia, Inc | 800-245-4848 | none | Call to determine what utilities they work with in West Virginia |
| North Carolina One Call Center | 800-632-4949 | www.ncocc.org/ncocc/default.htm | Public Utility Markouts in North Carolina |

Private Subcontractors

- Utility-locating support is required at some level for most all CH2M HILL field projects in "clearing" proposed subsurface boring locations on the project site. Utility location and sample clearance can include a comprehensive effort of GIS map interpretation, professional land surveying, field locating, and geophysical surveying. Since we can usually provide our own GIS-related services for projects and our professional land surveying services are normally procured separately, utility-locating subcontractors will normally only be required for some level of geophysical surveying support in the field. This level of geophysical surveying support can range widely from a simple electromagnetic (EM) survey over a known utility line, to a blind geophysical effort, including a ground-penetrating radar (GPR) survey and/or a comprehensive EM survey to delineate and characterize all unknown subsurface anomalies.

The level of service required from the subcontractor will vary depending on the nature of the site. At sites where utility locations are well defined on the maps and recent construction is limited, CH2M HILL may be confident with a limited effort from a traditional utility-locating subcontractor providing a simple EM survey. At sites where utility locations are not well defined, where recent constructions may have altered utility locations, or the nature of the site makes utility location difficult,

CH2M HILL will require the services of a comprehensive geophysical surveying subcontractor, with a wide range of GPR and EM services available for use on an "as-needed" basis. Typical costs for geophysical surveying subcontractors will range from approximately \$200 per day for a simple EM effort (usually one crew member and one instrument) to approximately \$1,500 per day for a comprehensive geophysical surveying effort (usually a two-person crew and multiple instruments). Comprehensive geophysical surveying efforts may also include field data interpretation (and subsequent report preparation) and non-destructive excavation to field-verify utility depths and locations.

The following table provides a list of recommended geophysical surveying support subcontractors that can be used for utility-locating services:

| Company Name and Address | Contact Name and Phone Number | Equipment ¹ | | | | | Other Services ² | | |
|--|-------------------------------|------------------------|---|---|---|---|-----------------------------|---|---|
| | | 1 | 2 | 3 | 4 | 5 | A | B | C |
| US Radar, Inc.* PO Box 319 Matawan, NJ 07747 | Ron LaBarca | | | 4 | | | | | |
| Utilities Search, Inc.* | Jim Davis | 4 | | | | 4 | 4 | 4 | 4 |
| So Deep, Inc.* 8397 Euclid Avenue Manassas Park, VA 20111 | | 4 | | | | | 4 | 4 | 4 |
| Accurate Locating, Inc. 1327 Ashton Rd., Suite 101 Hanover, MD 21076 | Ken Shipley | 4 | 4 | | | | | | |
| NAEVA Geophysics, Inc. P.O. Box 7325 Charlottesville, VA 22906 | Alan Mazurowski | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| Earth Resources Technology, Inc. 8106 Stayton Rd. Jessup, MD 20794 | Peter Li | 4 | 4 | 4 | 4 | 4 | 4 | 4 | |
| Geophex, Ltd 605 Mercury Street Raleigh, NC 27603 | I. J. Won | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |

Notes:

*Companies denoted with an asterisk have demonstrated reluctance to assume responsibility for damage to underground utilities or an inability to accommodate the insurance requirements that CH2M HILL requests for this type of work at many Navy sites.

¹Equipment types are:

1. Simple electromagnetic instruments, usually hand-held
2. Other, more innovative, electromagnetic instruments, including larger instruments for more area coverage
3. Ground-penetrating radar systems of all kinds
4. Audio-frequency detectors of all kinds
5. Radio-frequency detectors of all kinds

²Other services include:

- A. Data interpretation and/or report preparation to provide a permanent record of the geophysical survey results and a professional interpretation of the findings, including expected accuracy and precision.
- B. Non-destructive excavation to field-verify the depths, locations, and types of subsurface utilities.
- C. Concrete/asphalt coring and pavement/surface restoration.

Attachment C – Equipment Used for Identifying Underground Utilities

This attachment provides a summary of the various types of equipment used for subsurface utility location. It describes the capabilities and limitations of each in order to help the AM and PM determine if the equipment being proposed by a subcontractor or Navy is adequate. A list of in-house experts that can be used to answer questions you may have is provided below.

CH2M HILL In-house Utility Location Experts

Tamir Klaff/WDC

Home Office Phone –

Electromagnetic Induction (EMI) Methods

EMI instruments, in general, induce an electromagnetic field into the ground (the primary field) and then record the response (the secondary field), if any. Lateral changes in subsurface conductivity, such as caused by the presence of buried metal or by significant soil variations, cause changes in the secondary field recorded by the instrument and thus enable detection and mapping of the subsurface features. It should be noted that EMI only works for electrically conductive materials--plastic or PVC pipes are generally not detected with EMI. Water and gas lines are commonly plastic, although most new lines include a copper “locator” strip on the top of the PVC to allow for detection with EMI.

EMI technology encompasses a wide range of instruments, each with inherent strengths and weaknesses for particular applications. One major division of EMI is between “time-domain” and “frequency-domain” instruments that differ in the aspect of the secondary field they detect. Another difference in EMI instruments is the operating frequency they use to transmit the primary field. Audio- and radio-frequencies are often used for utility detection, although other frequencies are also used. Consideration of the type of utility expected, surface features that could interfere with detection, and the “congestion” of utilities in an area, should be made when choosing a particular EMI instrument for a particular site.

One common EMI tool used for utility location is a handheld unit that can be used to quickly scan an area for utilities and allows for marking locations in “real time”. This method is most commonly used by “dig-safe” contractors marking out known utilities prior to excavation. It should be noted that this method works best when a signal (the primary field) can be placed directly onto the line (i.e., by clamping or otherwise connecting to the end of the line visible at the surface, or for larger utilities such as sewers, by running a transmitter through the utility). These types of tools also have a limited capability to scan an area for unknown utilities. Usually this requires having enough area to separate a hand held transmitter at least a hundred feet from the

receiver. Whether hunting for unknown, or confirming known, utilities, this method will only detect continuous lengths of metallic conductors.

In addition to the handheld EMI units, larger, more powerful EMI tools are available that provide more comprehensive detection and mapping of subsurface features. Generally, data with these methods are collected on a regular grid in the investigation area, and are then analyzed to locate linear anomalies that can be interpreted as utilities. These methods will usually detect *all* subsurface metal (above a minimum size), including pieces of abandoned utilities. In addition, in some situations, backfill can be detected against native soils giving information on trenching and possible utility location. Drawbacks to these methods are that the secondary signals from utilities are often swamped (i.e., undetectable) close to buildings and other cultural features, and that the subsurface at heavily built-up sites may be too complicated to confidently interpret completely.

Hand-held metal detectors (treasure-finders) are usually based on EMI technology. They can be used to locate shallow buried metal associated with utilities (e.g., junctions, manholes, metallic locators). Advantages of these tools is the ease of use and real-time marking of anomalies. Drawbacks include limited depths of investigations and no data storage capacity.

Ground Penetrating Radar (GPR)

GPR systems transmit radio and microwave frequency (e.g., 80 megaHertz to 1,000 megaHertz) waves into the ground and then record reflections of those waves coming back to the surface. Reflections of the radar waves typically occur at lithologic changes, subsurface discontinuities, and subsurface structures. Plastic and PVC pipes can sometimes be detected in GPR data, especially if they are shallow, large, and full of a contrasting material such as air in a wet soil, or water in a dry soil. GPR data are usually collected in regular patterns over an area and then analyzed for linear anomalies that can be interpreted as utilities. GPR is usually very accurate in x-y location of utilities, and can be calibrated at a site to give very accurate depth information as well. A significant drawback to GPR is that depth of investigation is highly dependant on background soil conductivity, and it will not work on all sites. It is not uncommon to get only 1-2 feet of penetration with the signal in damp, clayey environments. Another drawback to GPR is that sites containing significant fill material (e.g., concrete rubble, scrap metal, garbage) will result in complicated anomalies that are difficult or impossible to interpret.

Magnetic Field Methods

Magnetic field methods rely on detecting changes to the earth's magnetic field caused by ferrous metal objects. This method is usually more sensitive to magnetic metal (i.e., deeper detection) than EMI methods. A drawback to this method is it is more susceptible to being swamped by surface features such as fences and cars. In addition, procedures must usually be implemented that account for natural variations in the earth's background field as it changes throughout the day. One common use of the method is to measure and analyze the gradient of the magnetic field, which eliminates most of the drawbacks to the method. It should be noted this method only detects

ferrous metal, primarily iron and steel for utility location applications. Some utility detector combine magnetic and EMI methods into a single hand-held unit.

Optical Methods

Down the hole cameras may be useful in visually reviewing a pipe for empty conduits and/or vaults.

Attachment D – Utility Clearance Documentation Form

Attachment E – Utility Marking Color Codes

The following is the standard color code used by industry to mark various types of utilities and other features at a construction site.

White - Proposed excavations and borings

Pink - Temporary survey markings

Red - Electrical power lines, cables, conduits and lighting cables

Yellow - Gas, oil, steam, petroleum or gaseous materials

Orange - Communication, alarm or signal lines, cables, or conduits

Blue - Potable water

Purple - Reclaimed water, irrigation and slurry lines

Green - Sewer and storm drain lines

PMS 219

PMS 1795*

PMS 108









PMS 144*

13.5 parts process
2.5 parts reflex



PMS 253

PMS 3415

ADWA **UNIFORM COLOR CODE**

| | |
|--|---|
|  | WHITE - Proposed Excavation |
|  | PINK - Temporary Survey Markings |
|  | RED - Electric Power Lines, Cables, Conduit and Lighting Cables |
|  | YELLOW - Gas, Oil, Steam, Petroleum or Gaseous Materials |
|  | ORANGE - Communication, Alarm or Signal Lines, Cables or Conduit |
|  | BLUE - Potable Water |
|  | PURPLE - Reclaimed Water, Irrigation and Slurry Lines |
|  | GREEN - Sewers and Drain Lines |

TYPICAL MARKING

| | |
|--|---|
| LARGE PIPE OR MULTIPLE DUCTS  TOLERANCE ZONE 2.4' 600 mm | SMALL PIPE OR CABLE(S)  TOLERANCE ZONE * REFER TO TEXT ON FRONT OF CARD |
|--|---|

Customize with your center's phone and address information

GUIDELINES FOR UNIFORM TEMPORARY MARKING OF UNDERGROUND FACILITIES

This marking guide provides for universal use and understanding of the temporary marking of subsurface facilities to prevent accidents and damage or service interruption by contractors, excavators, utility companies, municipalities or any others working on or near underground facilities.

ONE-CALL SYSTEMS

The One-Call damage prevention system shall be contacted prior to excavation.

PROPOSED EXCAVATION

Use white marks to show the location, route or boundary of proposed excavation. Surface marks on roadways do not exceed 1.5" by 18" (40 mm by 450 mm). The facility color and facility owner identity may be added to white flags or stakes.

USE OF TEMPORARY MARKING

Use color-coded surface marks (i.e., paint or chalk) to indicate the location or route of active and out-of-service buried lines. To increase visibility, color coded vertical markers (i.e., stakes or flags) should supplement surface marks. Marks and markers indicate the name, initials or logo of the company that owns or operates the line, and width of the facility if it is greater than 2" (50 mm). Marks placed by other than line owner/operator or its agent indicate the identity of the designating firm. Multiple lines in joint trench are marked in tandem. If the surface over the buried line is to be removed, supplementary offset markings are used. Offset markings are on a uniform alignment and clearly indicate the actual facility is a specific distance away.

TOLERANCE ZONE

Any excavation within the tolerance zone is performed with non-powered hand tools or non-invasive method until the marked facility is exposed. The width of the tolerance zone may be specified in law or code. If not, a tolerance zone including the width of the facility plus 18" (450 mm) measured horizontally from each side of the facility is recommended.

ADOPT UNIFORM COLOR CODE

The American Public Works Association encourages public agencies, utilities, contractors, other associations, manufacturers and all others involved in excavation to adopt the APWA Uniform Color Code, using ANSI standard Z535.1 Safety Colors for temporary marking and facility identification.

Rev. 4/09

Equipment Blank and Field Blank Preparation

I. Purpose

To prepare blanks to determine whether decontamination procedures are adequate and whether any cross-contamination is occurring during sampling due to contaminated air and dust.

II. Scope

The general protocols for preparing the blanks are outlined. The actual equipment to be rinsed will depend on the requirements of the specific sampling procedure.

III. Equipment and Materials

- Blank liquid (use ASTM Type II or lab grade water)
- Millipore™ deionized water
- Sample bottles as appropriate
- Gloves
- Preservatives as appropriate

IV. Procedures and Guidelines

- A. Decontaminate all sampling equipment that has come in contact with sample according to SOP *Decontamination of Personnel and Equipment*.
- B. To collect an equipment blank for volatile analysis from the surfaces of sampling equipment other than pumps, pour blank water over one piece of equipment and into two 40-ml vials until there is a positive meniscus, then seal the vials. Note the sample number and associated piece of equipment in the field notebook as well as the type and lot number of the water used.

For non-volatiles analyses, one aliquot is to be used for equipment. For example, if a pan and trowel are used, place trowel in pan and pour blank fluid in pan such that pan and trowel surfaces which contacted the sample are contacted by the blank fluid. Pour blank fluid from pan into appropriate sample bottles.

Do not let the blank fluid come in contact with any equipment that has not been decontaminated.

- C. When collecting an equipment blank from a pump, run an extra gallon of deionized water through the pump while collecting the pump outflow into appropriate containers. Make sure the flow rate is low when sampling VOCs. If a Grundfos Redi-Flo2 pump with disposable tubing is used, remove the disposable tubing after sampling but before decon. When decon is complete, put a 3- to 5-foot segment of new tubing onto the pump to collect the equipment blank.
- D. To collect a field blank, slowly pour ASTM Type II or lab grade water directly into sample containers.
- E. Document and ship samples in accordance with the procedures for other samples.
- F. Collect next field sample.

V. Attachments

None.

VI. Key Checks and Items

- Wear gloves.
- Do not use any non-decontaminated equipment to prepare blank.
- Use ASTM-Type II or lab grade water.

Decontamination of Personnel and Equipment

I. Purpose

To provide general guidelines for the decontamination of personnel, sampling equipment, and monitoring equipment used in potentially contaminated environments.

II. Scope

This is a general description of decontamination procedures.

III. Equipment and Materials

- Demonstrated analyte-free, deionized (“DI”) water (specifically, ASTM Type II water or lab-grade DI water)
- Potable water; must be from a municipal water supplier, otherwise an analysis must be run for appropriate volatile and semivolatile organic compounds and inorganic chemicals (e.g., Target Compound List and Target Analyte List chemicals)
- 2.5% (W/W) Liquinox[®] and water solution
- Concentrated (V/V) pesticide grade isopropanol (DO NOT USE ACETONE)
- Large plastic pails or tubs for Liquinox[®] and water, scrub brushes, squirt bottles for Liquinox[®] solution, methanol and water, plastic bags and sheets
- DOT approved 55-gallon drum for disposal of waste
- Personal Protective Equipment as specified by the Health and Safety Plan
- Decontamination pad and steam cleaner/high pressure cleaner for large equipment

IV. Procedures and Guidelines

A. PERSONNEL DECONTAMINATION

To be performed after completion of tasks whenever potential for contamination exists, and upon leaving the exclusion zone.

1. Wash boots in Liquinox[®] solution, then rinse with water. If disposable latex booties are worn over boots in the work area, rinse with Liquinox[®] solution, remove, and discard into DOT-approved 55-gallon drum.
2. Wash outer gloves in Liquinox[®] solution, rinse, remove, and discard into DOT-approved 55-gallon drum.
3. Remove disposable coveralls (“Tyveks”) and discard into DOT-approved 55-gallon drum.
4. Remove respirator (if worn).
5. Remove inner gloves and discard.
6. At the end of the work day, shower entire body, including hair, either at the work site or at home.
7. Sanitize respirator if worn.

B. SAMPLING EQUIPMENT DECONTAMINATION – GROUNDWATER SAMPLING PUMPS

Sampling pumps are decontaminated after each use as follows.

1. Don phthalate-free gloves.
2. Spread plastic on the ground to keep equipment from touching the ground
3. Turn off pump after sampling. Remove pump from well and remove and dispose of tubing. Place pump in decontamination tube.
4. Turn pump back on and pump 1 gallon of Liquinox[®] solution through the sampling pump.
5. Rinse with 1 gallon of 10% isopropanol solution pumped through the pump. (DO NOT USE ACETONE). (Optional)
6. Rinse with 1 gallon of tap water.
7. Rinse with 1 gallon of deionized water.
8. Keep decontaminated pump in decontamination tube or remove and wrap in aluminum foil or clean plastic sheeting.
9. Collect all rinsate and dispose of in a DOT-approved 55-gallon drum.
10. Decontamination materials (e.g., plastic sheeting, tubing, etc.) that have come in contact with used decontamination fluids or sampling equipment will be disposed of in either DOT-approved 55-gallon drums or with solid waste in garbage bags, dependent on Facility/project requirements.

C. SAMPLING EQUIPMENT DECONTAMINATION – OTHER EQUIPMENT

Reusable sampling equipment is decontaminated after each use as follows.

1. Don phthalate-free gloves.
2. Before entering the potentially contaminated zone, wrap soil contact points in aluminum foil (shiny side out).
3. Rinse and scrub with potable water.
4. Wash all equipment surfaces that contacted the potentially contaminated soil/water with Liquinox[®] solution.
5. Rinse with potable water.
6. Rinse with distilled or potable water and isopropanol solution (DO NOT USE ACETONE). (Optional)
7. Air dry.
8. Rinse with deionized water.
9. Completely air dry and wrap exposed areas with aluminum foil (shiny side out) for transport and handling if equipment will not be used immediately.
10. Collect all rinsate and dispose of in a DOT-approved 55-gallon drum.
11. Decontamination materials (e.g., plastic sheeting, tubing, etc.) that have come in contact with used decontamination fluids or sampling equipment will be disposed of in DOT-approved 55-gallon drums or with solid waste in garbage bags, dependent on Facility/project requirements.

D. HEALTH AND SAFETY MONITORING EQUIPMENT DECONTAMINATION

1. Before use, wrap soil contact points in plastic to reduce need for subsequent cleaning.
2. Wipe all surfaces that had possible contact with contaminated materials with a paper towel wet with Liquinox[®] solution, then a towel wet with methanol solution, and finally three times with a towel wet with distilled water. Dispose of all used paper towels in a DOT-approved 55-gallon drum or with solid waste in garbage bags, dependent on Facility/project requirements.

E. SAMPLE CONTAINER DECONTAMINATION

The outsides of sample bottles or containers filled in the field may need to be decontaminated before being packed for shipment or handled by personnel without hand protection. The procedure is:

1. Wipe container with a paper towel dampened with Liquinox[®] solution or immerse in the solution AFTER THE CONTAINERS HAVE BEEN SEALED. Repeat the above steps using potable water.
2. Dispose of all used paper towels in a DOT-approved 55-gallon drum or with solid waste in garbage bags, dependent on Facility/project requirements.

F. HEAVY EQUIPMENT AND TOOLS

Heavy equipment such as drilling rigs, drilling rods/tools, and the backhoe will be decontaminated upon arrival at the site and between locations as follows:

1. Set up a decontamination pad in area designated by the Facility
2. Steam clean heavy equipment until no visible signs of dirt are observed. This may require wire or stiff brushes to dislodge dirt from some areas.

V. Attachments

None.

VI. Key Checks and Items

- Clean with solutions of Liquinox[®], Liquinox[®] solution (optional), and distilled water.
- Do not use acetone for decontamination.
- Drum all contaminated rinsate and materials.
- Decontaminate filled sample bottles before relinquishing them to anyone.

Disposal of Waste Fluids and Solids

I. Purpose and Scope

This SOP describes the procedures used to dispose of hazardous fluid and solid materials generated as a result of the site operations. This SOP does not provide guidance on the details of Department of Transportation regulations pertaining to the transport of hazardous wastes; the appropriate Code of Federal Regulations (49 CFR 171 through 177) should be referenced. Also, the site investigation-derived waste management plan should be consulted for additional information and should take precedence over this SOP.

II. Equipment and Materials

A. Fluids

- DOT-approved 55-gallon steel drums or Baker® Tanks
- Tools for securing drum lids
- Funnel for transferring liquid into drum
- Labels
- Paint Pens
- Marking pen for appropriate labels
- Seals for 55-gallon steel drums

B. Solids

- DOT-approved 55-gallon steel drums or rolloffs
- Tools for securing drum lids
- Paint Pens
- Plastic sheets
- Labels
- Marking pen for appropriate labels

III. Procedures and Guidelines

A. Methodology

Clean, empty drums or rolloffs or Baker® Tanks will be brought to the site by the drilling subcontractor for soil and groundwater collection and storage. The empty drums will be located at the field staging area and moved to drilling locations as required. The drums will be filled with the drilling and well installation wastes, capped, sealed, and moved to the onsite drum storage area by the drilling subcontractor. The full drums will separate types of wastes by media. The drums will

be labeled as they are filled in the field and labels indicating that the contents are pending analysis affixed.

The drum contents will be sampled to determine the disposal requirements of the drilling wastes. Check with the Environmental Manager (EM) assigned to the project prior to sample collection for frequency and analysis. Unless otherwise specified by the EM, the drum sampling will be accomplished through the collection and submittal of composite samples, one sample per 10 drums (check with disposal facility to determine sample frequency) containing the same media. Similar compositing will be performed in each rolloff to obtain a representative sample. The compositing of the sample will be accomplished by collecting a specific volume of the material in each drum into a large sample container. When samples from each of the drums being sampled in a single compositing are collected, the sample will be submitted for TCLP, ignitability, corrosivity, and reactivity analysis. Additional analysis may be required by your EM.

If rollofs are used, compositing and sampling of soil will comply with applicable state and federal regulations.

B. Labels

Drums and other containers used for storing wastes from drilling operations will be labeled when accumulation in the container begins. Analysis pending labels should be used initially. Labels will include the following minimum information:

- Container number
- Container contents
- Origin (source area including individual wells, piezometers, and soil borings)
- Date that accumulation began
- Date that accumulation ended
- Generator Contact Information
- When laboratory results are received, drum labels will be completed or revised to indicate the hazardous waste constituents in compliance with Title 40 of the Code of Federal Regulations, Part 262, Subpart C if the results indicate hazardous waste or labeled as non-hazardous if applicable.

C. Fluids

Drilling fluids generated during soil boring and groundwater discharged during development and purging of the monitoring wells will be collected in 55-gallon, closed-top drums. When a drum is filled, the bung will be secured tightly. Fluids may also be transferred to Baker® Tanks after being temporarily contained in drums to minimize the amount of drums used.

When development and purging is completed, the water will be tested for appropriate hazardous waste constituents as per instruction from the project EM. Compositing and sampling of fluids will comply with applicable state and federal regulations.

D. Solids

The soil cuttings from well and boring drilling will constitute a large portion of the solids to be disposed of.

The solid waste stream also will include plastic sheeting used for decontamination pads, Tyveks, disposable sampling materials, and any other disposable material used during the field operations that appears to be contaminated. These materials will be placed in designated drums.

E. Storage and Disposal

The wastes generated at the site at individual locations will be transported to the drum storage area by the drilling services subcontractor. Drums should be stored on plastic sheeting with a short berm wall (hay bales or 2 x 4 planks or equivalent) to capture small spills. The drums should be staged such that the labels are all visible and there should be enough room to walk between rows of drums if applicable.

Waste solid materials that contain hazardous constituents will be disposed of at an offsite location in a manner consistent with applicable solid waste, hazardous waste, and water quality regulations. Transport and disposal will be performed by a commercial firm under subcontract.

The liquid wastes meeting acceptable levels of discharge contamination may be disposed of through the sanitary sewer system at the site. However, prior to disposal to the sanitary sewer system, approval and contract arrangements will be made with the appropriate authorities. Wastes exceeding acceptable levels for disposal through the sanitary sewer system will be disposed of through contract with a commercial transport and disposal firm.

IV. Attachments

None.

V. Key Checks and Preventative Maintenance

- Contact the project Environmental Manager prior to containerizing waste to determine containerization method and sampling frequency and analysis.
- Check that representative samples of the containerized materials are obtained.
- Be sure that all state and federal regulations are considered when classifying waste for disposal.

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30

FIELD PROCEDURE 3

WATER SAMPLE COLLECTION FROM TREATMENT PLANT

During sampling activities, water samples will be collected from sample ports installed in the influent and effluent lines at the treatment plant. The effluent sample will be taken prior to taking the influent sample. Water quality measurements for pH, conductivity, and temperature will be collected immediately before sample collection in accordance with Field Procedure 1.

Following is the procedure for collecting an extraction well and treatment plant sample:

- Don a clean pair of gloves.
- Flush the sample port and obtain water quality measurements as instructed in Field Procedure 1.
- Open sample port to a slow flow rate (100 to 500 ml/minutes) in order to minimize sample agitation.
- Fill sample containers and close sample port.

Sample Bottle Filling Procedure

Sample container sizes and preservation requirements are listed in SAP Table 2-2. The sample containers will be obtained from the laboratory, containing chemical preservatives as applicable for some of the analytical parameters. The integrity of the sample containers will be checked after receipt from the laboratory.

Sample containers for VOCs will be filled at a slow rate to minimize agitation and aeration of water.

The following procedure will be followed for filling the sample containers:

- Don new, clean gloves.
- Label each sample container and double-check label to make sure the information is correct.
- Open sample containers and fill with water. Avoid contact between the bottle and sampling port. Samples will be collected in the following order (as applicable): VOCs then 1,4-dioxane. Note: For VOCs, which requires chemical preservation, transfer water into appropriate preserved containers. There must be zero headspace (no air bubbles) in the VOC vials.

- 1 • Tighten sample container lids hand-tight.
- 2 • Dry glassware after they are full and place immediately in cooler.

Installation of Surface-Cased Monitoring Wells

I. Purpose and Scope

The purpose of this procedure is to outline equipment and methods that will be used to install surface casings to isolate shallow intervals from deeper drilling. The guideline only addresses installation in unconsolidated materials. Installation of monitoring wells in bedrock is discussed in SOP *Installation of Bedrock Monitoring Wells* and installation of shallow, single-cased monitoring wells is discussed in SOP *Installation of Shallow Monitoring Wells*.

II. Equipment and Materials

Drilling

- Drilling rig (hollow stem auger, sonic, air rotary, or mud rotary).

Surface Casing

- 6-inch to 12-inch ID steel or Schedule 80 polyvinyl chloride (PVC) surface casing, depending upon application.
- Temporary bottom plug or grout shoe.
- Bentonite for grout: pure, additive-free powdered bentonite.
- Cement-Bentonite Grout. Proportion: 6 to 8 gallons of water per 94-pound bag of Portland cement; 3 pounds of bentonite added per bag of cement to reduce shrinkage.

Well Installation

- PVC, Schedule 40, minimum 2-inch ID, flush-threaded well riser; alternatively, stainless-steel riser.
- PVC, Schedule 40, minimum 2-inch ID, flush-threaded, factory slotted well screen; alternatively, stainless-steel screen.
- PVC or stainless steel bottom cap, threaded to match the well screen.
- Centering guides (if used); same material as the casing, except stainless steel may be used in lieu of PVC.
- Clean silica sand, provided in factory-sealed bags, well-rounded, containing no organic material, anhydrite, gypsum, mica, or calcareous material; primary (coarse – e.g., Morie #1) filter pack, and secondary (fine sand seal) filter pack. Grain size determined based on sediments observed during drilling.
- Bentonite seal: Pure, bentonite pellets or chips.

- Bentonite for grout: Pure, powdered bentonite.
- Cement-Bentonite Grout: Proportion 6 to 8 gallons of water per 94-pound bag of Portland cement; 3 pounds of bentonite added per bag of cement to reduce shrinkage.
- Above-grade well completion: PVC or stainless-steel well cap, threaded or push-on type, vented.
- Flush-mount well completion: PVC or stainless-steel well cap, locking, leak-proof seal.
- Above-grade protective casing: Permanent isolation casing with heavy duty locking cover, painted with epoxy paint for rust protection, industrial lock.
- Flush-mount protective casing: Morrison 9-inch or 12-inch 519 manhole cover; rubber seal for cover; heavy duty locking cap on permanent isolation casing.

Well Development

- Surge block.
- Pump and associated development equipment.
- Calibrated meters to measure pH, temperature, specific conductance, and turbidity of development water.
- Containerization for water produced from well.

III. Procedures and Guidelines

A. Drilling Methods

Boreholes for the surface casing can be drilled with hollow-stem auger, air rotary, or mud rotary. Boreholes will be drilled to various diameters, depending upon applications. In the case of temporary surface casing, where grout will not be used to install the casing, the borehole for the casing will be drilled with a method by which the borehole will be as close to the diameter of the surface casing as possible to minimize the size of the annular space. This may be by a rotary method or by using a hollow-stem auger with as small an inside diameter as possible. For permanent surface casing, typically hollow-stem auger will be used.

1. Hollow-Stem Auger Drilling

Hollow-stem auger (HSA) drilling techniques can be used to drill boreholes for installation of surface casing. The borehole will be drilled into a clay layer of significant thickness. Minimum 8-1/4-inch ID HSA will be used to drill the borehole a minimum of 5 feet into a clay layer of significant thickness.

The use of water or other fluid to assist in hollow-stem auger drilling is to be avoided.

The bit of the auger is placed at the ground surface and then turned with the drilling rig. To collect split-spoon or other samples, the auger is advanced to the top of the sampling depth, and the sample is collected from below the auger head. The split spoon is advanced through repeated blows from a 140-pound or 300-pound hammer dropped from a height of 30 inches. Thin-walled tube samplers are advanced by pressing down on the rods with the weight of the drilling rig. Split-spoon samples will be collected at selected intervals for chemical analysis and/or lithologic classification. Soil sampling procedures are detailed in SOPs *Soil Boring Sampling – Split Spoons* and *Soil Sampling*.

Material brought to the surface on the outside of the augers should be containerized at a convenient space away from the working area. Material may be stored on plastic sheeting and containerized at the completion of activities at the drilling location. Such material will be disposed of according to SOP *Disposal of Waste Fluids and Solids* and the Investigation Derived Waste Management Plan (IDWMP).

Drilling equipment will be decontaminated before drilling in accordance with the procedures detailed in SOP *Decontamination of Drilling Rigs and Equipment*.

2. Rotary Drilling

Mud rotary or other rotary drilling techniques can be used to install surface casing.

To collect split spoon samples, the drill bit is advanced to the depth to be sampled, the bit is removed from the borehole, and the split-spoon sample is collected from the borehole.

Drill cuttings and fluids generated during rotary drilling activities will be contained until completion of activities at the drilling location. Such material will be disposed of according to SOP *Disposal of Waste Fluids and Solids* and the IDWMP.

Drilling equipment will be decontaminated before drilling in accordance with the procedures detailed in SOP *Decontamination of Drilling Rigs and Equipment*.

B. Surface-Casing Installation

Surface casing will be constructed of minimum 6-inch ID or greater black iron steel with a minimum wall thickness of 0.20 inches or Schedule 80 PVC. Casing lengths for permanent surface casings will be welded or connected by threaded connections sealed with Teflon tape, while casing lengths for temporary surface casings will be either threaded connections of casing installed as part of the rotary-drilling method. The steel casing and threaded couplings must be free of paint, varnish, or coatings of any kind, both inside and outside. Threaded connections must be free of oils or grease. Welding of the casing is permissible provided that the welds meet the Standards of the American Welding Society.

Surface casing will be decontaminated prior to installation in accordance with the procedures detailed in *SOP Decontamination of Drilling Rigs and Equipment*.

Permanent surface casing will be placed in the bottom of the borehole and the surface casing will be pressed into a low permeability layer, if present. The surface casing will be grouted in place by installing the grout through a tremie pipe connected to the grout shoe, or placed at the bottom of the annulus.

Alternatively, the surface casing may be installed and grouted in place by a grout displacement method. The bottom of the surface casing is fitted with a tight, drillable plug. The borehole is then filled with the estimated volume of cement-bentonite grout to fill the annular space, and the casing is lowered to the bottom of the borehole (displacement method). If the weight of the casing is not sufficient to displace the grout and allow the casing to sink to the bottom of the borehole, the casing may be filled with clean water.

Well installation will proceed inside the surface casing once the grout has been allowed to cure for approximately 16 to 24 hours. All water in the surface casing will be removed before drilling resumes in order to prevent carrying contamination downward into deeper intervals of the water-bearing unit. All water in the casing will be disposed of according to *SOP Disposal of Waste Fluids and Solids* and the IDWMP before drilling is resumed.

Temporary surface casing installed independently of the drilling process also will be placed in the bottom of the borehole and the surface casing will be pressed into a low permeability layer, if present. However, it will not be grouted into place.

C. Monitoring-Well Installation

Typically, the well is completed within the surface casing using mud rotary techniques. Sonic drilling methods may also be used through permanent surface casings.

If the borehole has been drilled to a depth greater than that at which the well is to be completed, the borehole will be backfilled with bentonite pellets or chips or a bentonite-cement slurry to a depth approximately 1 foot below the intended well depth. Approximately 1 foot of clean sand will be placed on top of the bentonite to return the borehole to the correct depth for well installation.

The appropriate lengths of well screen, nominally 10 feet (with bottom cap), and casing will be lowered to the bottom of the borehole. Centering guides, if used, will be placed at intervals around the well casing, at the base of the screen, and 5 feet above the top of the well screen.

Selection of final filter pack and well screen depths for the wells shall be made in the field.

A primary sand pack consisting of clean Morie No. 00 (or DSI No.1) silica sand for 0.010-inch slotted screen and Morie No. 01 (or DSI No.2) silica sand for 0.020-inch slotted screen will be placed around the well screen. The sand will be placed into the borehole at a uniform rate, in a manner that will allow even

placement of the sand pack. During placement of the sand, the position of the top of the sand will be continuously sounded using a stainless steel weight attached to a tape measure. The primary sand pack will extend from the bottom of the borehole to a minimum of 2 feet above the top of the well screen. A secondary (fine sand seal) sand pack will then be installed to a minimum of 1 foot above the primary sand pack.

A bentonite seal at least 2 feet thick will be placed above the sand pack. The seal will be placed into the borehole in a manner that will prevent bridging. The position of the top of the bentonite seal will be verified using a weighted tape measure. A hydration period of at least 30 minutes will be allowed following installation of the bentonite seal.

Above the bentonite seal, an annular seal of cement-bentonite grout will be placed. The cement-bentonite grout will be installed continuously in one operation from the top of the bentonite seal to the ground surface. The cement-bentonite grout will be installed through a side-discharge tremie pipe plugged at the bottom. The openings in the tremie pipe will allow the grout to discharge laterally into the borehole and avoid disturbance the bentonite seal.

D. Monitoring-Well Completion

For monitoring wells that will be completed above-grade, the surface casing itself may serve as the protective casing. However, a separate steel protective casing may be used instead. The protective surface casing will be finished 2 to 3 feet above grade and fitted with a locking steel cap. A concrete pad with four guard posts will be installed.

The concrete pad will be square, approximately 2 feet per side (unless otherwise specified in the project plans), and poured into wooden forms. The concrete will be sloped away from the protective casing. The concrete pad will extend at least 6 inches below and 2 inches above the ground surface.

Four steel guard posts will be installed around the locking casing. Guard posts shall be concrete-filled, at least 2 inches in diameter, and extend at least 2 feet into the ground and 3 feet above the ground. The protective casing and guard posts will be painted with an epoxy paint to prevent rust.

For monitoring wells with flush-mount completions, a 8 to 12-inch dia. manhole cover with a rubber gasket and drain will be installed. The top of the manhole will be positioned approximately 1 inch above grade. A square concrete pad, approximately 2 feet per side (unless otherwise specified in the project plans), will be installed as a concrete collar surrounding the road box cover, and will slope uniformly downward to the adjacent grade. The road box and installation thereof will be of sufficient strength to withstand normal vehicular traffic. The concrete pad will extend at least 6 inches below the ground surface.

Inside the manhole, a locking cap will be placed on the inner well casing.

Each well will be labeled on the exterior of the locking cap with a metal stamp indicating the permanent well number.

E. Well Development

Well development will be accomplished using a combination of surging throughout the well screen and pumping, until the physical and chemical parameters of the discharge water that are measured in the field have stabilized and the turbidity of the discharge water is substantially reduced. Fine-grained materials in the surficial aquifer may not allow low turbidity results to be achieved.

The surging apparatus will include a tight-fitting surge block. Well development will begin by surging the well screen, starting at the bottom of the screen and proceeding upwards, throughout the screened zone. Following surging, the well will be pumped to remove the fine materials that have been drawn into the well. During pumping, measurements of pH, temperature, turbidity, and specific conductance will be recorded.

Development will continue by alternately surging and pumping until the discharge water is free from sand and silt, the turbidity is substantially reduced, and the pH, temperature, and specific conductance have stabilized at regional background levels, based on historical data. Development will continue for a minimum of one hour and until the water removed from the well is as clear of turbidity as practicable.

Well development equipment will be decontaminated prior to initial use and after the development of each well. Decontamination procedures are detailed in *SOP Decontamination of Personnel and Equipment*. Water generated during well development will be contained and managed as detailed in the *SOP Disposal of Waste Fluids and Solids* and the IDWMP.

IV. Attachments

Schematic diagram of double-cased monitoring-well construction (MWDDoubleDiag.xls)

General Guidance for Monitoring Well Installation

I. Purpose

To provide site personnel with a review of the well installation procedures that will be performed. These procedures are to be considered general guidelines only and are in no way intended to supplement or replace the contractual specifications in the driller's subcontract.

II. Scope

Monitoring well installations are planned for shallow and/or deep unconsolidated aquifers and/or for bedrock aquifers. The SOPs *Installation of Shallow Monitoring Wells*, *Installation of Surface-Cased Monitoring Wells*, *Installation of Bedrock Monitoring Wells*, and *Installation of Monitoring Wells Using Sonic Drilling* provide more specifics.

III. Equipment and Materials

1. Drilling rig (hollow stem auger, sonic, air hammer, air rotary, or mud rotary)
2. Well-construction materials (i.e., surface casing, screens, riser, casing, caps, bottom plugs, centering guides, sand, bentonite, grout, and surface-finish materials)
3. Development equipment

IV. Procedures and Guidelines

1. Wells will be installed in accordance with standard EPA procedures. Note that USEPA Region III requires any well penetrating a confining layer to be double-cased.
2. The threaded connections will be water-tight.
3. Well screens generally will be constructed of 10-slot or 20-slot Schedule 40 PVC and will be 5 to 10 feet in length depending on saturated thickness of unconsolidated sediments. The exact slot size and length will be determined by the field team supervisor. Stainless steel may be required under certain contaminant conditions.
4. Stick-up wells will be surrounded by four concrete-filled guard posts at least 2 inches in diameter.

5. A record of the finished well construction will be compiled.
6. All soils and liquids generated during well installations will be drummed for proper disposal.

Monitoring Well Installation

- 2" monitoring wells in unconsolidated materials will be installed in at least 6-inch-diameter boreholes to accommodate well completion materials in designated locations.
- All monitoring wells penetrating a confining layer will be surface-cased from the ground surface to approximately 5 feet into the confining layer. Exceptions to this may be allowed under certain circumstances (e.g., evidence of significant natural gaps in the confining layer).
- Monitoring wells in unconsolidated materials will be constructed of 2-inch-diameter, factory manufactured, flush-jointed, Schedule 40 PVC (or stainless steel) screen with threaded bottom plug and riser.
- Screens will be filter packed with a properly sized and graded, thoroughly washed, sound, durable, well-rounded basalt or siliceous sand. When using hollow-stem augers, the filter pack will be installed by slowly pouring the sand into the annular space while simultaneously raising the augers and using a weighted tape to sound for the sand surface. For rotary-drilled wells, the height of the sand pack also will be sounded with a weighted tape.
- The primary filter sand pack (typically Morie #00 or DSI #1 for a 10-slot screen) will extend from 1 to 2 feet below the base to 2 feet above the top of the screen; filter pack will be allowed to settle before final measurement is taken. For wells deeper than 30 feet, the filter pack will be placed using a tremie pipe and flowing water.

| Screen Size Opening (Inches) | Screen Size Slot Number | Typical Sand Pack Mesh Size (U.S. Standard Sieve Number) |
|------------------------------|-------------------------|--|
| 0.005 | 5 | 100 |
| 0.010 | 10 | 20 to 40 |
| 0.020 | 20 | 10 to 20 |
| 0.030 | 30 | 10 to 20 |

- A secondary filter sand pack (typically a fine sand seal) 1-foot thick may be placed above the primary sand pack.
- Annular well seals will consist of 2 feet of pelletized, chip, or granular bentonite clay placed above the filter pack. If necessary, the pellets will be hydrated using potable water. For wells installed using hollow-stem augers, the bentonite will be poured into the annular space while slowly raising the augers and sounding for the top of the bentonite with a weighted tape. A

high-solids bentonite slurry using powdered bentonite introduced with a side-discharging tremie pipe will be used for the bentonite seals in wells greater than 30 feet deep. For rotary-drilled wells, the height of the well seal also will be sounded with a weighted tape. High-solids slurries will have solids content of at least 20 percent.

- The top of the annular seal will be measured after the bentonite seal has been allowed to hydrate and before the grout is applied. The seal will be allowed to hydrate for at least 30 minutes before work in the well continues.
- The annular space above the bentonite seal will be filled to grade with a bentonite-cement slurry grout mixture.
- The grout mixture consists of 6 to 8 gallons of water per 94-pound bag of Portland cement; 3 to 6 pounds of bentonite added per bag of cement to reduce shrinkage. A grout density scale is recommended for determining the correct density. See attached grout volume and weights chart for calculation of grout volume.
- The grout mix will be carefully applied to avoid disturbing the bentonite seal; the method of grout placement must force grout from the top of the bentonite seal to ground surface.
- After allowing the grout to settle and set up overnight, additional grout will be added to maintain grade.
- A protective steel casing equipped with keyed alike locking caps will be grouted in place for each new well; the casing will extend at least 2 feet above grade and 3 feet below grade, and will be painted a bright color.

Well Development

- New monitoring wells will be developed after the well has been completely installed and the grout has hardened (at least 24 hours)
- The well will be developed by surging and pumping.
- Equipment placed in the well will be decontaminated before use.
- If information is available, begin developing in the least-contaminated well first.
- Development will include surging the well by either abruptly stopping flow and allowing water in the well column to fall back into the well or through the use of a surge block that is slightly smaller in diameter than the well casing inner diameter.
- Pipes and pumps must not be fitted with foot valves or other devices that might inhibit the return flow of water to the well.
- Surging should continue throughout the development process.

- The air-lift method may be used to pump materials out of the well. The air compressor will be fitted with filters to remove all oil and the air lift hose used will be made of inert materials.
- Well development will continue until the water produced is free of turbidity, sand, and silt. A Horiba-U22 meter, YSI meter with separate Hanna turbidity meter, or equivalent should be used to determine when the turbidity is low and parameters have stabilized.
- Development water will be considered hazardous and placed in sealed 55-gallon U.S. DOT approved steel drums. CH2M HILL will label and date the drums as pending analysis, and transport the drums to a designated site for storage.

V. Attachments

Grout Volume and Weights Chart

VI. Key Check and Items

- Ensure that all equipment is properly decontaminated as needed.
- Only new, sealed materials (e.g., screens, risers, and sand) will be used in constructing the well.
- Care shall be taken when making downhole measurements to ensure that proper heights of sand, seal, and grout are achieved.

Installation of Shallow Monitoring Wells

I. Purpose and Scope

The purpose of this guideline is to describe methods for drilling and installation of shallow monitoring wells and piezometers in unconsolidated or poorly consolidated materials using hollow stem augers, air rotary, or mud rotary. Installing monitoring wells in unconsolidated materials using sonic drilling is discussed in SOP *Installation of Monitoring Wells Using Sonic Drilling*. Methods for drilling and installing bedrock monitoring wells and deep, surface-cased wells in unconsolidated materials are presented in SOPs *Installation of Bedrock Monitoring Wells* and *Installation of Surface-Cased Monitoring Wells*, respectively.

II. Equipment and Materials

Drilling

- Drilling rig (hollow stem auger, air rotary or mud rotary) and associated tools and equipment

Well Riser/Screen and Associated Materials

- Polyvinyl chloride (PVC), Schedule 40, minimum 2-inch ID, flush-threaded riser; alternatively, stainless-steel riser
- PVC, Schedule 40, minimum 2-inch ID, flush-threaded, factory slotted screen; alternatively, stainless-steel screen
- PVC bottom cap, threaded to match the well screen; alternatively, stainless steel
- PVC or stainless-steel centering guides (if used)
- Above-grade well completion: PVC well cap, threaded or push-on type, vented
- Flush-mount well completion: PVC well cap, locking, leak-proof seal
- Stainless steel to be used as appropriate

Sand

- Clean silica sand, provided in factory-sealed bags, well-rounded, containing no organic material, anhydrite, gypsum, mica, or calcareous material; primary (coarse – e.g., Morie #1) filter pack, and secondary (fine sand seal) filter pack. Grain size determined based on sediments observed during drilling.

Bentonite

- Pure, additive-free bentonite pellets or chips
- Pure, additive-free powdered bentonite
- Coated bentonite pellets; coating must biodegrade within 7 days

- Cement-Bentonite Grout: proportion of 6 to 8 gallons of water per 94-pound bag of Portland cement; 3 to 6 pounds of bentonite added per bag of cement to reduce shrinkage.

Protective Casing

- Above-grade well completion: 6-inch minimum ID black iron steel pipe with locking cover, diameter at least 2 inches greater than the well casing, painted with epoxy paint for rust protection; heavy duty lock; protective posts if appropriate
- Flush-mount well completion: Morrison 9-inch or 12-inch 519 manhole cover, or equivalent; rubber seal to prevent leakage; locking cover inside of road box

Well Development

- Surge block
- Well-development pump and associated equipment
- Calibrated meters to ensure pH, temperature, specific conductance, ORP, and dissolved oxygen of development water
- Containers (e.g., DOT-approved 55-gallon drums) for water produced from well.

III. Procedures and Guidelines

A. Drilling Method

Typically, continuous-flight hollow-stem augers with a minimum 4.25-inch inside diameter (ID) will be used to drill shallow monitoring well boreholes for 2-inch diameter monitoring wells. Alternatively, air or mud rotary may be used.

The bit of the auger is placed at the ground surface and then turned with the drilling rig. To collect split spoon samples, the auger is advanced to the top of the sampling depth, and the split-spoon sample is collected from below the auger head. The split spoon is advanced through repeated blows from a 140- or 300-pound hammer dropped from a height of 30 inches. Thin-walled tube samplers are advanced by pressing down on the rods with the weight of the drilling rig. Split-spoon samples may be collected at selected intervals for chemical analysis and/or lithologic classification. Soil sampling procedures are detailed in SOPs *Soil Boring Sampling – Split Spoons* and *Soil Sampling*.

The use of water to assist in hollow-stem auger drilling for monitoring well installation will be avoided, unless required for such conditions as running sands.

Hollow-stem augers, drilling bits, rods, split-spoon samplers, and other downhole drilling tools will be properly decontaminated prior to the initiation of drilling activities and between each borehole location. Split-spoon samplers and other downhole soil sampling equipment will also be

properly decontaminated before and after each use. SOP *Decontamination of Drill Rigs and Equipment* details proper decontamination procedures.

Drill cuttings and decontamination fluids generated during well drilling activities will be contained according to the procedures detailed in the SOP *Disposal of Waste Fluids and Solids* and the Investigation Derived Waste Management Plan (IDWMP).

Air or mud rotary drilling may be used instead of hollow-stem augers. The use of added mud should be kept to a minimum.

B. Monitoring-Well Installation

Shallow monitoring wells will be constructed inside the hollow-stem augers, once the borehole has been advanced to the desired depth, or in the mudded borehole once the drilling rods have been withdrawn. If the borehole has been drilled to a depth greater than that at which the well is to be set, the borehole will be backfilled with bentonite pellets or chips or a bentonite-cement slurry to a depth approximately 1 foot below the intended well depth. Approximately 1 foot of clean sand will be placed on top of the bentonite to return the borehole to the proper depth for well installation.

The appropriate lengths of well screen, nominally 10 feet (with bottom cap), and casing will be joined watertight and lowered inside the augers to the bottom of the borehole. Centering guides, if used, will be placed at the bottom of the screen and above the interval in which the bentonite seal is placed.

Selection of the filter pack and well screen intervals for the shallow monitoring wells shall be made in the field.

A primary sand pack consisting of clean Morie No. 00 (or DSI No.1) silica sand for 10-slot screen and Morie No. 01 (or DSI No.2) for 20-slot screen silica sand will be placed around the well screen. The sand will be placed into the borehole at a uniform rate, in a manner that will allow even placement of the sand pack. The augers will be raised gradually during sand pack installation to avoid caving of the borehole wall; at no time will the augers be raised higher than the top of the sand pack during installation. During placement of the sand, the position of the top of the sand will be continuously sounded.

The primary sand pack will be extended from the bottom of the borehole to a minimum height of 2 feet above the top of the well screen. A secondary, finer-grained (fine sand seal), sand pack will be installed for a minimum of 1 foot above the coarse sand pack. Heights of the coarse and fine sand packs and bentonite seal may be modified in the field to account for a shallow water table and a small saturated thickness of the surficial aquifer.

A bentonite seal at least 2 feet thick will be placed above the sand pack. The seal will be placed into the borehole in a manner that will prevent bridging. The position of the top of the bentonite seal will be verified using a weighted tape measure. If all or a portion of the bentonite seal is above the water table,

clean water will be added to hydrate the bentonite. A hydration period of at least 30 minutes will be required following installation of the bentonite seal.

Above the bentonite seal, an annular seal of cement-bentonite grout will be placed. The cement-bentonite grout will be installed continuously in one operation from the bottom of the space to be grouted to the ground surface through a tremie pipe. The tremie pipe must be plugged at the bottom and have small openings along the sides of the bottom 1-foot length of pipe. This will allow the grout to diffuse laterally into the borehole and not disturb the bentonite pellet seal.

C. Well Completion

For monitoring wells that will be completed above-grade, a locking steel protective casing set in a concrete pad will be installed. The steel protective casing will extend at least 3 feet into the ground and 2 feet above ground but should not penetrate the bentonite seal. The concrete pad will be square, approximately 2 feet per side (unless otherwise specified in the project plans), and poured into wooden forms. The concrete will be sloped away from the protective casing.

Guard posts may be installed in high-traffic areas for additional protection. Four steel guard posts will be installed around the protective casing. Guard posts would be concrete-filled, at least 2 inches in diameter, and would extend at least 2 feet into the ground and 3 feet above the ground. The protective casing and guard posts will be painted with an epoxy paint to prevent rust.

For monitoring wells with flush-mount completions, Morrison 9-inch or 12-inch 519 manhole cover or equivalent, with a rubber-sealed cover and drain will be installed. The top of the manhole cover will be positioned approximately 1 inch above grade. A square concrete pad, approximately 2 feet per side (unless otherwise specified in the project plans), will be installed as a concrete collar surrounding the road box cover, and will slope uniformly downward to the adjacent grade. The road box and installation thereof will be of sufficient strength to withstand normal vehicular traffic.

Concrete pads installed at all wells will be a minimum of 6 inches below grade. The concrete pad will be 12 inches thick at the center and taper to 6-inch thick at the edge. The surface of the pad should slope away from the protective casing to prevent water from pooling around the casing. Protective casing, guard posts, and flush mounts will be installed into this concrete.

Each well will be properly labeled on the exterior of the locking cap or protective casing with a metal stamp indicating the permanent well number.

D. Well Development

Well development will be accomplished using a combination of surging throughout the well screen and pumping, until the physical and chemical parameters of the discharge water that are measured in the field have

stabilized and the turbidity of the discharge water is substantially reduced. Fine-grained materials in the surficial aquifer at the site may not allow low turbidity results to be achieved.

The surging apparatus will include a surge block. Well development will begin by surging the well screen, starting at the bottom of the screen and proceeding upwards, throughout the screened zone. Following surging, the well will be pumped to remove the fine materials that have been drawn into the well. During pumping, measurements of pH, temperature, and specific conductance will be recorded.

Development will continue by alternately surging and pumping until the discharge water is free from sand and silt, the turbidity is substantially reduced, and the pH, temperature, and specific conductance have stabilized at regional background levels, based on historical data. Development will continue for a minimum of 30 minutes and until the water removed from the well is as clear of turbidity as practicable.

Well development equipment will be decontaminated prior to initial use and after the development of each well. Decontamination procedures are detailed in SOP *Decontamination of Personnel and Equipment*. Water generated during well development will be contained and managed as detailed in the SOP *Disposal of Waste Fluids and Solids* and the Investigation Derived Waste Management Plan.

IV. Attachments

Schematic diagram of shallow monitoring-well construction (MWSingleDiag.xls)

1 **FIELD SAMPLING PROTOCOLS TO AVOID CROSS-CONTAMINATION DURING WATER SAMPLING**
2 **FOR PERFLUORINATED COMPOUNDS (PFCs)**

3 **1.0 PURPOSE**

4 While EPA method 537 provides basic guidance on sampling for PFC's in drinking water, due to
5 the potential for cross contamination this Standard Operating Procedure (SOP) addendum
6 describes additional precautionary procedures/considerations when collecting groundwater or
7 drinking water samples. Sampling specific SOPs should also be reviewed prior to conducting
8 field sampling activities at PFC sites.

9 **2.0 SCOPE**

10 This procedure applies to all qualified personnel and subcontractors who collect or otherwise
11 handle water samples for analysis of PFCs. This SOP should be reviewed by all on-site
12 personnel prior to implementation of field activities.

13 **3.0 GENERAL**

14 Given the low detection limits associated with PFC analysis and the many potential sources of
15 trace levels of PFCs, field personnel are advised to act on the side of caution by strictly following
16 these protocols, frequently replacing nitrile gloves, and rinsing field equipment to help mitigate
17 the potential for background contamination detections of PFCs. Specific items related to field
18 sampling are discussed below.

19 **4.0 PROCEDURES/CONSIDERATIONS**

20 The following are procedures/considerations to be made during field activities at potential PFC
21 release sites.

22 **Field Equipment**

- 23
- 24 • **Do not use Teflon®-containing materials** (e.g., Teflon® tubing, bailers, tape, plumbing
25 paste, or other Teflon® materials) since Teflon® contains fluorinated compounds.
 - 26 • High-density polyethylene (HDPE), low-density polyethylene (LDPE), and silicon
27 materials are acceptable for sampling. Samples should not be stored in containers made
28 of LDPE materials.
 - 29 • To avoid plastic coating or glue materials, **do not use waterproof field books**. Field
30 reports should be documented on loose paper on masonite or aluminum clipboards (i.e.
31 plastic clipboards, binders, or spiral hard cover notebooks are not acceptable).
32 Sharpies®/markers should be avoided.
 - **Post-It Notes are not allowed** on project sites.

- 33 • **Do not use markers.** Pens should be used when documenting field activities in the field
34 log and on field forms as well as labeling sample containers and preparing the Chain of
35 Custody.
- 36 • **Do not use chemical (blue) ice packs** during the sampling program. This includes the
37 use of ice packs for the storage of food and/or samples.

38 **Field Clothing and Personal Protective Equipment**

- 39 • **Do not wear water resistant, waterproof, or stain-treated clothing** during the field
40 program. Field clothing made of synthetic and natural fibers (preferably cotton) are
41 acceptable. Field clothing should be laundered avoiding the use of fabric softener.
42 Preferably, field gear should be cotton construction and well laundered (a minimum of 6
43 times from time of purchase). New clothing may contain PFC related treatments. **Do**
44 **not use new clothing** while sampling or sample handling.
- 45 • **Do not wear clothing or boots containing Gore-Tex™** during the sampling program as it
46 consists of a PFC membrane.
- 47 • All safety footwear will consist of steel-toed boots made with polyurethane and
48 polyvinyl chloride (PVC).
- 49 • **Do not wear Tyvek® clothing** on-site since it contains fluorinated compounds.
- 50 • Disposable nitrile gloves must be worn at all times. Further, a new pair of nitrile gloves
51 should be donned prior to the following activities at each sample location:
 - 52 - Decontamination of re-usable sampling equipment;
 - 53 - Prior to contact with sample bottles or water containers;
 - 54 - Insertion of anything into the well (e.g. HDPE tubing, HydraSleeve bailer, etc.);
 - 55 - Insertion of silicon tubing into the peristaltic pump;
 - 56 - Completion of monitor well purging, prior to sample collection;
 - 57 - Handling of any quality assurance/quality control samples including field blanks and
58 equipment blanks; and,
 - 59 - After the handling of any non-dedicated sampling equipment, contact with non-
60 decontaminated surfaces, or when judged necessary by field personnel.

61 **Sample Containers**

- 62 • Samples should be collected in polypropylene or HDPE bottles fitted with an unlined (no
63 Teflon®), polypropylene HDPE screw cap. This is an especially important point as many
64 laboratories utilize Teflon-lined bottles.
- 65 • Container labels will be completed using pen (**NO MARKERS**) after the caps have been
66 placed back on each bottle.

- 67 • Glass containers should also be avoided due to potential loss of analyte through
68 adsorption.

69 **Wet Weather**

- 70 • Field sampling occurring during wet weather (e.g., rainfall and snowfall) should be
71 conducted while wearing appropriate clothing that will not pose a risk for cross-
72 contamination. Teams should avoid synthetic gear that has been treated with water-
73 repellant finishes containing PFCs. Use rain gear made from polyurethane and wax-
74 coated materials.

75 **Equipment Decontamination**

76 For GW sampling, it is highly recommended that disposable equipment be utilized. However, if
77 equipment re-use is performed, field sampling equipment, including oil/water interface meters
78 and water level indicators, that are utilized at each sample location will require cleaning
79 between uses. Alconox® and Liquinox® soap is acceptable for use since the Material Safety
80 Data Sheets do not list fluoro-surfactants as an ingredient. However, **Decon 90 must not be**
81 **used** during decontamination activities. Water used for the decontamination of sampling
82 equipment will be laboratory certified “PFC-free” water.

83 **Personnel Hygiene**

- 84 • Field personnel should not use cosmetics, moisturizers, hand cream, or other related
85 products as part of their personal cleaning/showering routine on the morning of a
86 sampling event, as these products may contain surfactants and represent a potential
87 source of PFCs.
- 88 • Many manufactured sunblock and insect repellants contain PFCs and should not be
89 brought or used on-site. Sunblock and insect repellants that are used on-site should
90 consist of 100% natural ingredients.

91 **Food Considerations**

- 92 • No food or drink shall be brought on-site, with the exception of bottled water and
93 hydration drinks (i.e., Gatorade® and Powerade®).

94 **Blanks**

- 95 • Utilization of blanks is a good quality check to monitor and control the effects of
96 contamination. Trip blanks and field blanks are recommended.

97 **REFERENCES**

- 98 • Transport Canada, 2013. *Perfluorochemical (PFC) Field Sampling Protocol*. May.

99 • Delta Consultants, 2010. *Report of Investigation Activities at Select Firefighting Foam*
100 *Training Areas and Foam Discharge Sites in Minnesota*. February.
101 • MPCA, 2008. *Closed Landfill Program Sampling Protocol for Monitoring Wells*. October.
102 • Oregon State University, 2015. *COLLECTION AND HANDLING OF SAMPLES FOR*
103 *FLUORO-CHEMICAL ANALYSIS*. July.
104 • EPA, 2009. EPA Document #: EPA/600/R-08/092, *METHOD 537. DETERMINATION OF*
105 *SELECTED PERFLUORINATED ALKYL ACIDS IN DRINKING WATER BY SOLID PHASE*
106 *EXTRACTION AND LIQUID CHROMATOGRAPHY/TANDEM MASS SPECTROMETRY*
107 *(LC/MS/MS)*. Version 1.1. September
108
109

Water-Level Measurements

I. Purpose and Scope

The purpose of this procedure is to provide a guideline for the measurement of the depth to groundwater in piezometers and monitoring wells, even where a second phase of floating liquid (e.g., gasoline) is encountered, and on staff gages in surface-water bodies. This SOP includes guidelines for discrete measurements of static water levels and does not cover the use of continuously recording loggers (see SOP *Use of Data Loggers and Pressure Transducers*).

II. Equipment and Materials

- Electronic water-level meter (Solinst® or equivalent) with a minimum 100-foot tape; the tape should have graduations in increments of 0.01 feet or less
- Interface probe (Solinst® Model 122 Interface Meter or equivalent)

III. Procedures and Guidelines

Verify that the unit is turned on and functioning properly. Slowly lower the probe on its cable into the piezometer or well until the probe just contacts the water surface; the unit will respond with a tone or light signal. Note the depth from a reference point indicated on the piezometer or well riser. Typically, this is the top of the PVC casing. If no reference is clearly visible, measure the depth to water from the northern edge of the PVC casing. If access to the top of the PVC casing is difficult, sight across the top of the locking casing adjacent to the measuring point, recording the position of the cable when the probe is at the water surface.

Measure the distance from this point to the closest interval marker on the tape, and record the water level reading in the logbook. Water levels will be measured to the nearest 0.01-foot. Also when specified in the project plans, measure and record the depth of the piezometer or well. The depth of the piezometer or well may be measured using the water-level probe with the instrument turned off.

Free product light or dense nonaqueous phase liquid may be present in the piezometer or well. If the presence of free product is suspected, the thickness of the product should be determined using appropriate equipment (e.g., Solinst® Model 122 Interface Meter). The depth to water also is determined with this equipment and the water-level meter should not be used in the piezometer or well as long as product is present. Typically, a constant sound is emitted from the device when free product is encountered and an alternating on/off beep sound is emitted when water is encountered.

The apparent elevation of the water level in the well or piezometer is determined by measuring both the apparent depth to water and the thickness of free product. The corrected water-level elevation is calculated by the following equation:

$$WL_c = WL_a + (\text{Free-product thickness} \times 0.80)$$

Where WL_c = Corrected water-level elevation

WL_a = Apparent water-level elevation

0.80 = Typical value for the density of petroleum hydrocarbon products.

If free product is detected on the surface of the water in the piezometer or well, the value of sampling should be reconsidered because of the potential for contaminating the sampling equipment.

Staff gages may be installed in some surface-water bodies. These facilities typically are constructed by attaching a calibrated, marked staff gage to a wood or metal post, driving the post into the bottom of the surface-water body, and surveying the elevation of the top of the post to a resolution or 0.01-foot. The elevation of the water in the surface-water body then can be determined by reading off the distance the water level is from the top of the post. A shield or other protection may be needed to calm the fluctuations in water level if the gage is installed at a location exposed to wind or wave.

IV. Attachments

None.

V. Key Checks

- Before each use, verify that the battery is charged by pressing the test button on the water-level meter.
- Verify that the unit is operating correctly by testing the probe in distilled or de-ionized water. Leave the unit turned off when not in use.

Packaging and Shipping Procedures for Low-Concentration Samples

I. Purpose and Scope

The purpose of this guideline is to describe the packaging and shipping of low-concentration samples of various media to a laboratory for analysis.

II. Scope

The guideline only discusses the packaging and shipping of samples that are anticipated to have low concentrations of chemical constituents. Whether or not samples should be classified as low-concentration or otherwise will depend upon the site history, observation of the samples in the field, odor, and photoionization-detector readings.

If the site is known to have produced high-concentration samples in the past or the sampler suspects that high concentrations of contaminants might be present in the samples, then the sampler should conservatively assume that the samples cannot be classified as low-concentration. Samples that are anticipated to have medium to high concentrations of constituents should be packaged and shipped accordingly.

If warranted, procedures for dangerous-goods shipping may be implemented. Dangerous goods and hazardous materials pose an unreasonable risk to health, safety, or property during transportation without special handling. As a result, only employees who are trained under CH2M HILL Dangerous Goods Shipping course may ship or transport dangerous goods. Employees should utilize the HAZMAT ShipRight tool on the Virtual Office and/or contact a designated CH2M HILL HazMat advisor with questions.

III. Equipment and Materials

- Coolers
- Clear tape
- "This Side Up" labels
- "Fragile" labels
- Vermiculite
- Ziplock bags or bubble wrap
- Ice
- Chain-of-Custody form (completed)
- Custody seals

IV. Procedures and Guidelines

Low-Concentration Samples

- A. Prepare coolers for shipment:
 - Tape drains shut.
 - Affix "This Side Up" labels on all four sides and "Fragile" labels on at least two sides of each cooler.
 - Place mailing label with laboratory address on top of coolers.
 - Fill bottom of coolers with about 3 inches of vermiculite or absorbent pads.
- B. Arrange decontaminated sample containers in groups by sample number. Consolidate VOC samples into one cooler to minimize the need for trip blanks.
- C. Affix appropriate adhesive sample labels to each container. Protect with clear label protection tape.
- D. Seal each sample bottle within a separate ziplock plastic bag or bubble wrap, if available. Tape the bag around bottle. Sample label should be visible through the bag.
- E. Arrange sample bottles in coolers so that they do not touch.
- F. If ice is required to preserve the samples, cubes should be repackaged in zip-lock bags and placed on and around the containers.
- G. Fill remaining spaces with vermiculite or absorbent pads.
- H. Complete and sign chain-of-custody form (or obtain signature) and indicate the time and date it was relinquished to Federal Express or the courier.
- J. Close lid and latch.
- K. Carefully peel custody seals from backings and place intact over lid openings (right front and left back). Cover seals with clear protection tape.
- L. Tape cooler shut on both ends, making several complete revolutions with strapping tape. Cover custody seals with tape to avoid seals being able to be peeled from the cooler.
- M. Relinquish to Federal Express or to a courier arranged with the laboratory. Place airbill receipt inside the mailing envelope and send to the sample documentation coordinator along with the other documentation.

Medium- and High-Concentration Samples:

Medium- and high-concentration samples are packaged using the same techniques used to package low-concentration samples, with potential additional restrictions. If applicable, the sample handler must refer to instructions associated with the shipping of dangerous goods for the necessary procedures for shipping by Federal Express or other overnight carrier. If warranted, procedures for dangerous-goods shipping may be implemented. Dangerous goods and hazardous materials pose an unreasonable risk to health, safety, or property during transportation without special handling. As a result, only employees who are trained under CH2M HILL Dangerous Goods Shipping course may ship or transport dangerous goods. Employees should utilize the HAZMAT ShipRight tool on the Virtual Office and/or contact a designated CH2M HILL HazMat advisor with questions.

V. Attachments

None.

VI. Key Checks and Items

- Be sure laboratory address is correct on the mailing label
- Pack sample bottles carefully, with adequate vermiculite or other packaging and without allowing bottles to touch
- Be sure there is adequate ice
- Include chain-of-custody form
- Include custody seals

Geopump Peristaltic Pump

Installation and Operation Manual



Table of Contents

| | |
|---|----|
| Section 1: System Description | 5 |
| Section 2: System Installation | 6 |
| Section 3: System Operation | 8 |
| Section 4: System Maintenance | 9 |
| Section 5: System Troubleshooting | 10 |
| Section 6: System Specifications | 11 |
| Section 7: System Schematics | 12 |
| Section 8: Replacement Parts List | 13 |
| Warranty and Repair | 15 |

DOCUMENTATION CONVENTIONS

This document uses the following conventions to present information:



WARNING

An exclamation point icon indicates a **WARNING** of a situation or condition that could lead to personal injury or death. You should not proceed until you read and thoroughly understand the **WARNING** message.



CAUTION

A raised hand icon indicates **CAUTION** information that relates to a situation or condition that could lead to equipment malfunction or damage. You should not proceed until you read and thoroughly understand the **CAUTION** message.



NOTE

A note icon indicates **NOTE** information. Notes provide additional or supplementary information about an activity or concept.

NOTICES



In order to ensure your Geopump has a long service life and operates properly, adhere to the following cautions and read this manual before use.

- **Disconnect from power source when not in use.**
- **Power input source must not exceed maximum ratings.**
- **Equipment must be wired to a negative ground system.**
- **Equipment may not operate properly with excess wiring not supplied by manufacturer .**
- **Avoid spraying fluid directly at equipment.**
- **Never submerge equipment.**
- **Avoid pulling on wires to unplug equipment wiring.**
- **Avoid using equipment with obvious physical damage.**
- **To prevent equipment damage, avoid dropping it.**



The Geotech Geopump Peristaltic Pump cannot be made dangerous or unsafe as a result of failure due to EMC interference.



WARNING

Do not operate this equipment if it has visible signs of significant physical damage other than normal wear and tear.



Notice for consumers in Europe:

This symbol indicates that this product is to be collected separately.

The following applies only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the seller or the local authorities in charge of waste management.

Section 1: System Description

Function and Theory

The Geotech Series I and II Peristaltic Pumps (Geopump) are designed for single and multi-stage pressure or vacuum pumping of liquids for field or laboratory use. Since the Geopump can operate to a depth of 27 feet (8m) at sea level, it is ideally suited for sample removal from shallow wells and all surface water sources.

The Geopump operates by mechanical peristalsis, therefore the sample only comes in contact with the tubing. This allows for sample integrity as well as easy cleaning and tubing replacement. Tubing can also be lowered to a specific depth without curling or floating on the surface of the water with the use of an optional stainless steel tubing weight.

Differences between the two models affect the number of pump heads which may be used with the Geopump at one time and the speed(s) at which the pump heads operate. Therefore, the instructions for general operations will be covered only once.

System Components

SERIES I Peristaltic Pumps are available in AC only, DC only, or an AC/DC combination. These units have one pumping station which can also be piggy-backed for multi-station pumping. The variable speed range is from 0 RPM to 350 RPM.

SERIES II Peristaltic Pumps are available in AC only, DC only, or an AC/DC combination. They have two pumping stations which can also be piggy-backed. The first pumping station is rated at 0 RPM to 350 RPM and the second station at 0 RPM to 600 RPM. Each pumping station works in conjunction with the other.

Section 2: System Installation

Standard Pump Head Instructions

1. Separate the pump halves. Hold the pump head as shown with the rollers in the 2, 6, and 10 o'clock positions and the rotor shaft facing down.



2. Place the tubing around the rollers.



3. Turn rotor counterclockwise until tubing completely surrounds the rotor.
4. The tubing is now in place. Next, position other pump half onto the motor shaft and snap shut. Be careful not to pinch tubing between plastic halves.



Easy-Load II Pump Head Instructions

1. Attach the Easy-Load II pump to the Geopump with the screws provided.
2. Set the lever to the left to open the pump. Place the tubing left to right.



3. Set the lever to the right to close the pump housing onto the tubing.



Section 3: System Operation

The Geopump arrives packed in a hard-shell peristaltic pump carry case with the pump head properly attached to the pump (purchased separately). See Section 8 on available pump parts.

To place the pump into service:

1. Remove the pump from the case and verify the pump is switched to “OFF” (red, open circle)
2. For AC/DC combination units, plug in the appropriate power cord into the outlet in the back of the pump and the other end of the power cord into the power source.
3. Insert the tubing into the pump head.
4. Put one end of the tubing into the sample source (well, river, ditch, lagoon, etc.) and the other end into the sample container.
5. Determine the desired direction of flow and set the toggle switch for the flow direction.
6. Turn the pump “ON” (the black filled circle).
7. Once pumping has begun, the speed dial can be adjusted to increase or reduce the fluid pumping speed as needed.

Section 4: System Maintenance

The Geopump has a strong reputation for durability and being virtually maintenance free. The following maintenance steps will assure your pump's long-term reliability:

Pump Tubing:

Depending on the pump head design, different sizes of tubing may be used. Use of incorrect tubing, size, or type, will cause damage to the pump and/or the pump head and void the warranty. Geotech recommends regular tubing replacement for optimum performance. Using the proper size and type of tubing for the pump head is essential. If you are unsure of the tubing type for your application, please call Geotech.

Pump:

Keep your Geopump clean and dry. In the event that the Geopump is subjected to significant splashing or immersion, discontinue use and wipe the unit down immediately with a clean dry cloth.

To keep your Geopump reliable follow these simple guidelines:

- Do not drop your Geopump.
- Do not immerse your Geopump.
- Do not subject your Geopump to poor power supplies.
- Do not subject your Geopump to extreme heat or cold when in use.

Power Cords:

Always replace a kinked or damaged power cord. Replacement power cords are available for AD/DC combination units. Units with a hard-wired power cord are to be sent back to Geotech for proper repair. Refer to the Geotech Warranty and Repair page in the back of this manual.

Pump Head:

Clean the Geopump pump head periodically using a phosphate-free cleaning detergent and water solution.

Section 5: System Troubleshooting

Problem: Unit will not turn on.

Solution:

1. No power to unit: (rollers not moving):
 - Check power source and compatibility.
 - Check connections.
2. Speed control not set fast enough to overcome tubing resistance:
 - Check speed setting; if too low turn it up.
3. Check tubing size and type. Make sure it is the correct size and type for the pump head.
4. Check circuit breaker; if tripped press it in to reset.

Problem: Unit turns on, but not pumping (pump head rollers are moving).

Solution:

1. Verify fluid level in well (max suction lift unit can pump from is 27 feet (8m) below ground at sea level).
2. Water level is below down well tubing intake. Increase tubing length.
3. If using a combination of flexible and rigid tubing, check connection between tubing. A poor connection may cause a vacuum leak. Secure tubing connection.
4. Flexible tubing in pump head compromised or worn out:
 - Replace flexible tubing regularly.
5. Obstruction in tubing:
 - Check for clogs and kinks.
 - Clear any obstructions.
6. Using incorrect tubing type for pump head:
 - Tubing may have collapsed.
 - Replace with proper tubing type.

Problem: Pump head rollers are not moving .

Solution:

1. Pump head is loose from the pump housing:
 - Tighten pump head screws to engage pump head to gear.
 - Possible internal damage, call Geotech for consultation.


Section 6: System Specifications

| | |
|---------------------------|---|
| Operating range | 27 feet (8m) (at sea level) |
| Principle of Operation | Mechanical peristalsis |
| Dimensions | 3.5 x 8 x 8 inches (9 x 20 x 20cm) |
| Power source (DC) | Any rated external 12-18 VDC @ 70 Watts |
| Power source (AC) | 90-260 VAC, 47-65 Hz |
| Nominal operating current | 3 amps DC |
| Over current Protection | 5 amps DC |
| Power cord | 12 VDC cord |
| Range of speed: Series I | 0 to 350 RPM |
| Range of speed: Series II | First pumping station 0 to 350 RPM Second pumping station 0 to 600 RPM |
| Speed control | Step-less variable speed control |
| Liquid delivery rate | 1.67 ml per revolution (for size 15 tubing) |
| Pumping options | Pressure or vacuum (reversible flow) |
| Pump head rotor | Cold rolled steel |

OPTIONS

| | |
|-------------|--------------------------------|
| Models: | Geopump 1, Geopump 2 |
| Tubing: | Silicone, Tygon, Viton, C-Flex |
| Pump Heads: | Standard, Easyload, Easyload 2 |

Section 7: System Schematics



Section 8: Parts and Accessories

Schematic Parts Listing (Section 7)

| Item | QTY | Part Number | Part Description |
|------|-----|-------------|---|
| 1 | 1 | 51350001 | Assy, Gear Housing, Series I |
| 2 | 1 | 51350002 | Assy, Gear Housing, Series II |
| 3 | 1 | 51350003 | Assy, Motor, PP |
| 4 | 1 | 51350012 | Assy, Housing, Bottom, PP |
| 5 | 1 | 51350023 | Housing, Top, Silk Screened |
| 6 | 4 | 17500042 | Foot, RBR, 9/32" Hole Dia |
| 7 | 1 | 11350005 | Breaker, Thermal, 5amp, Circuit 250V |
| 8 | 1 | 51350011 | Assy, Rheostat |
| 9 | 1 | 11350020 | Switch, Toggle, Dpdt, Frwd/Rvrs |
| 10 | 1 | 11350021 | Switch, Toggle, Dpst, On/Off |
| 11 | 1 | 11350010 | Knob, Plastic, Rheostat |
| 12 | 1 | 51350033 | Assy, Wiring Harness, PP |
| 13 | 2 | 17500037 | Boot, RBR, Toggle Switch, Grey |
| 14 | 1 | 11350009 | Handle, PE, NI |
| 15 | 1 | 11350015 | Plate, AL, 1.5x1.5, Hardwire, Cord, Painted |
| 16 | 2 | 00114 | Screw, SS8, 4-40x3/8", FHD |
| 17 | 1 | 11350019 | Grommet, RBR, 5/16x1/2", 1/4" Thick Hole |
| 18 | 1 | 17500040 | Cord, SJOW, DC Power, 18-2 |
| 19 | 4 | 17500366 | Screw, SS8, 8-32x3/8", SHCS |
| 20 | 4 | 17200081 | Washer, SS8, #8, Lock |
| 21 | 2 | 17200046 | Nut, Hex, 4-40, Nyloc |
| 22 | 8 | 17200078 | Screw, SS8, 6-32x.25", PNH, M/S |
| 23 | 20 | 17200077 | Screw, SS8, 6x3/8", PNH, TEK Self Drilling |

Additional Parts Listing

| Part Number | Part Description |
|-------------|---|
| 17500035 | Adaptor, Cigarette to Clips |
| 51350030 | Power Supply, AC Adapter, PP, 18V, 70W, CE |
| 57500008 | Assy, Power Cord, DC w/Amp |
| 51350015 | Case, Peristaltic Pump with foam |
| 51350026 | Faceplate, Gear, Hsng, Series II, Painted |
| 51350025 | Faceplate, Gear, Hsng, Series I, Painted |
| 17200079 | Screw, SS8, 8-32x1.25", Fillister, Peristaltic Pump |
| 17200199 | Screw, ZNC, 6-32x2.5", Thumb, Peristaltic Pump |
| 71350030 | Screw, SS8, 8-32x3", Phil |

Old Style Non-CE Parts

| Part Number | Part Description |
|--------------------|----------------------------------|
| 57500007 | Assy, Power Cord, AC, w/Amp |
| 51350007 | Assy, Diode, PP |
| 57500009 | Assy, Rectifier Bridge, PP-Logic |
| 51350013 | Assy, Transformer w/Jumper, PP |
| 51350004 | Assy, Wiring Harness, PP |

DOCUMENT REVISIONS

| EDCF# | DESCRIPTION | REV/DATE |
|-------|--|----------|
| - | Previous Release | 7/14/11 |
| - | Update Declaration of Conformity to include header, SP | 3/3/15 |

EC Declaration of Conformity

Manufacturer:

Geotech Environmental Equipment, Inc.
2650 E 40th Avenue
Denver, CO 80205

Declares that the following products,

Product Name: Geopump Peristaltic Pump

Model(s): 51350018 - GEOPUMP, CE, SERIES II, DC ONLY
51350021 - GEOPUMP, CE, SERIES I, DC ONLY
51350031 - GEOPUMP, CE, SERIES I
51350032 - GEOPUMP, CE, SERIES II

Year of manufacture: 2009

Conform to the principle safety objectives of 2006/95/EC Low Voltage Directive by application of the following standards:

EN 61010-1: 2010
EN 809-1 + A1:2010

Year of affixation of the CE Marking: 2009

Conform to the protection requirements of 2004/108/EC Electromagnetic Compatibility (EMC) by application of the following standards:

EN 61000-6-1: 2007
EN 61000-6-3: 2012
EN 61326-1: 2013

EMC conformity established: 08/14/2009

Production control follows the ISO 9001:2008 regulations and includes required safety routine tests.

This declaration issued under the sole responsibility of Geotech Environmental Equipment, Inc.

A handwritten signature in cursive script that reads "Joseph Leonard".

Joe Leonard
Product Development

Serial number _____

The Warranty

For a period of one (1) year from date of first sale, product is warranted to be free from defects in materials and workmanship. Geotech agrees to repair or replace, at Geotech's option, the portion proving defective, or at our option to refund the purchase price thereof. Geotech will have no warranty obligation if the product is subjected to abnormal operating conditions, accident, abuse, misuse, unauthorized modification, alteration, repair, or replacement of wear parts. User assumes all other risk, if any, including the risk of injury, loss, or damage, direct or consequential, arising out of the use, misuse, or inability to use this product. User agrees to use, maintain and install product in accordance with recommendations and instructions. User is responsible for transportation charges connected to the repair or replacement of product under this warranty.

Equipment Return Policy

A Return Material Authorization number (RMA #) is required prior to return of any equipment to our facilities, please call our 800 number for appropriate location. An RMA # will be issued upon receipt of your request to return equipment, which should include reasons for the return. Your return shipment to us must have this RMA # clearly marked on the outside of the package. Proof of date of purchase is required for processing of all warranty requests.

This policy applies to both equipment sales and repair orders.

FOR A RETURN MATERIAL AUTHORIZATION, PLEASE CALL OUR
SERVICE DEPARTMENT AT 1-800-833-7958.

Model Number: _____

Serial Number: _____

Date of Purchase: _____

Equipment Decontamination

Prior to return, all equipment must be thoroughly cleaned and decontaminated. Please make note on RMA form, the use of equipment, contaminants equipment was exposed to, and decontamination solutions/methods used. Geotech reserves the right to refuse any equipment not properly decontaminated. Geotech may also choose to decontaminate the equipment for a fee, which will be applied to the repair order invoice.



Geotech Environmental Equipment, Inc.

2650 East 40th Avenue Denver, Colorado 80205
(303) 320-4764 • **(800) 833-7958** • FAX (303) 322-7242
email: sales@geotechenv.com website: www.geotechenv.com

In the EU

Geotech Equipos Ambientales
Calle Francesc I Ferrer, Guardia Local 19, Mollet del Valles, Barcelona 08100, España
Tlf: (34)93 5445937
email: ventas@geotechenv.com
website: <http://spanish.geotechenv.com>

Printed in the United States of America

Multi RAE Photoionization Detector (PID)

I. Purpose

The purpose of this SOP is to provide general reference information for using the Multi RAE PID in the field. Calibration and operation, along with field maintenance, will be included in this SOP.

II. Scope

This procedure provides information on the field operation and general maintenance of the Multi RAE PID. Review of the information contained herein will ensure that this type of field monitoring equipment will be properly utilized. Review of the owner's instruction manuals is a necessity for more detailed descriptions.

III. Definitions

Carbon Monoxide Sensor (CO) - Carbon Monoxide concentration in ppm.

Volatile Organic Compound (VOC) - VOC concentration in ppm

Lower Explosive Limit (LEL) - Combustible gas is expressed as a percent of the lower explosive limit.

Hydrogen Sulfide Sensor (H₂S) - Hydrogen Sulfide concentration in ppm.

Oxygen Sensor (OXY) - Oxygen concentration as a percentage.

ppm - parts per million: parts of vapor or gas per million parts of air by volume.

IV. Procedures

The PID operates on the principle that most organic compounds and some inorganic compounds are ionized when they are bombarded by high-energy ultraviolet light. The air sample is drawn across a UV lamp using a pump or a fan. The energy of the lamp determines whether a particular chemical will be ionized. Each chemical compound has a unique photoionization potential (PIP). When the UV light energy is greater than the ionization potential of the chemical, ionization will occur. All PID readings are relative to the calibration gas, usually isobutylene.

It is important to calibrate the PID in the same temperature and elevation that the equipment will be used, and to determine the background concentrations in the field before taking measurements. For environments where background readings are high, factory zero calibration gas should be used.

Note: For volatile and semi-volatile compounds, knowing the PIP is critical in determining the appropriate instrument to use when organic vapor screening. Consult the QAPP and manufacturer's manual to determine that the proper instrument has been selected for the contaminate vapors of interest. If an expected compound at a site has a PIP less than 11.7 eV, it is possible to use a PID. If the ionization potential is greater than 11.7eV, a flame-ionization detector is required.

The following subsections will discuss Mini RAE calibration, operation, and maintenance. These sections, however, do not take the place of the instruction manual.

A. Calibration

For Multi RAE configured with O₂, LEL, H₂S, CO, sensors and a 10.6 eV PID Lamp.

Start up Instrument

- Press **Mode** button
- Observe displays:

On!.....

Multi RAE
Version X.XX

Model Number
SN XXXX

Date Time
Temp

Checking Sensor
Ids....

VOC Installed

CO Installed

H₂S Installed

OXY Installed

LEL Installed

H₂S VOC CO
LEL OXY

Alarm Limits=

XX XX.X XX
XX High XX.X

XX XX.X XX
XX Low XX.X

XX XX.X XX
STEL

XX XX.X XX
TWA

Battery = X.XV
Shut off at 4.2V

User Mode=

Alarm Mode=

Datalog Time Left

Datalog Mode

Datalog Period

Unit ready in.....
10 Seconds

- The pump will start, the seconds will count down to zero, and the instrument will be ready for use

Calibration Check and Adjustment

Allow instrument to warm up for 15 minutes.

- Depress the [N/-] key first, then while depressing the [N/-], depress the [Mode] key also and depress both keys for 5 seconds.
- Display will read:

Calibrate
Monitor?

- Press the [Y/+] key
- Display will read:

Fresh Air
Calibration?

- If “Zero Air” is necessary, attach the calibration adapter over the inlet port of the Multi RAE Monitor and connect the other end of the tube to the gas regulator (HAZCO loaner regulator LREG.5, RAE Systems P/N 008-3011 or suitable .5 LPM regulator) on the Zero Air bottle (HAZCO P/N SGZA, RAE P/N 600-0024). If no Zero Air is available, perform the Fresh Air Calibration in an area free of any detectable vapor.
- Press the [Y/+] key
- Display will read:

Zero....
In progress...

CO Zeroed!
Reading = X

VOC Zeroed!
Reading = X

LEL Zeroed!
Reading = X

OXY Zeroed!
Reading = X

Zero Cal done!
H₂S Zeroed!
Reading = X

In each of the above screens, “X” is equal to the reading of the sensor before it was zeroed.

- Display will then read:
- Press the [Y/+] key
 - The display shows all of the pre-selected sensors and the “OK?” question:

CO H₂S
LEL OK? OXY

- Apply calibration gas – use either HAZCO Services Part Number R-SGRAE4 or Rae Systems Part Number 008-3002 – using a .5 LPM regulator and direct tubing.
- Press the [Y/+] key. Display will read:

Apply Mixed gas

Calibration
In progress ...

- The display will count down showing the number of remaining seconds:

CO cal'ed
Reading=50

H₂S cal'ed
Reading=25

LEL cal'ed
Reading=50

OXY cal'ed
Reading=20.9

Calibration done
Turn off gas!

- Display will read:

Single Sensor
Calibration?

- Press the **[Y/+]**.
- Display will read:

CO VOC H₂S
LEL pick? OXY

- Attach 100 ppm Isobutylene (HAZCO P/N r-SGISO or Rae P/N 600-0002) using a 1.0 LPM regulator (HAZCO P/N LR10HS or Rae P/N 008-3021). Open regulator.
- Press the **[Mode]** key once, the V of VOC will be highlighted.
- Press the **[Y/+]**. The display will read:

Apply VOC Gas

Calibration
In progress...

- The display will count down showing the number of remaining seconds:, then display:

VOC cal'd
Reading=100

Calibration done
Turn off gas!

Single Sensor
Calibration?

- Press **[Mode]** key twice to return to main screen.

- **CALIBRATION IS COMPLETE!**

B. Operation

Due to the Multi RAE having many functions in terms of operation, it is recommended that you follow the operational procedures as outlined in the instruction manual from pages 9 to 14.

C. Site Maintenance

After each use, the meter should be recharged and the outside of the instruments should be wiped clean with a soft cloth.

D. Scheduled Maintenance

| <u>Function</u> | <u>Frequency</u> |
|--|--|
| Check alarm and settings | Monthly/before each use |
| Clean screens and gaskets around sensors | Monthly |
| Replace sensors | Biannually or when calibration is unsuccessful |

V. Quality Assurance Records

Quality assurance records will be maintained for each air monitoring event. The following information shall be recorded in the field logbook.

- Identification - Site name, date, location, CTO number, activity monitored, (surface water sampling, soil sampling, etc), serial number, time, resulting concentration, comments and identity of air monitoring personnel.
- Field observations - Appearance of sampled media (if definable).
- Additional remarks (e.g, Multi RAE had wide range fluctuations during air monitoring activities.)

VI. References

Multi RAE Plus Multiple Gas Monitor User Manual, RAE Systems, Revision B1, November 2003.

Decontamination of Drilling Rigs and Equipment

I. Purpose and Scope

The purpose of this guideline is to provide methods for the decontamination of drilling rigs, downhole drilling tools, and water-level measurement equipment. Personnel decontamination procedures are not addressed in this SOP; refer to the site safety plan and SOP *Decontamination of Personnel and Equipment*. Sample bottles will not be field decontaminated; instead they will be purchased with certification of laboratory sterilization.

II. Equipment and Materials

- Portable steam cleaner and related equipment
- Potable water
- Phosphate-free detergent such as Liquinox®
- Buckets
- Brushes
- Isopropanol, pesticide grade
- Personal Protective Equipment as specified by the Health and Safety Plan
- ASTM-Type II grade water or Lab Grade DI Water
- Aluminum foil

III. Procedures and Guidelines

A. Drilling Rigs and Monitoring Well Materials

Before the onset of drilling, after each borehole, before drilling through permanent isolation casing, and before leaving the site, heavy equipment and machinery will be decontaminated by steam cleaning at a designated area. The steam-cleaning area will be designed to contain decontamination wastes and waste waters and can be an HDPE-lined, bermed pad. A pumping system will be used to convey decontaminated water from the pad to drums.

Surface casings may be steam cleaned in the field if they are exposed to contamination at the site prior to use.

B. Downhole Drilling Tools

Downhole tools will be steam cleaned before the onset of drilling, prior to drilling through permanent isolation casing, between boreholes, and prior to leaving the site. This will include, but is not limited to, rods, split spoons or similar samplers, coring equipment, augers, and casing.

Before the use of a sampling device such as a split-spoon sampler for the collection of a soil sample for physical characterization, the sampler shall be cleaned by scrubbing with a detergent solution followed by a potable water rinse.

Before the use of a sampling device such as a split-spoon sampler for the collection of a soil sample for chemical analysis, the sampler shall be decontaminated following the procedures outlined in the following subsection.

C. Field Analytical Equipment

1. Water Level Indicators

Water level indicators that consist of a probe that comes into contact with the groundwater must be decontaminated using the following steps:

- a. Rinse with tap water
- b. Rinse with de-ionized water
- c. Solvent rinse with isopropanol (Optional)
- d. Rinse with de-ionized water

2. Probes

Probes, for example, pH or specific ion electrodes, geophysical probes, or thermometers that would come in direct contact with the sample, will be decontaminated using the procedures specified above unless manufacturer's instructions indicate otherwise. For probes that make no direct contact, for example, OVM equipment, the probe will be wiped with clean paper-towels or cloth wetted with isopropanol.

IV. Attachments

None.

V. Key Checks and Preventative Maintenance

- The effectiveness of field cleaning procedures may be monitored by rinsing decontaminated equipment with organic-free water and submitting the rinse water in standard sample containers for analysis.

Installation of Monitoring Wells by Sonic Drilling

I. Purpose and Scope

The purpose of this guideline is to describe methods for drilling and installation of groundwater monitoring wells and piezometers in unconsolidated or poorly consolidated materials using sonic drilling techniques. Sonic drilling technology potentially eliminates telescoping monitoring wells, allowing the installation of aquifer penetrating, single-cased wells.

II. Equipment and Materials

Drilling

- Sonic drilling rig
- Override casings and core barrel

Well Riser/Screen

- Polyvinyl chloride (PVC), Schedule 40, minimum 2-inch ID, flush-threaded riser; alternatively, stainless steel riser
- PVC, Schedule 40, minimum 2-inch ID, flush-threaded, factory slotted screen; alternatively, stainless steel screen.

Bottom Cap

- PVC, threaded to match the well screen; alternatively, stainless steel
- Centering guides (if used)

Well Cap

- Above-grade well completion: PVC, threaded or push-on type, vented
- Flush-mount well completion: PVC, locking, leak-proof seal
- Stainless steel to be used as appropriate

Sand

- Clean silica sand, provided in factory-sealed bags, well-rounded, containing no organic material, anhydrite, gypsum, mica, or calcareous material; primary (coarse – e.g., Morie #1) filter pack, and secondary (fine sand seal) filter pack. Grain size determined based on sediments observed during drilling.

Bentonite

- Pure, additive-free bentonite pellets
- Pure, additive-free powdered bentonite

- Coated bentonite pellets; coating must biodegrade within 7 days
- Cement-Bentonite Grout: proportion of 6 to 8 gallons of water per 94-pound bag of Portland cement; 3 pounds of bentonite added per bag of cement to reduce shrinkage

Protective Casing

- Above-grade well completion: 6-inch minimum ID black iron steel pipe with locking cover, diameter at least 2 inches greater than the well casing, painted with epoxy paint for rust protection; heavy duty lock; protective posts if appropriate
- Flush-mount well completion: 8-inch or 12-inch dia. manhole cover, or equivalent; rubber seal to prevent leakage

Well Development

- Surge block
- Well-development pump and associated equipment
- Calibrated meters to measure pH, temperature, specific conductance, and turbidity of development water
- Containers (e.g., 55 gallon drums) for water produced from well.

III. Procedures and Guidelines

A. Drilling Method

Drill rods and core barrel with a minimum 6-inch inside diameter (ID) will be used to drill monitoring well boreholes. Continuous core soil samples (4-inches outside diameter) will be collected for lithologic classification and intervals may be selected for chemical analysis. Soil sampling procedures are detailed in SOP *Shallow Soil Sampling*.

The use of water and additives to assist in sonic drilling for monitoring well installation will be minimized, unless required for such conditions as running sands or drilling bedrock formations.

Override casings, core barrels, and other downhole drilling tools will be decontaminated prior to the initiation of drilling activities and between each borehole location. Core barrels and other downhole soil sampling equipment will also be decontaminated before and after each use. SOP *Decontamination of Drilling Rigs and Equipment* details proper decontamination procedures.

Drill cuttings and decontamination fluids generated during well drilling activities will be contained according to the procedures detailed in the Field Sampling Plan.

B. Monitoring Well Installation

Sonic drilling technology eliminates the necessity to install double or triple cased wells since the borehole will be fully cased during drilling activities. Monitoring wells will be constructed inside the override casing(s), once the borehole has been advanced to the desired depth. Following setting the well screen, riser, filter pack, and bentonite seal, the well will be grouted as the temporary casing is withdrawn, preventing cross contamination. If the borehole has been drilled to a depth greater than that at which the well is to be set, the borehole will be backfilled with bentonite pellets or a bentonite-cement slurry to a depth approximately 1 foot below the intended well depth. Approximately 1 foot of clean sand will be placed on top of the bentonite to return the borehole to the proper depth for well installation.

The appropriate lengths of well screen, nominally 10 feet (with bottom cap), and casing will be joined watertight and lowered inside the temporary casing to the bottom of the borehole. Centering guides, if used, will be placed at the bottom of the screen and above the interval in which the bentonite seal is placed.

A primary sand pack consisting of clean Morie No. 00 (or DSI No.1) silica sand for 0.010-inch slotted screen and Morie No. 01 (or DSI No.2) silica sand for 0.020-inch slotted screen will be placed around the well screen. The sand will be placed into the borehole at a uniform rate, in a manner that will allow even placement of the sand pack. The inner-most override casing will be raised gradually during sand pack installation to avoid caving of the borehole wall; at no time will the innermost override casing be raised higher than the top of the sand pack during installation. During placement of the sand, the position of the top of the sand will be continuously sounded. The primary sand pack will extend from the bottom of the borehole to a minimum of 2 feet above the top of the well screen. A secondary, finer-grained sand pack may be installed for a minimum of 1 foot above the coarse sand pack. Heights of the coarse and fine sand packs and bentonite seal may be modified in the field to account for a shallow water table and small saturated thickness of the surficial aquifer.

A bentonite seal at least 2 feet thick will be placed above the sand pack. The seal will be placed into the borehole in a manner that will prevent bridging. The position of the top of the bentonite seal will be verified using a weighted tape measure. If all or a portion of the bentonite seal is above the water table, clean water will be added to hydrate the bentonite. A hydration period of at least 30 minutes will be required following installation of the bentonite seal.

Above the bentonite seal, an annular seal of cement-bentonite grout will be placed. The cement-bentonite grout will be installed continuously in one operation from the bottom of the space to be grouted to the ground surface through a tremie pipe. The tremie pipe must be plugged at the bottom and have small openings along the sides of the bottom 1-foot length of pipe. This will allow the grout to discharge laterally into the borehole and not disturb the bentonite pellet seal.

C. Well Completion

For monitoring wells that will be completed above-grade, a locking steel protective casing set in a concrete pad will be installed. The steel protective casing will extend at least 2 feet into the ground and 3 feet above ground but should not penetrate the bentonite seal. The concrete pad will be square, approximately 2 feet per side (unless otherwise specified in the project plans), and poured into wooden forms. The concrete will be sloped away from the protective casing.

Guard posts may be installed in high-traffic areas for additional protection. Four steel guard posts will be installed around the protective casing, within the edges of the concrete pad. Guard posts will be concrete-filled, at least 2 inches in diameter, and will extend at least 2 feet into the ground and 3 feet above the ground. The protective casing and guard posts will be painted with an epoxy paint to prevent rust.

For monitoring wells with flush-mount completions, Morrison 9-inch or 12-inch 519 manhole cover, or equivalent, with a rubber gasket and drain will be installed. The top of the manhole cover will be positioned approximately 1 inch above grade. A square concrete pad, approximately 2 feet per side (unless otherwise specified in the project plans), will be installed as a concrete collar surrounding the road box cover, and will slope uniformly downward to the adjacent grade. The road box and installation thereof will be of sufficient strength to withstand normal vehicular traffic.

Concrete pads installed at all wells will be a minimum of 6 inches below grade. The concrete pad will be 12-inches thick at the center and taper to 6-inch thick at the edge. The surface of the pad should slope away from the protective casing to prevent water from pooling around the casing. Protective casing, guard posts, and flush mounts will be installed into this concrete.

Each well will be properly labeled on the exterior of the locking cap or protective casing with a metal stamp indicating the permanent well number.

C. Well Development

Well development will be accomplished using a combination of surging throughout the well screen and pumping, until the physical and chemical parameters of the discharge water that are measured in the field have stabilized and the turbidity of the discharge water is substantially reduced. Fine-grained materials in the surficial aquifer at the site may not allow low turbidity results to be achieved.

The surging apparatus will include a tight-fitting surge block. Well development will begin by surging the well screen, starting at the bottom of the screen and proceeding upwards, throughout the screened zone. Following surging, the well will be pumped to remove the fine materials that have been drawn into the well. During pumping, measurements of pH, temperature, turbidity and specific conductance will be recorded.

Development will continue by alternately surging and pumping until the discharge water is free from sand and silt, the turbidity is substantially reduced, and the pH, temperature, and specific conductance have stabilized at regional background levels, based on historical data. Development will continue for a minimum of one hour until the water removed from the well is as clear of turbidity as practicable.

Well development equipment will be decontaminated prior to initial use and after the development of each well. Decontamination procedures are detailed in SOP *Decontamination of Personnel and Equipment*. Water generated during well development will be contained and managed as detailed in the SOP *Disposal of Waste Fluids and Solids* and the Investigation Derived Waste Management Plan.

IV. Attachments

Schematic diagram of shallow monitoring well construction (MWSingleDiag.xls)

STANDARD OPERATING PROCEDURE

Soil Sampling for Per- and Poly-fluoroalkyl Substances

I. Purpose

To provide general guidelines for the collection and handling of soil samples collected in support of per- and poly-fluorinated alkyl substance (PFAS) investigations.

Standard techniques for collecting representative samples are summarized. These procedures are specific to the Navy Comprehensive Long-term Environmental Action Navy (CLEAN) Program under Contract N62470-16-D-9000.

II. Scope

The method described applies to soil sampling for PFAS constituents using a variety of collection tools (hand auger, split spoon, direct push technology [DPT] sampling, and trowel collection).

III. Equipment and Materials

- Sample jars (sample jars should be made of polyethylene as glass jars may sorb PFAS, please notify the project manager [PM] if glass jars are provided by the lab). Sample containers should not contain Teflon lids.
- A hand auger or other device that can be used to remove the soil from the ground. Stainless steel tools, carbon steel tools, or steel DPT tooling with acetate sleeves are preferred for PFAS sampling. Avoid any sampling materials containing Teflon. Any plastic sampling materials should be evaluated thoroughly before selection to ensure they are fluorine-free
- A stainless steel spatula or fluorine-free disposable plastic scoop should be used to remove material from the sampling device.
- Unpainted wooden stakes or pin flags
- Fiberglass measuring tape (at least 200 feet in length)
- GPS Unit
- PFAS-free shipping materials
- Loose leaf paper or a wire-bound notebook without waterproof coating
- Clipboard (if using loose-leaf paper)
- Pen (not Sharpie)
- Nitrile or Latex gloves

Equipment and materials used to collect soil samples should not contain any fluorinated compounds including Teflon or synthetic rubber with fluoropolymer elastomers (e.g. Viton).

Specifically, the following material should be avoided during sampling:

- Gore-tex brand or similar high-performance outdoor clothing, clothing treated with ScotchGuard brand or similar water repellent, fluoropolymer-coated Tyvek, wrinkle-resistant fabrics, and fire-resistant clothing with fluorochemical treatment or anything advertised as a water repellent.
- Weatherproof logbooks with fluorochemical coatings
- New clothing that has been washed fewer than six times

If a driller is supporting collection of soil samples in split spoons or acetate DPT sleeves, ensure the driller has not used and will not use drilling lube containing polytetrafluoroethylene (PTFE) or any other fluorine-containing substance. Biolube has been determined to be an acceptable substitute.

IV. Procedures and Guidelines

Prior to initiating soil sampling activities, steps should be taken to ensure the sampling area is free of pre-packaged food wrappers, microwave popcorn bags, blue ice containers, aluminum foil, Kim-wipes, sunscreen, insect repellent, and other personal hygiene products unless these products have been confirmed to be fluorine-free.

Research which has not yet been published has allowed us to generate a list of sunscreens and insect repellents which do not contain fluorine. Check with Bill Diguseppi or Laura Cook on recommendations (because the research is not ours, it cannot be released externally at this time).

Once the area has been determined to be free of materials potentially containing PFAS, these steps can be followed to collect the soil samples:

- A. Wear protective gear, as specified in the Health and Safety Plan.
- B. To locate samples, identify the correct location using the pin flags or stakes. Proceed to collect a sample from the undisturbed soil adjacent to the marker following steps C and D. If markers are not present, the following procedures will be used.
 1. For samples on a grid:
 - a. Use measuring tape to locate each sampling point on the first grid line as prescribed in the sampling plan. As each point is located, drive a numbered stake in the ground and record its location on the site map and in the field notebook/clipboard.
 - b. Proceed to sample the points on the grid line.
 - c. Measure to location where next grid line is to start and stake first sample. For subsequent samples on the line take two orthogonal measurements: one to the previous grid line, and one to the previous sample on the same grid line.
 - d. Proceed to sample the points on the grid line as described in Section C below.
 - e. Repeat 1c and 1d above until all samples are collected from the area.

- f. Or, a GPS unit can be used to identify each location based on map coordinated, if available.
 2. For non-grid samples:
 - a. Use measuring tape to position sampling point at location described in the sampling plan by taking two measurements from fixed landmarks (e.g., corner of house and fence post).
 - b. Note measurements, landmarks, and sampling point on a sketch in the field notebook, and on a site location map.
 - c. Proceed to sample as described in Section C below.
 - d. Repeat 2a through 2c above until all samples are collected from the area.
 - e. Or, a GPS unit can be used to identify each location based on map coordinated, if available.
- C. To the extent possible, differentiate between fill and natural soil. If both are encountered at a boring location, sample both as prescribed in the field sampling plan. Do not locate samples in debris, tree roots, or standing water. In residential areas, do not sample in areas where residents' activities may impact the sample (e.g., barbecue areas, beneath eaves of roofs, driveways, garbage areas). If an obstacle prevents sampling at a measured grid point, move as close as possible, but up to a distance of one half the grid spacing in any direction to locate an appropriate sample. If an appropriate location cannot be found, consult with the Field Team Leader (FTL). If the FTL concurs, the sampling point may be deleted from the program. The FTL will contact the CH2M HILL PM immediately. The PM and Navy Technical Representative (NTR) will discuss whether the point should be deleted from the program. If it is deleted, the PM will follow-up with the NTR in writing.
- D. To collect samples using standard methods:
1. Use a decontaminated stainless steel scoop/trowel or disposable plastic scoop to scrape away surficial organic material (grass, leaves, etc.) adjacent to the stake. New disposable scoops or trowels may also be used to reduce the need for equipment blanks if the disposable scoops have been confirmed by your project PFAS subject matter expert (SME) to be PFAS free.
 2. If sampling:
 - a. Surface soil: Obtain soil sample by scooping soil using the augering scoop/trowel, starting from the surface and digging down to a depth of about 6 inches, or the depth specified in the workplan.
 - b. Subsurface soil: Obtain the subsurface soil sample using an auger down to the depths prescribed in the field sampling plan.
 3. Record lithologic description and any pertinent observations (such as discoloration) in the field notebook/clipboard.
 4. Empty the contents of the scoop/trowel into a decontaminated stainless steel pan or dedicated sealable bag.
 5. Repeat this procedure until sufficient soil is collected to meet volume requirements.

6. Homogenize cuttings in the pan using a decontaminated stainless steel utensil.
7. Transfer sample for analysis into appropriate containers with a decontaminated utensil.
8. Immediately upon collection, all samples for chemical analysis are to be placed in a closed container on ice unless it is not possible to do so. Although unusual and uncommon, there may be instances where it is not possible to have containers with ice at the sample location. In these instances, the samples should be placed on ice as soon as practical and during the time between collection and placing the samples on ice, the samples should be kept as cool as possible.
9. Backfill the hole with soil removed from the borehole. To the extent possible, replace topsoil and grass and attempt to return appearance of sampling area to its pre-sampled condition. For samples in non-residential, unmowed areas, mark the sample number on the stake and leave stake in place. In mowed areas, remove stake.

E. To collect Samples Using DPT Methods

1. Decontaminate sampling tubes and other non-dedicated downhole equipment in accordance with SOP *Decontamination of Personnel and Equipment*. Ensure that decontamination water used is PFAS free (do not use water from fire hydrants on-base for steam cleaning unless the water has been demonstrated to be free of PFAS).
2. Drive sampling tube to the desired sampling depth using the truck-mounted hydraulic percussion hammer. If soil above the desired depth is not to be sampled, first drive the lead rod, without a sampling tube, to the top of the desired depth.
3. Remove the rods and sampling tube from the borehole and remove the sampling tube from the lead rod.
4. Cut open the acetate liner using a specific knife designed to slice the acetate liners (see below).



5. Fill all sample containers, using a decontaminated or dedicated sampling implement. Label the containers and immediately place samples on ice for shipment to the laboratory.
6. Decontaminate all non-dedicated downhole equipment (rods, sampling tubes, etc.) in accordance with SOP *Decontamination of Personnel and Equipment* and ensure decontamination water is from a PFAS-free water source.

7. Backfill borehole at each sampling location with grout or bentonite and repair the surface with like material (bentonite, asphalt patch, concrete, etc.), as required.

V. Attachments

None.

VI. Key Checks and Items

- Decontaminate utensils before reuse with the last rinse using laboratory-provided certified PFAS-free water or use dedicated, disposable utensils which are PFAS-free.
- Field blank and field reagent blank procedures for PFAS sampling vary based on the lab's Method 537 Modified SOP. When using a Department of Defense (DoD) Environmental Laboratory Accreditation Program (ELAP) accredited laboratory, follow any procedures specified in the approved method.

References

United States Environmental Protection Agency (USEPA), 2009. *Determination of Selected Perfluorinated Alkyl Acids in Drinking Water by Solid Phase Extraction and Liquid Chromatography/Tandem Mass Spectrometry (LC/MS/MS)*. September.

United States Navy, 2015. *Field Sampling Protocols to Avoid Cross-Contamination during Water Sampling for Perfluorinated Compounds (PFCs)*.

Appendix B
Laboratory DoD ELAP
Accreditation Letters



SCOPE OF ACCREDITATION TO ISO/IEC 17025:2005

VISTA ANALYTICAL LABORATORY
 1104 Windfield Way
 El Dorado Hills, CA 95762
 Martha Maier Phone: 916-673-1520
 mmaier@vista-analytical.com

ENVIRONMENTAL

Valid To: September 30, 2019

Certificate Number: 3091.01

In recognition of the successful completion of the A2LA evaluation process, (including an assessment of the laboratory's compliance with ISO IEC 17025:2005, the 2009 TNI Environmental Testing Laboratory Standard, the requirements of the DoD Environmental Laboratory Accreditation Program (DoD ELAP) as detailed in version 5.1 of the DoD Quality Systems Manual for Environmental Laboratories), accreditation is granted to this laboratory to perform recognized EPA methods using the following testing technologies and in the analyte categories identified below:

Testing Technologies

High Resolution Gas Chromatography / Mass Spectrometry
 Liquid Chromatography Mass Spectrometry / Mass Spectrometry

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|--|---------------|-------------------|-----------------------|-------------------|
| <u>Dioxins/Furans</u> | | | | |
| 2,3,7,8-Tetrachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,7,8-Pentachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,4,7,8-Hexachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,6,7,8-Hexachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,7,8,9-Hexachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,4,6,7,8-Heptachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,4,6,7,8,9-Octachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 2,3,7,8-Tetrachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,7,8-Pentachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 2,3,4,7,8-Pentachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,4,7,8-Hexachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |

(A2LA Cert. No. 3091.01) Revised 07/10/2017

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|--|---------------|--------------------|-----------------------|--------------------|
| 1,2,3,6,7,8-Hexachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 2,3,4,6,7,8-Hexachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,7,8,9-Hexachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,4,6,7,8-Heptachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,4,7,8,9-Heptachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| 1,2,3,4,6,7,8,9-Octachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Heptachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Heptachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Hexachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Hexachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Pentachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Pentachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Tetrachlorodibenzofuran | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| Total Tetrachlorodibenzo-p-dioxin | ----- | EPA 1613B/8290 | EPA 1613B/8290 | EPA 1613B/8290 |
| PCBs | | | | |
| 2-Chlorobiphenyl (1) | ----- | EPA 168A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3-Chlorobiphenyl (2) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 4-Chlorobiphenyl (3) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2'-Dichlorobiphenyl (4) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3-Dichlorobiphenyl (5) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3'-Dichlorobiphenyl (6) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4-Dichlorobiphenyl (7) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4'-Dichlorobiphenyl (8) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,5-Dichlorobiphenyl (9) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,6-Dichlorobiphenyl (10) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|-------------------------------|---------------|--------------------|-----------------------|--------------------|
| 3,3'-Dichlorobiphenyl (11) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,4-Dichlorobiphenyl (12) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,4'-Dichlorobiphenyl (13) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,5-Dichlorobiphenyl (14) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 4,4'-Dichlorobiphenyl (15) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3-Trichlorobiphenyl (16) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4-Trichlorobiphenyl (17) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',5-Trichlorobiphenyl (18) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',6-Trichlorobiphenyl (19) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3'-Trichlorobiphenyl (20) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4-Trichlorobiphenyl (21) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4'-Trichlorobiphenyl (22) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,5-Trichlorobiphenyl (23) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,6-Trichlorobiphenyl (24) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4-Trichlorobiphenyl (25) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',5-Trichlorobiphenyl (26) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',6-Trichlorobiphenyl (27) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4,4'-Trichlorobiphenyl (28) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4,5-Trichlorobiphenyl (29) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4,6-Trichlorobiphenyl (30) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4',5-Trichlorobiphenyl (31) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4',6-Trichlorobiphenyl (32) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2',3,4-Trichlorobiphenyl (33) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2',3,5-Trichlorobiphenyl (34) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|------------------------------------|---------------|--------------------|-----------------------|--------------------|
| 3,3',4-Trichlorobiphenyl (35) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',5-Trichlorobiphenyl (36) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,4,4'-Trichlorobiphenyl (37) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,4,5-Trichlorobiphenyl (38) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,4',5-Trichlorobiphenyl (39) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3'-Tetrachlorobiphenyl (40) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4-Tetrachlorobiphenyl (41) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4'-Tetrachlorobiphenyl (42) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5-Tetrachlorobiphenyl (43) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5'-Tetrachlorobiphenyl (44) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,6-Tetrachlorobiphenyl (45) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,6'-Tetrachlorobiphenyl (46) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,4'-Tetrachlorobiphenyl (47) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,5-Tetrachlorobiphenyl (48) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,5'-Tetrachlorobiphenyl (49) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,6-Tetrachlorobiphenyl (50) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,6'-Tetrachlorobiphenyl (51) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',5,5'-Tetrachlorobiphenyl (52) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',5,6'-Tetrachlorobiphenyl (53) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',6,6'-Tetrachlorobiphenyl (54) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4'-Tetrachlorobiphenyl (55) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4-Tetrachlorobiphenyl (56) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',5-Tetrachlorobiphenyl (57) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',5'-Tetrachlorobiphenyl (58) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|--------------------------------------|---------------|--------------------|-----------------------|--------------------|
| 2,3,3',6-Tetrachlorobiphenyl (59) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4,4'-Tetrachlorobiphenyl (60) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4,5-Tetrachlorobiphenyl (61) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4,6-Tetrachlorobiphenyl (62) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4',5-Tetrachlorobiphenyl (63) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4',6-Tetrachlorobiphenyl (64) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,5,6-Tetrachlorobiphenyl (65) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,4'-Tetrachlorobiphenyl (66) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,5-Tetrachlorobiphenyl (67) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,5'-Tetrachlorobiphenyl (68) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,6-Tetrachlorobiphenyl (69) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4',5-Tetrachlorobiphenyl (70) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4',6-Tetrachlorobiphenyl (71) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',5,5'-Tetrachlorobiphenyl (72) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',5',6-Tetrachlorobiphenyl (73) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4,4',5-Tetrachlorobiphenyl (74) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,4,4',6-Tetrachlorobiphenyl (75) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2',3,4,5-Tetrachlorobiphenyl (76) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',4,4'-Tetrachlorobiphenyl (77) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',4,5-Tetrachlorobiphenyl (78) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',4,5'-Tetrachlorobiphenyl (79) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',5,5'-Tetrachlorobiphenyl (80) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,4,4',5-Tetrachlorobiphenyl (81) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4-Pentachlorobiphenyl (82) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|---------------------------------------|---------------|--------------------|-----------------------|--------------------|
| 2,2',3,3',5-Pentachlorobiphenyl (83) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',6-Pentachlorobiphenyl (84) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4'-Pentachlorobiphenyl (85) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5-Pentachlorobiphenyl (86) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5'-Pentachlorobiphenyl (87) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,6-Pentachlorobiphenyl (88) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,6'-Pentachlorobiphenyl (89) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',5-Pentachlorobiphenyl (90) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',6-Pentachlorobiphenyl (91) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5,5'-Pentachlorobiphenyl (92) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5,6-Pentachlorobiphenyl (93) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5,6'-Pentachlorobiphenyl (94) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5',6-Pentachlorobiphenyl (95) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,6,6'-Pentachlorobiphenyl (96) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3',4,5-Pentachlorobiphenyl (97) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3',4,6-Pentachlorobiphenyl (98) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,4',5-Pentachlorobiphenyl (99) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,4',6-Pentachlorobiphenyl (100) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,5,5'-Pentachlorobiphenyl (101) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,5,6'-Pentachlorobiphenyl (102) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,5,'6-Pentachlorobiphenyl (103) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,6,6'-Pentachlorobiphenyl (104) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4'-Pentachlorobiphenyl (105) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,5-Pentachlorobiphenyl (106) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|---|---------------|--------------------|-----------------------|--------------------|
| 2,3,3',4',5-Pentachlorobiphenyl (107) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,5'-Pentachlorobiphenyl (108) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,6-Pentachlorobiphenyl (109) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4',6-Pentachlorobiphenyl (110) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',5,5'-Pentachlorobiphenyl (111) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',5,6-Pentachlorobiphenyl (112) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',5',6-Pentachlorobiphenyl (113) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4,4',5-Pentachlorobiphenyl (114) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4,4',6-Pentachlorobiphenyl (115) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4,5,6-Pentachlorobiphenyl (116) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4',5,6-Pentachlorobiphenyl (117) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,4',5-Pentachlorobiphenyl (118) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,4',6-Pentachlorobiphenyl (119) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,5,5'-Pentachlorobiphenyl (120) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,5',6-Pentachlorobiphenyl (121) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2',3,3',4,5-Pentachlorobiphenyl (122) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2',3,4,4',5-Pentachlorobiphenyl (123) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2',3,4,5,5'-Pentachlorobiphenyl (124) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2',3,4,5,6'-Pentachlorobiphenyl (125) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',4,4',5-Pentachlorobiphenyl (126) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',4,5,5'-Pentachlorobiphenyl (127) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4'-Hexachlorobiphenyl (128) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5-Hexachlorobiphenyl (129) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5'-Hexachlorobiphenyl (130) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|---|---------------|--------------------|-----------------------|--------------------|
| 2,2',3,3',4,6-Hexachlorobiphenyl (131) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,6'-Hexachlorobiphenyl (132) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',5,5'-Hexachlorobiphenyl (133) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',5,6-Hexachlorobiphenyl (134) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',5,6'-Hexachlorobiphenyl (135) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',6,6'-Hexachlorobiphenyl (136) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',5-Hexachlorobiphenyl (137) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',5'-Hexachlorobiphenyl (138) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',6-Hexachlorobiphenyl (139) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',6'-Hexachlorobiphenyl (140) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5,5'-Hexachlorobiphenyl (141) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5,6-Hexachlorobiphenyl (142) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5,6'-Hexachlorobiphenyl (143) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5',6-Hexachlorobiphenyl (144) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,6,6'-Hexachlorobiphenyl (145) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',5,5'-Hexachlorobiphenyl (146) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',5,6-Hexachlorobiphenyl (147) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',5,6'-Hexachlorobiphenyl (148) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',5',6-Hexachlorobiphenyl (149) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',6,6'-Hexachlorobiphenyl (150) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5,5',6-Hexachlorobiphenyl (151) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,5,6,6'-Hexachlorobiphenyl (152) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,4',5,5'-Hexachlorobiphenyl (153) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',4,4',5',6-Hexachlorobiphenyl (154) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|--|---------------|--------------------|-----------------------|--------------------|
| 2,2',4,4',6,6'-Hexachlorobiphenyl (155) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4',5-Hexachlorobiphenyl (156) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4',5'-Hexachlorobiphenyl (157) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4',6-Hexachlorobiphenyl (158) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,5,5'-Hexachlorobiphenyl (159) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,5,6-Hexachlorobiphenyl (160) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,5',6-Hexachlorobiphenyl (161) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4',5,5'-Hexachlorobiphenyl (162) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4',5,6-Hexachlorobiphenyl (163) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4',5',6-Hexachlorobiphenyl (164) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',5,5',6-Hexachlorobiphenyl (165) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,4,4',5,6-Hexachlorobiphenyl (166) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,4',5,5'-Hexachlorobiphenyl (167) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3',4,4',5',6-Hexachlorobiphenyl (168) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 3,3',4,4',5,5'-Hexachlorobiphenyl (169) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',5-Heptachlorobiphenyl (170) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',6-Heptachlorobiphenyl (171) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5,5'-Heptachlorobiphenyl (172) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5,6-Heptachlorobiphenyl (173) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5,6'-Heptachlorobiphenyl (174) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5',6-Heptachlorobiphenyl (175) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,6,6'-Heptachlorobiphenyl (176) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4',5,6-Heptachlorobiphenyl (177) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',5,5',6-Heptachlorobiphenyl (178) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|--|---------------|--------------------|-----------------------|--------------------|
| 2,2',3,3',5,6,6'-Heptachlorobiphenyl (179) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',5,5'-Heptachlorobiphenyl (180) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',5,6-Heptachlorobiphenyl (181) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',5,6'-Heptachlorobiphenyl (182) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',5',6-Heptachlorobiphenyl (183) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',6,6'-Heptachlorobiphenyl (184) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5,5',6-Heptachlorobiphenyl (185) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,5,6,6'-Heptachlorobiphenyl (186) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',5,5',6-Heptachlorobiphenyl (187) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4',5,6,6'-Heptachlorobiphenyl (188) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4',5,5'-Heptachlorobiphenyl (189) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4',5,6-Heptachlorobiphenyl (190) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4',5',6-Heptachlorobiphenyl (191) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,5,5',6-Heptachlorobiphenyl (192) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4',5,5',6-Heptachlorobiphenyl (193) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',5,5'-Octachlorobiphenyl (194) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',5,6-Octachlorobiphenyl (195) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',5,6'-Octachlorobiphenyl (196) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',6,6'-Octachlorobiphenyl (197) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5,5',6-Octachlorobiphenyl (198) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5,5',6'-Octachlorobiphenyl (199) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5,6,6'-Octachlorobiphenyl (200) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5',6,6'-Octachlorobiphenyl (201) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',5,5',6,6'-Octachlorobiphenyl (202) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|---|---------------------------|--------------------|---------------------------|---------------------------|
| 2,2',3,4,4',5,5',6-Octachlorobiphenyl (203) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,4,4',5,6,6'-Octachlorobiphenyl (204) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,3,3',4,4',5,5',6-Octachlorobiphenyl (205) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',5,5',6-Nonachlorobiphenyl (206) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,4',5,6,6'-Nonachlorobiphenyl (207) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| 2,2',3,3',4,5,5',6,6'-Nonachlorobiphenyl (208) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Decachlorobiphenyl (209) | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Decachlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Dichlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Heptachlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Hexachlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Monochlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Nonachlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Octachlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Pentachlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Tetrachlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Trichlorobiphenyl, Total | ----- | EPA 1668A/1668C | EPA 1668A/1668C | EPA 1668A/1668C |
| Per- and Poly-fluorinated compounds | | | | |
| 6:2 Fluorotelomer sulfanate (6:2 FTS) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| 8:2 Fluorotelomer sulfanate (8:2 FTS) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| N-ethyl perfluorooctanesulfonamidoacetic acid (N-EtFOSAA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| N-ethylperfluoro-1-octanesulfonamide (N-EtFOSA) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|--|---------------------------|------------------|---------------------------|---------------------------|
| N-ethylperfluoro-1-octanesulfonamido ethanol (N-EtFOSE) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| N-methyl perfluorooctanesulfonamidoacetic acid (N-MeFOSAA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| N-methylperfluoro-1-octanesulfonamide (N-MeFOSA) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| N-methylperfluoro-1-octanesulfonamido ethanol (N-MeFOSE) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorobutanesulfonic acid (PFBS) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorobutanoic acid (PFBA) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorodecanesulfonate (PFDS) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorodecanoic acid (PFDA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorododecanoic acid (PFDoA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluoroundecanoic acid (PFUnA) | EPA 537 | ----- | ----- | ----- |
| Perfluoroheptanesulfonate (PFHpS) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluoroheptanoic acid (PFHpA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorohexadecanoic acid (PFHxDA) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorohexanesulfonic acid (PFHxS) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorohexanoic acid (PFHxA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorononaic acid (PFNA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorooctane sulfonamide (PFOSA) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |



| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste | Tissue |
|--------------------------------------|---------------------------|-------------------------|------------------------------|---------------------------------|
| Perfluorooctanesulfonic acid (PFOS) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorooctanoic acid (PFOA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluoropentanoic acid (PFPeA) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorotetradecanoic acid (PFTeDA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluorotridecanoic acid (PFTrDA) | EPA 537 EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |
| Perfluoroundecanoic acid (PFUdA) | EPA 537 (Mod.) | EPA 537 (Mod.) | EPA 537 (Mod.) (VAL-PFAS) | EPA 537 (Mod.) (VAL-PFAS) |





Accredited Laboratory

A2LA has accredited

VISTA ANALYTICAL LABORATORY

El Dorado Hills, CA

for technical competence in the field of

Environmental Testing

In recognition of the successful completion of the A2LA evaluation process that includes an assessment of the laboratory's compliance with ISO/IEC 17025:2005, the 2009 TNI Environmental Testing Laboratory Standard, and the requirements of the Department of Defense Environmental Laboratory Accreditation Program (DoD ELAP) as detailed in version 5.1 of the DoD Quality System Manual for Environmental Laboratories (QSM), accreditation is granted to this laboratory to perform recognized EPA methods as defined on the associated A2LA Environmental Scope of Accreditation. This accreditation demonstrates technical competence for this defined scope and the operation of a laboratory quality management system (refer to joint ISO-ILAC-IAF Communiqué dated 8 January 2009).



Presented this 5th day of July 2017.

A handwritten signature in black ink, written over a horizontal line.

President and CEO
For the Accreditation Council
Certificate Number 3091.01
Valid to September 30, 2019

For the tests to which this accreditation applies, please refer to the laboratory's Environmental Scope of Accreditation.

Appendix C
Laboratory Standard Operating
Procedures